
STEERING

STEERING

CONTENTS

3710900023

GENERAL INFORMATION	2	Checking Steering Wheel Return to Centre (Power Steering)	10
SERVICE SPECIFICATIONS	3	Drive Belt Tension Check (Power Steering)	11
LUBRICANTS	4	Fluid Level Check (Power Steering)	11
SEALANTS	4	Fluid Replacement (Power Steering)	11
SPECIAL TOOLS	4	Bleeding (Power Steering)	12
ON-VEHICLE SERVICE	7	Oil Pump Pressure Test (Power Steering)	13
Steering Wheel Free Play Check	7	Power Steering Oil Pressure Switch Check (Power Steering) <Petrol-powered vehicles>	14
Steering Angle Check	7	STEERING WHEEL AND SHAFT*	15
Steering Gear Backlash Check	8	MANUAL STEERING GEAR BOX*	19
Tie Rod End Ball Joint Variation Check (Shaft Direction)	9	POWER STEERING GEAR BOX*	26
Tie Rod End Ball Joint Starting Torque Check	9	POWER STEERING OIL PUMP	37
Steering Gear Oil Level Check (Manual Steering)	10	POWER STEERING HOSES	45
Stationary Steering Effort Check (Power Steering)	10	STEERING LINKAGE	49

WARNINGS REGARDING SERVICING OF SUPPLEMENTAL RESTRAINT SYSTEM (SRS) EQUIPPED VEHICLES

WARNING!

- (1) Improper service or maintenance of any component of the SRS, or any SRS-related component, can lead to personal injury or death to service personnel (from inadvertent firing of the air bag) or to the driver (from rendering the SRS inoperative).
- (2) Service or maintenance of any SRS component or SRS-related component must be performed only at an authorized MITSUBISHI dealer.
- (3) MITSUBISHI dealer personnel must thoroughly review this manual, and especially its GROUP 52B – Supplemental Restraint System (SRS) before beginning any service or maintenance of any component of the SRS or any SRS-related component.

NOTE

The SRS includes the following components: impact sensor, SRS diagnosis unit, SRS warning lamp, air bag module, clock spring and interconnecting wiring. Other SRS-related components (that may have to be removed/installed in connection with SRS service or maintenance) are indicated in the table of contents by an asterisk (*).

GENERAL INFORMATION


37100010025

Engine speed-responsive hydraulic power steering or manual steering has been used. The main features are as follows. The steering wheel has four spokes. In addition, SRS (Supplemental Restraint System) is available as an option in all vehicles.

The steering column in all vehicles has a shock absorber mechanism and a tilt steering mechanism. A vane-type oil pump with a fluid flow control system has been included. The steering gear and linkage is ball and nut type.

Items		Specifications	
Manual steering gear box	Type	Ball and nut type	
	Gear ratio	18.5 – 23.0	
Power steering gear box	Type	Ball and nut type	
	Gear ratio	2WD	18.5 – 23.0
		4WD	16.4 – 18.0
Oil pump	Type	Vane type	
	Displacement ml/rev.	9.6	
	Relief set pressure MPa	8.3 – 9.0	

CONSTRUCTION DIAGRAM



A13V0076

SERVICE SPECIFICATIONS

37100030021

Items		Standard value	Limit	
Steering wheel free play mm		With engine running	–	50
		With engine stopped	10 or less	–
Steering angle	2WD	Inner wheel	33°55' – 36°55'	–
		Outer wheel	30°57'	–
	4WD	Inner wheel	29°40' – 32°40'	–
		Outer wheel	29°30'	–
Steering gear backlash mm		–	0.5	
Variation of tie rod end ball joint shaft direction mm		–	1.5	
Tie rod end ball joint starting torque Nm		3.0	–	
Steering gear oil level mm		22	–	
Engine idle speed r/min		4G6	750 ± 100	–
		4D56	750 ± 100	–
Stationary steering effort N		39.2 or less	–	
Oil pump pressure MPa	Oil pump relief pressure		8.3 – 9.0	–
	Pressure under no-load conditions		0.8 – 1.0	–
	Steering gear retention hydraulic pressure		8.3 – 9.0	–
Oil pressure switch operating pressure MPa		OFF → ON	1.5 – 2.0	–
		ON → OFF	0.7 – 1.2	–
Mainshaft starting torque Nm		0.49 – 0.78	–	
Cross-shaft axial play mm		0.05 or less	–	
Mainshaft total starting torque Nm		<2WD>	0.98 – 1.47	–
		<4WD>	0.69 – 1.28	–
Pitman arm ball joint starting torque Nm		0.5 – 1.5	–	
Mainshaft axial play mm		0.03 or less	–	
Backlash between ball groove of rack piston and balls mm		–	0.05	
Idler arm sliding resistance N		2WD	8.8 – 30	–
		4WD	2.4 – 16	–

LUBRICANTS

37100040017

Items	Specified lubricants	Quantity ℓ
Manual steering gear oil	Hypoid gear oil API GL-4 or higher SAE80	0.21
Power steering fluid	Automatic transmission fluid DEXRON or DEXRON II	0.8
Seal ring, rack piston, mainshaft, cross-shaft, bearing, O-ring, oil seal, vane	Automatic transmission fluid DEXRON or DEXRON II	As required





SEALANTS

37100050010





Items	Specified sealants	Remarks
Cover assembly installation hole Adjusting bolt, seal bolt, packing, adjusting shim, dust cover lip for ball joint	3M ATD Part No.8663 or equivalent	Semi-drying sealant


SPECIAL TOOLS

37100060013

Tool	Number	Name	Use
 B990948	MB990948	Linkage joint gauge	Ball joint variation check for shaft direction
 00003982	MB991113 or MB990635	Steering linkage puller	Disconnection of ball joint
	MB990685 MB991151	Torque wrench	<ul style="list-style-type: none"> • Measurement of the ball joint starting torque • Measurement of the pinion shaft preload • Measurement of the mainshaft starting torque
	MB990326	Preload socket	Measurement of the ball joint starting torque
 B990993	MB990993 or MB991217	Power steering oil pressure gauge adapter (pump side)	Measurement of oil pressure

Tool	Number	Name	Use
<p>B990994</p>	MB990994	Power steering oil pressure gauge adapter (hose side)	Measurement of oil pressure
<p>B990662</p>	MB990662	Oil pressure gauge assembly	
<p>B990803</p>	MB990803	Steering wheel puller	Disconnection of the steering wheel
<p>B991006</p>	MB991006 or MB990228	Preload socket	Measurement of the mainshaft total starting torque
<p>B990776</p>	MB990776	Front axle base	Installation of dust cover for tie rod end ball joint
	MB990628	Snap ring pliers	To remove and install the snap ring of the pulley assembly
<p>B990925</p>	MB990925	Bearing and oil seal installer set	Installation of the oil seal and bearing (Refer to GROUP 26 – Special Tools.)
<p>B990915</p>	MB990915	Pitman arm puller	Removal of the pitman arm
<p>B991367</p>	MB991367	Special spanner	Removal and installation of the lock nut

Tool	Number	Name	Use
 <p>B991394</p>	MB991394	Pin set	Removal and installation of the lock nut
 <p>B991203</p>	MB991203	Oil seal & bearing installer	To press in the valve housing oil seal and bearing
 <p>B990956</p>	MB990956	Needle bearing installer	To press in the drive shaft assembly
	MB991172	Adapter	
	MB990767	End yolk holder	Securing the drive pulley
	MD998719 or MD998754	Crankshaft pulley holder pin	



ON-VEHICLE SERVICE

37100090036

STEERING WHEEL FREE PLAY CHECK

<Manual steering>

1. Set the front wheels straight ahead.
2. Measure the play on the steering wheel circumference before wheels move when slightly moving the steering wheel in both directions.

Limit: 50 mm

3. When the play exceeds the limit, check the play in the steering shaft connection and steering linkage. Correct or replace.
4. When (3) check provides good results, check the following to adjust:
 - Remove the steering gear box, check and adjust the mainshaft total starting torque.

<Power steering>


1. With engine running (hydraulic operation), set front wheels straight ahead.
2. Measure the play on steering wheel circumference before wheels start to move when slightly moving steering wheel in both directions.

Limit: 50 mm

3. When play exceeds the limit, check for play on steering shaft connection and steering linkage. Correct or replace.
4. If the free play still exceeds the limit value, set steering wheel straight ahead with engine stopped. Load 5 N towards steering wheel circumference and check play.

Standard value (steering wheel play with engine stopped): 10 mm or less

If the play exceeds the standard value, check the steering gear backlash and ball joint axial play.




STEERING ANGLE CHECK

37100100012



1. Place the front wheel on a turning radius gauge and measure the steering angle.

Standard value:

Items	2WD	4WD
Inside wheel	33°55' – 36°55'	29°40' – 32°40'
Outside wheel	30°57'	29°30'




- If the steering angle is outside the standard value after checking the toe-in (refer to GROUP 33A – On-vehicle Service), adjust the steering angle with the stopper bolt.



STEERING GEAR BACKLASH CHECK 37100120018

- Jack up the vehicle front and hold the steering wheel in the straight ahead position.
- Apart the pitman arm and the relay rod. (Refer to P.37A-49.)
- Measure the steering gear backlash at the pitman arm top end with a dial indicator.


Limit: 0.5 mm



- If the measured value exceeds the limit, screw in the steering gear box adjusting bolt until steering wheel free play is within the standard value.

Caution

- Be sure to make the adjustment with the steering wheel in the straight ahead position.
- If the adjusting bolt is overtightened, more steering effort will be required, and return of the wheel will be adversely affected.



TIE-ROD END BALL JOINT VARIATION CHECK (SHAFT DIRECTION)

37100130011


1. Hold the ball joint with the special tool.
2. Set the special tool scale at its highest and measure variation with ball stud compressed. The variation should locate between the highest and centre scales.

Limit: 1.5 mm

3. When the variation exceeds the centre scale, replace the tie-rod end.

Caution

Even if the variation is within the limit, check ball joint starting torque.




TIE-ROD END BALL JOINT STARTING TORQUE CHECK

37100140014

1. Use the special tool to disconnect the ball joint.

Caution

1. Only loosen tie-rod end mounting nut; but do not remove it from the ball joint.
2. Support the special tool with a cord, etc. to prevent it from coming off.




2. Move the ball joint stud several times and install the nut on stud. Measure ball joint starting torque with special tools.

Standard value: 3.0 Nm

3. When the starting torque exceeds the standard value, replace the tie-rod end.
4. When the starting torque is under the standard value, check ball joint for end play or ratcheting. If none of these, the ball joint is still serviceable.
5. Tighten the nut to the specified torque and install a new split pin.

Tightening torque: 40 Nm




STEERING GEAR OIL LEVEL CHECK (MANUAL STEERING)

37100110015

Remove the breather plug and check the oil level in the steering gear box by using a special gauge or a thin screwdriver.

Standard value: 22 mm



STATIONARY STEERING EFFORT CHECK (POWER STEERING)

37200170115

1. With the vehicle stopped on a flat and paved surface, and turn the steering wheel to the straight ahead position.
2. Start the engine and check the engine idle speed.

Standard value:


Engine idle speed r/min	Remarks
750 ± 100	4G6
750 ± 100	4D56

3. Attach a spring balance to the outer circumference of the steering wheel and measure the steering force required to turn the steering wheel from the straight ahead position to the left and right (within a range of 1.5 turns). Also check to be sure that there is no significant fluctuation of the required steering force.

Standard value:

Steering effort: 39.2 N or less

Fluctuation allowance: 5 N or less



CHECKING STEERING WHEEL RETURN TO CENTRE (POWER STEERING)

37200180118

Conduct a road test before this test.

1. Make both gradual and sudden turns and check the steering "feeling" to be sure that there is no difference in the steering force required and the wheel return between left and right turns.
2. At a speed of 35 km/h, turn the steering wheel 90° and release the steering wheel after 1 or 2 seconds. If the steering wheel then returns 70° or more, the return can be judged to be satisfactory.


NOTE

There will be a momentary feeling or "heaviness" when the wheel is turned quickly, but this is not abnormal. (this is because the oil pump discharge amount is especially apt to be insufficient during idling.)

**DRIVE BELT TENSION CHECK
(POWER STEERING)**

37200190074

Refer to GROUP 11A and B – On-vehicle Service.


**FLUID LEVEL CHECK (POWER STEERING)**

37200200098

1. Park the vehicle on a flat, level surface, start the engine, and then turn the steering wheel several times to raise the temperature of the fluid to approximately 50–60°C.
2. With the engine running, turn the wheel all the way to the left and right several times.
3. Check the fluid in the oil reservoir for foaming or milkiness. Check the difference of the fluid level when the engine is stopped, and while it is running. If the change of the fluid level is 5 mm or more, air bleeding should be done.

FLUID REPLACEMENT (POWER STEERING)

37200210091



1. Raise the front wheels on a jack, and then support them with rigid racks.
2. Disconnect the return hose connection.
3. Connect a vinyl hose to the return hose, and drain the oil into a container.
4. On vehicles with a petrol engine, disconnect the high-tension cable. On vehicles with a diesel engine, remove the fuel cut valve connector attached to the injection pump.

Caution**Be careful not to position the high-tension cable near the delivery pipe.**

5. While operating the starting motor intermittently, turn the steering wheel all the way to the left and right several times to drain all of the fluid.
6. Connect the return hoses securely, and then secure it with the clip.
7. Fill the oil reservoir with the specified fluid up to the lower position of the filter, and then bleed the air.

Specified fluid:**Automatic transmission fluid
DEXRON or DEXRON II**

BLEEDING (POWER STEERING)

37200220100

1. Jack up the front wheels and support them by using a rigid rack.
2. Manually turn the oil pump pulley a few times.
3. Turn the steering wheel all the way to the left and to the right five or six times.
4. On vehicles with a petrol engine, disconnect the high-tension cable. On vehicles with a diesel engine, remove the fuel cut valve connector attached to the injection pump.

Caution

Be careful not to place the high-tension cable near the delivery pipe.

5. While operating the starting motor intermittently, turn the steering wheel all the way to the left and right five or six times (for 15 to 20 seconds).

Caution


1. **During air bleeding, refill the fluid so that the level never falls below the lower position of the filter.**
2. **If air bleeding is done while engine is running, the air will be broken up and absorbed into the fluid; be sure to do the bleeding only while cranking.**


6. On vehicles with a petrol engine, connect the high-tension cable. On vehicles with a diesel engine, connect the fuel cut valve connector attached to the injection pump. Start the engine (idling).
7. Turn the steering wheel to the left and right until there are no air bubbles in the oil reservoir.
8. Confirm that the fluid is not milky, and that the level is up to the specified position on the level gauge.
9. Confirm that there is very little change in the fluid level when the steering wheel is turned left and right.

10. Check whether or not the change in the fluid level is within 5 mm when the engine is stopped and when it is running.
11. If the change of the fluid level is 5 mm or more, the air has not been completely bled from the system, and thus must be bled completely.

Caution

1. **If the fluid level rises suddenly after the engine is stopped, the air has not been completely bled.**
2. **If air bleeding is not complete, there will be abnormal noises from the pump and the flow-control valve, and this condition could cause a lessening of the life of the pump, etc.**





OIL PUMP PRESSURE TEST (POWER STEERING)

37200230127

1. Disconnect the pressure hose from the oil pump, and then connect the special tools.
2. Bleed the air, and then turn the steering wheel several times while the vehicle is not moving so that the temperature of the fluid rises to approximately 50–60°C.
3. Start the engine and idle it at 1,000±100 r/min.
4. Fully close the shut-off valve of the pressure gauge and measure the oil pump relief pressure to confirm that it is within the standard value range.

Standard value: 8.3 – 9.0 MPa

Caution

Pressure gauge shut off valve must not remain closed for more than 10 seconds.

5. If it is not within the standard value, replace the oil pump.
6. Check whether or not the hydraulic pressure is the standard value when no-load conditions are created by fully opening the shut-off valve of the pressure gauge.

Standard value: 0.8 – 1.0 Mpa


7. If it is not within the standard value, the probable cause is a malfunction of the oil line or steering gear box, so check these parts and repair as necessary.
8. Turn the steering wheel all the way to the left or right; then check whether or not the retention hydraulic pressure is the standard value.

Standard value: 8.3 – 9.0 MPa

9. When not within the standard value, overhaul the steering gear box.
Remeasure fluid pressure.
10. Remove the special tools, and then tighten the pressure hose to the specified torque.

Tightening torque: 18 Nm

11. Bleed the system.



POWER STEERING OIL PRESSURE SWITCH CHECK (POWER STEERING)

<Petrol-powered vehicle>

37200720105

1. Disconnect the pressure hose from the oil pump, and then connect the special tools.
2. Bleed the air, and then turn the steering wheel several times while the vehicle is not moving so that the temperature of the fluid rises to approximately 50–60°C.
3. The engine should be idling.
4. Disconnect the connection of the connector for the oil pressure switch, and place an ohmmeter in position.
5. Gradually close the shut-off valve of the pressure gauge and increase the hydraulic pressure, then check whether or not the hydraulic pressure that activates the switch is the standard value.

Standard value: 1.5 – 2.0 MPa

6. Gradually open the shut-off valve and reduce the hydraulic pressure; then check whether or not the hydraulic pressure that deactivates the switch is the standard value.

Standard value: 0.7 – 1.2 MPa

7. Remove the special tools, and then tighten the pressure hose to the specified torque.

Tightening torque: 18 Nm

8. Bleed the system

STEERING WHEEL AND SHAFT


37100170013

REMOVAL AND INSTALLATION


Caution: SRS
 Before removal of air bag module, refer to GROUP 52B – Service Precautions and Air Bag Module and Clock Spring.

Post-installation Operation
 • Checking Steering Wheel Position with Wheels Straight Ahead

<2WD>



Sealant:
 3M ATD Part No.8661 or equivalent



13V0064
 00004888



Removal steps

1. Horn pad <Vehicles without SRS>
2. Air bag module
 (Refer to GROUP 52B – Air Bag Module and Clock Spring.)
3. Steering wheel
4. Upper column cover
 • Instrument under cover (Refer to GROUP 52A – Instrument Panel.)

5. Lower column cover
- ▶◀ 6. Column switch
 <Vehicles without SRS>
- ▶◀ 7. Clock spring (Refer to GROUP 52B – Air Bag Module and Clock Spring.)
8. Brake pedal return spring
9. Steering column assembly



<4WD>




13V0065
00004889

Removal steps


1. Horn pad <Vehicles without SRS>
2. Air bag module
(Refer to GROUP 52B – Air Bag Module and Clock Spring.)
3. Steering wheel
4. Upper column cover
5. Lower column cover

- ▶◀ 6. Column switch
<Vehicles without SRS>
- ▶◀ 7. Clock spring and column switch
(Refer to GROUP 52B – Air Bag Module and Clock Spring.)
8. Brake pedal return spring
9. Steering column assembly



REMOVAL SERVICE POINT

◀▶ STEERING WHEEL REMOVAL



INSTALLATION SERVICE POINT


►A◄ CLOCK SPRING AND COLUMN SWITCH/COLUMN SWITCH INSTALLATION

Tighten the screws in an alphabetical order.


DISASSEMBLY AND REASSEMBLY

37100190019

<2WD>




<4WD>




00004890

Disassembly steps




- 1. Special bolt
- 2. Steering lock bracket
- 3. Steering lock cylinder
- 4. Snap ring
- 5. Stopper
- 6. Bearing spacer
- 7. Lower boot
- 8. Joint assembly
- 9. Upper boot
- 10. Steering shaft assembly
- 11. Bearing spacer
- 12. Stopper
- 13. Snap ring
- 14. Yoke
- 15. Rubber coupling
- 16. Steering shaft
- 17. Packing
- 18. Column sub assembly



DISASSEMBLY SERVICE POINT

◀▶ STEERING LOCK BRACKET/STEERING LOCK CYLINDER REMOVAL

If it is necessary to remove the steering lock cylinder, use a hacksaw to cut the special bolts at the steering lock bracket side.



REASSEMBLY SERVICE POINT

▶◀ UPPER BOOT/LOWER BOOT INSTALLATION


Assemble the upper and lower boots and the dust cover.

NOTE

Align the arrows on the upper and lower boots to the slit on the yokes in order to assemble.

▶B◀ STEERING LOCK CYLINDER/STEERING LOCK BRACKET/SPECIAL BOLT INSTALLATION

- (1) When installing the steering lock cylinder and steering lock bracket to the column tube, temporarily install the steering lock in alignment with the column boss.



- (2) After checking that the lock works properly, tighten the special bolts until the head twists off.

Caution

The steering lock bracket and bolts must be replaced with new ones when the steering lock is installed.

MANUAL STEERING GEAR BOX

37100220046


REMOVAL AND INSTALLATION

Caution: SRS

For vehicles with SRS, before removal of steering gear box refer to GROUP 52B, center front wheels and remove ignition key. Failure to do so may damage SRS clock spring and render SRS system inoperative, risking serious driver injury.

Post-installation Operation

- Checking Steering Wheel Position with Wheels Straight Ahead
- Front Wheel Alignment Adjustment (Refer to GROUP 33A – On-vehicle Service.)



Removal steps

1. Steering gear box and steering shaft connecting bolt
2. Split pin
3. Pitman arm and relay rod connection
4. Self-locking nut
5. Steering gear box




REMOVAL SERVICE POINT

◀▶ PITMAN ARM AND RELAY ROD DISCONNECTION

Use the special tool to disconnect the ball joint.

Caution

1. Using the special tool, loosen the tie rod end mounting nut. Only loosen the nut; do not remove it from the ball joint.
2. Support the special tool with a cord, etc. to prevent it from coming off.



INSPECTION


37100230049

PITMAN ARM DUST COVER CHECK


If there are any cracks in or damage to the dust cover, replace the pitman arm. If the dust cover is damaged accidentally during service work, replace the dust cover only. (Refer to P. 37A-25.)

DISASSEMBLY AND REASSEMBLY




37100240042



Sealant:
3M ATD Part No.8661 or equivalent



Sealant:
3M ATD Part No.8661 or equivalent





Sealant: 3M ATD Part No.8661 or equivalent

00005030


Disassembly steps

- ▶H◀ ● Steering gear backlash check
- ◀A▶ ▶G▶ 1. Jam nut
- 2. Pitman arm
- 3. Breather plug
- 4. Gasket
- 5. Seal bolt
- ▶F▶ ● Mainshaft total starting torque adjustment
- 6. Lock nut
- ◀B▶ 7. Side cover
- 8. Packing
- 9. Adjusting bolt
- ▶E▶ ● Cross-shaft axial play adjustment



- ◀C▶ 10. Adjusting spacer
- 11. Cross-shaft
- 12. Bolt
- ▶D▶ ● Mainshaft starting torque adjustment
- 13. End cover
- 14. Adjusting shim
- 15. Bearing
- ▶C▶ 16. Mainshaft assembly
- 17. Bearing
- ▶B▶ 18. Oil seal
- ▶A▶ 19. Oil seal
- 20. Gear box housing

**DISASSEMBLY SERVICE POINTS****◀A▶ PITMAN ARM REMOVAL****◀B▶ SIDE COVER REMOVAL**

1. Loosen the lock nut, and then turn the adjusting bolt anti-clockwise slightly.
2. Screw in the adjusting bolt without turning the side cover, and then remove the side cover.


**◀C▶ CROSS-SHAFT REMOVAL**

With the mainshaft and cross-shaft placed in the straight ahead position, tap the bottom of the cross-shaft with a plastic hammer to take out the cross-shaft together with the top cover.

**REASSEMBLY SERVICE POINTS****▶A▶ OIL SEAL INSTALLATION****▶B▶ OIL SEAL INSTALLATION**

►C◄ MAINSHAFT ASSEMBLY INSTALLATION


Apply gear oil to the tooth surfaces and sliding surfaces, and insert the mainshaft assembly and bearings into the gear housing.

**►D◄ MAINSHAFT STARTING TORQUE ADJUSTMENT**

1. Install the end cover and adjusting shim(s) to the gear housing and then tighten to the specified torque.

Standard value: 0.49 – 0.78 Nm

2. Measure the mainshaft starting torque by using the special tools.
3. If the measured value is not within the standard value, adjust by changing the adjusting shim(s).
4. Remove the shim(s) to increase starting torque, or add shim(s) to reduce.

**►E◄ CROSS-SHAFT AXIAL PLAY ADJUSTMENT**

1. Install the adjusting spacer to the adjusting bolt and measure the cross-shaft axial play.

Standard value: 0.05 mm or less

2. If the measured value is not within the standard value, adjust by changing the adjusting spacer.

►F◄ MAINSHAFT TOTAL STARTING TORQUE ADJUSTMENT

Lubricate the bearings and gear teeth of each shaft.

1. Move the ball nut of the mainshaft to the centre position (straight ahead position).

Caution

Do not damage the cross-shaft oil seal.


2. Turn the adjusting bolt 2 or 3 times until the tooth surfaces are in contact.


3. Measure the mainshaft total starting torque.
 - (1) Secure the flange part of the gear box housing in a vise.
 - (2) Measure the mainshaft total starting torque by using the special tools.

Standard value: 0.98 – 1.47 Nm


NOTE

The mainshaft should rotate smoothly across the entire range.






- (3) If the measured value is not within the standard value, adjust by turning the adjusting bolt in or out.
- (4) If it is not possible, check the following points.
 - 1) Cross-shaft eccentricity due to improperly installed top cover
 - 2) Cross-shaft needle roller bearing damaged
 - 3) End cover improperly installed



►G◄ PITMAN ARM INSTALLATION

Install the pitman arm to the gear box with the mating marks aligned.



►H◄ STEERING GEAR BACKLASH CHECK


1. Move the pitman arm to the right and left 3 to 5 times to be sure that the tooth surfaces sufficiently correct with each other.
2. Measure the steering gear backlash at the end of the pitman arm with a dial indicator.

Limit: 0.5 mm

Caution

Measure the steering gear backlash when the mainshaft, cross-shaft and pitman arm are in the straight-ahead position.

3. If the reading exceeds the limit, replace the mainshaft.




INSPECTION

37100250045

PITMAN ARM BALL JOINT STARTING TORQUE CHECK

After shaking the ball joint stud several times, install the nut to the stud and use the special tool to measure the starting torque of the ball joint.

Standard value: 0.5 – 1.5 Nm

**DUST COVER REPLACEMENT**

Only when the dust cover is damaged accidentally during service work, replace the dust cover only as follows:

1. Fill inside the dust cover with multipurpose grease.
2. Apply specified sealant to the mounting surface of the dust cover at the pitman arm.

Specified sealant: 3M ATD Part No.8661 or equivalent

3. Using the special tool, install the dust cover to the pitman arm.

POWER STEERING GEAR BOX

37200390122

REMOVAL AND INSTALLATION

Caution: SRS


For vehicles with SRS, before removal of steering gear box refer to GROUP 52B, center front wheels and remove ignition key. Failure to do so may damage SRS clock spring and render SRS system inoperative, risking serious driver injury.

Pre-removal Operation


- Power Steering Fluid Draining (Refer to P.37A-11.)

Post-installation Operation


- Power Steering Fluid Supplying (Refer to P.37A-11.)
- Power Steering Fluid Line Bleeding (Refer to P.37A-12.)
- Checking Steering Wheel Position with Wheels Straight Ahead
- Front Wheel Alignment Adjustment (Refer to GROUP 33A – On-vehicle Service.)



<2WD>



<4WD>




Removal steps

1. Connecting bolt for steering gear box and steering shaft
2. Split pin
3. Connection for pitman arm and relay rod

4. Pressure tube
5. Return tube
6. O-ring
7. Self-locking nut
8. Power steering gear box



**REMOVAL SERVICE POINT****◀A▶ PITMAN ARM AND RELAY ROD DISCONNECTION**

Use the special tool to disconnect the ball joint.

Caution

1. Using the special tool, loosen the tie rod end mounting nut. Only loosen the nut; do not remove it from the ball joint.
2. Support the special tool with a cord, etc. to prevent it from coming off.

INSPECTION


37200400108

PITMAN ARM DUST COVER CHECK

If there are any cracks in or damage to the dust cover, replace the pitman arm. (Refer to P. 37A-36 .)

DISASSEMBLY

37200420029




A13V0108

Disassembly steps


- ◀A▶ 1. Jam nut
- ◀B▶ 2. Pitman arm
- 3. Bolts
- 4. Adjusting bolt locking nut
- 5. Side cover
- 6. O-ring
- 7. Y-packing
- 8. Adjusting bolt
- 9. Adjusting plate
- ◀C▶ 10. Cross-shaft
- ◀D▶ 11. Mainshaft and valve assembly
- 12. Rack piston
- 13. Spacer
- 14. Seal ring
- 15. Circulator holder
- 16. Circulator

- ◀E▶ 17. Ball
- ◀F▶ 18. Lock nut
- ◀F▶ 19. Mainshaft
- ◀F▶ 20. Bearing race
- ◀F▶ 21. Cage
- ◀F▶ 22. Ball
- ◀G▶ 23. Seal ring
- ◀G▶ 24. Bearing race
- ◀G▶ 25. O-ring
- ◀G▶ 26. Bearing
- ◀G▶ 27. Oil seal
- 28. Valve housing
- 29. Oil seal
- 30. Y-packing
- 31. Gear box housing




DISASSEMBLY SERVICE POINTS

◀A▶ PITMAN ARM REMOVAL




◀B▶ SIDE COVER REMOVAL

1. Loosen the lock nut and then turn the adjusting bolt anti-clockwise slightly.
2. Screw in the adjusting bolt without turning the side cover, and then remove the side cover.



◀C▶ CROSS-SHAFT REMOVAL

With the mainshaft and cross-shaft placed in the straight ahead position, tap the bottom of the cross-shaft with a plastic hammer to take out the cross-shaft together with the side cover.




◀D▶ RACK PISTON REMOVAL


Remove the rack piston from the mainshaft by turning it counterclockwise.

Caution

Be careful not to lose the 26 balls inside the rack piston.




◀E▶ LOCK NUT REMOVAL



◀F▶ MAINSHAFT, BEARING RACE AND BALL REMOVAL

Remove the mainshaft while pressing the bearing race so that the balls do not come out.




◀G▶ BEARING AND OIL SEAL REMOVAL

Using a socket, remove the oil seal and bearing from the valve housing simultaneously.

REASSEMBLY








37200430022




Reassembly steps

- 1. Gear box housing
- 2. Y-packing
- ▶A◀ 3. Oil seal
- ▶B◀ 4. Oil seal
- ▶C◀ 5. Bearing
- 6. Bearing case
- 7. O-ring
- ▶D◀ 8. Seal ring
- ▶E◀ 9. Cage
- ▶E◀ 10. Ball
- ▶E◀ 11. Bearing race
- ▶F◀ 12. Mainshaft
- ▶F◀ 13. Lock nut
- ▶G◀ • Mainshaft axial play adjustment
- 14. Seal ring
- 15. Spacer
- ▶H◀ 16. Rack piston
- ▶H◀ 17. Ball
- 18. Circulator
- 19. Circulator holder
- 20. Valve housing
- 21. Mainshaft and valve assembly
- 22. Y-packing
- 23. O-ring
- ▶I◀ • Cross-shaft axial play adjustment
- 24. Adjusting plate
- ▶J◀ 25. Adjusting bolt
- ▶J◀ 26. Cross-shaft
- ▶J◀ 27. Side cover
- ▶J◀ 28. Side cover and cross-shaft assembly
- 29. Bolt
- ▶K◀ • Mainshaft total starting torque adjustment
- ▶L◀ 30. Adjusting bolt lock nut
- ▶L◀ 31. Pitman arm
- ▶L◀ 32. Jam nut

LUBRICATION AND SEALING POINTS



00004894




REASSEMBLY SERVICE POINTS

▶A◀ OIL SEAL INSTALLATION

Apply a coating of the specified fluid to the outside of the oil seal. Using the special tools, press the oil seal into the valve housing.

Specified fluid:
Automatic transmission fluid DEXRON or DEXRON II




►B◄ OIL SEAL INSTALLATION

Apply a coating of the specified fluid to the outside of the bearing. Using the special tools, press the oil seal into the valve housing.

Specified fluid:

**Automatic transmission fluid
DEXRON or DEXRON II**




►C◄ BEARING INSTALLATION

Apply a coating of the specified fluid to the outside of the bearing. Using the special tools, press the bearing into the valve housing.


Specified fluid:

**Automatic transmission fluid DEXRON or
DEXRON II**



►D◄ SEAL RING INSTALLATION

Press the seal ring firmly into the valve groove.




►E◄ CAGE, BALLS, BEARING RACE AND MAINSHAFT INSTALLATION

1. Apply specified fluid to the mainshaft.

Specified fluid:


**Automatic transmission fluid DEXRON or
DEXRON II**

2. Wrap vinyl tape around the serrated part so that the oil seal won't be damaged when the mainshaft is installed to the valve housing.
3. Mount the mainshaft to the valve housing.
4. Align the cage's hole and the channel in the mainshaft and insert two or three balls.
5. Insert the remainder of the balls into the cage's hole while pressing the ball with the bearing race.
6. When installing the mainshaft, connect it to the valve housing while pressing the bearing race so that the balls do not come out.



►F◄ LOCK NUT INSTALLATION


Using special tools, tighten carefully until the lock nut contacts the bearing race.




►G◄ MAINSHAFT AXIAL PLAY ADJUSTMENT

1. Adjust the play by tightening the lock nut gradually so that the mainshaft axial play will meet the range of the standard value.

Standard value: 0.03 mm or less



2. Use a punch to crimp the circumference of the lock nut so as to secure the lock nut.
3. Check to be sure that the mainshaft rotates smoothly.



►H◄ RACK PISTON AND BALLS INSTALLATION

1. Install the rack piston until it comes in contact with the edge of the mainshaft.
2. Rotate the mainshaft to align the ball race way with the 19-ball insertion hole.


NOTE

The balls must be inserted so that there is no clearance between the balls.

3. Set the remaining seven balls in the circulator, and install the circulator to the rack piston.
4. Apply the specified fluid to the seal ring of the rack piston.

Specified fluid:

Automatic transmission fluid DEXRON or DEXRON II



►I◄ CROSS-SHAFT AXIAL PLAY ADJUSTMENT

1. Install the adjusting plate so that the beveled part is facing downward.
2. Using a thickness gauge, measure the clearance between the adjusting bolt and cross-shaft.

Standard value: 0.05 mm or less


3. If the clearance exceeds the standard value, replace with a suitable adjusting plate.

►J◄ CROSS-SHAFT INSTALLATION

Set the rack piston in the neutral position and install the cross-shaft.

Caution

Do not rotate the side cover during installation. Take care not to damage the cross-shaft oil seal.



►K◄ MAINSHAFT TOTAL STARTING TORQUE ADJUSTMENT

1. While turning the adjusting bolt, measure the mainshaft total starting torque by using the special tools.

Standard value:


<2WD> 0.98 – 1.47 Nm

<4WD> 0.69 – 1.28 Nm

Caution


Adjust by turning adjusting bolt so that the starting torque at the centre position of the rack piston is approximately 0.2 Nm higher than the values at the both ends of the rack piston.

2. Tighten the adjusting bolt lock nut to the specified torque.



►L◄ PITMAN ARM INSTALLATION

Install the pitman arm to the gear box with the mating marks aligned.

**INSPECTION**

37200440087


BACKLASH BETWEEN BALL GROOVE OF RACK PISTON AND BALLS

Set the rack piston to the position shown in the figure, and then measure the backlash by using a dial gauge.

Limit: 0.05 mm

PITMAN ARM BALL JOINT STARTING TORQUE

Refer to P.37A-24.

**DUST COVER REPLACEMENT**

Only when the dust cover is damaged accidentally during service work, replace the dust cover only as follows:

1. Fill inside the dust cover with multipurpose grease.
2. Apply specified sealant to the mounting surface of the dust cover at the pitman arm.

Specified sealant:

3M ATD Part No.8661 or equivalent

3. Using the special tool, install the dust cover to the pitman arm.

POWER STEERING OIL PUMP



REMOVAL AND INSTALLATION

Pre-removal Operation

- Power Steering Fluid Draining (Refer to 37A-11.)


Post-installation Operation

- Power Steering Fluid Supplying (Refer to 37A-11.)
- Drive Belt Tension Check (Refer to 37A-11.)
- Power Steering Fluid Line Bleeding (Refer to 37A-12.)
- Oil Pump Pressure Check (Refer to 37A-13.)



Removal steps

1. Drive belt
2. Suction hose
3. Pressure hose
4. O-ring
5. Pressure switch connector <4G6>
6. Oil pump
7. Oil pump bracket



INSTALLATION SERVICE POINTS

▶A◀ PRESSURE HOSE INSTALLATION





Connect the pressure hose so that the notch part contacts the suction connector.

INSPECTION

Check the drive belt for cracks.
Check the pulley assembly for uneven rotation.

DISASSEMBLY AND REASSEMBLY <4G6>

37200540121




00005029

Disassembly steps


- | | | |
|-----|-------------------------|-----------------------|
| | 1. Pump cover | 17. Plunger |
| | 2. O-ring | 18. Piston rod |
| ◀A▶ | 3. Vanes | 19. Snap ring |
| ▶H▶ | 4. Cam ring | 20. Terminal |
| ▶G▶ | 5. Snap ring | 21. Washer |
| ▶F▶ | 6. Rotor | 22. Insulator |
| ▶E▶ | 7. Pulley assembly | ▶B▶ |
| ▶D▶ | 8. Side plate | ▶B▶ |
| ▶C▶ | 9. O-ring | ▶A▶ |
| | 10. Connector | 23. O-ring |
| | 11. O-ring | 24. Plug |
| | 12. Flow control valve | 25. Suction connector |
| | 13. Flow control spring | 26. O-ring |
| | 14. Terminal assembly | 27. Oil seal |
| | 15. O-ring | 28. Oil pump body |
| | ▶B▶ | |
| | ▶C▶ | |
| | 16. Spring | |

Caution
Do not disassemble the flow control valve.




DISASSEMBLY SERVICE POINT

◀A▶ SNAP RING REMOVAL




REASSEMBLY SERVICE POINTS

▶A◀ OIL SEAL INSTALLATION




▶B◀ O-RINGS INSTALLATION

No.	I.D. x Width mm
1	11 × 1.9
2	13 × 1.9
3	17.8 × 2.4
4	13.5 × 1.5
5	3.8 × 1.9
6	16.8 × 2.4




▶C◀ SPRING INSTALLATION

Fit the spring to the oil pump body with the larger-diameter end at the terminal assembly side.




►D◄ SIDE PLATE INSTALLATION

Line up the dowel pin hole of the side plate with the dowel pin of the pump body when installing the side plate.





►E◄ ROTOR INSTALLATION

Install the rotor to the pulley assembly so that the rotor's punch mark is at the pump cover side.




►F◄ SNAP RING INSTALLATION

After installation of the snap ring, lift the rotor and check that the snap ring has entered the countersunk part.



►G◄ CAM RING INSTALLATION

Install the cam ring with the punch mark facing the side plate.

**▶H◀ VANES INSTALLATION**

Install the vanes on the rotor, paying close attention to the installation direction.




INSPECTION

37200550087

- Check the flow control valve for clogging.
- Check the pulley assembly for wear or damage.
- Check the groove of rotor and vane for “stepped” wear.
- Check the contact surface of cam ring and vanes for “stepped” wear.
- Check the vanes for damage.

DISASSEMBLY AND REASSEMBLY <4D56>

37200540138



13V0054 00004901


Disassembly steps


- ◀A▶ ▶G▶ 1. Drive pulley
- ▶C▶ 2. Snap ring
- ▶F▶ 3. Pump cover
- ▶E▶ 4. Lock pin
- ▶D▶ 5. Seal washer
- ▶C▶ 6. Vanes
- ▶B▶ 7. Cam ring
- ▶A▶ 8. Rotor
- 9. Side plate
- ▶C▶ 10. O-ring
- 11. Connector
- ▶C▶ 12. O-ring
- ▶B▶ 13. Flow control valve
- ▶A▶ 14. Flow control spring
- ▶C▶ 15. Suction connector
- ▶B▶ 16. O-ring
- ▶A▶ 17. Drive shaft assembly
- ▶C▶ 18. Oil seal
- ▶A▶ 19. Oil pump body

Caution
Do not disassemble the flow control valve.

DISASSEMBLY SERVICE POINT


◀A▶ DRIVE PULLEY REMOVAL






REASSEMBLY SERVICE POINTS

▶A◀ OIL SEAL INSTALLATION




▶B◀ DRIVE SHAFT ASSEMBLY INSTALLATION




▶C◀ O-RINGS INSTALLATION

No.	I.D. x Width mm
1	11 × 1.9
2	13 × 1.9
3	15.5 × 2.4
4	14.6 × 2.4
5	19.4 × 1.9




▶D◀ ROTOR INSTALLATION

Install the rotor to the pulley assembly so that the rotor's punch mark is at the pump cover side.




►E◄ CAM RING INSTALLATION

Install the cam ring with the punch mark facing the side plate.



►F◄ VANE INSTALLATION

Install the vanes on the rotor, paying close attention to the installation direction.



►G◄ DRIVE PULLEY INSTALLATION

INSPECTION

37200550087

- Check the flow control valve for clogging.
- Check the pulley assembly for wear or damage.
- Check the groove of rotor and vane for "stepped" wear.
- Check the contact surface of cam ring and vanes for "stepped" wear.
- Check the vanes for damage.

POWER STEERING HOSES

REMOVAL AND INSTALLATION


Pre-removal Installation

- Power Steering Fluid Draining (Refer to P.37A-11.)
- Radiator Grille Removal

Post-installation Operation

- Radiator Grille Installation
- Power Steering Fluid Supplying (Refer to P.37A-11.)
- Power Steering Fluid Line Bleeding (Refer to P.37A-12.)


<4G6>



Removal steps


- | | |
|---|---|
| <ul style="list-style-type: none"> ▶F◀ 1. Suction hose ▶E◀ 2. Return hose ▶D◀ 5. Return hose ▶C◀ 7. Return tube ▶C◀ 8. Pressure hose ▶C◀ 9. O-ring ▶C◀ 10. Return tube | <ul style="list-style-type: none"> ▶B◀ 11. Tube stay ▶A◀ 12. Return hose ▶A◀ 13. Return tube ▶A◀ 14. O-ring ▶A◀ 15. Pressure tube ▶A◀ 16. O-ring ▶A◀ 17. Pressure tube ▶A◀ 18. O-ring |
|---|---|

<4D56-L.H.>



13V0060

<4D56-R.H.>




13V0059

00004897

Removal steps

- ▶F◀ 1. Suction hose
- ▶F◀ 2. Return hose
- ▶E◀ 3. Oil reservoir
- ▶F◀ 4. Suction hose
- ▶E◀ 5. Return hose
- ▶E◀ 6. Suction tube
- ▶D◀ 7. Return tube
- ▶D◀ 8. Pressure hose
- ▶D◀ 9. O-ring


- ▶C◀ 10. Return tube
- ▶B◀ 11. Tube stay
- ▶B◀ 12. Return hose
- ▶A◀ 13. Return tube
- ▶A◀ 14. O-ring
- ▶A◀ 15. Pressure tube
- ▶A◀ 16. O-ring
- ▶A◀ 17. Pressure tube
- ▶A◀ 18. O-ring



INSTALLATION SERVICE POINTS


▶A◀ RETURN TUBE INSTALLATION

Align the marks on the return tube and steering gear box, and install the return tube.




▶B◀ TUBE STAY INSTALLATION

Fit the protrusion of the tube stay to the positioning hole.




▶C◀ RETURN TUBE INSTALLATION

Connect the return tube so that the marking is positioned as shown in the illustration.




▶D◀ PRESSURE HOSE INSTALLATION

1. Connect the pressure hose so that its notch part contacts the suction connector.




2. Align the marks on the pressure hose and pressure tube, and install the pressure hose.




►E◄ RETURN HOSE INSTALLATION

Install the return hose so that the marking faces towards front of the vehicle.



►F◄ SUCTION HOSE INSTALLATION

Connect the suction hose so that the marking is positioned as shown in the illustration.




STEERING LINKAGE

REMOVAL AND INSTALLATION


Post-installation Operation

- Checking Steering Wheel Position with Wheels Straight Ahead
- Front Wheel Alignment (Refer to GROUP 33A – On-vehicle Service.)

<2WD>



<4WD>




Removal steps

1. Split pin
2. Tie rod assembly
3. Relay rod



4. Self-locking nut
5. Idler arm assembly





REMOVAL SERVICE POINT

◀▶ TIE ROD ASSEMBLY/RELAY ROD/IDLER ARM ASSEMBLY REMOVAL

Use the special tool to disconnect the ball joint.

Caution

1. Only loosen the tie rod end mounting nut; but do not remove it from the ball joint.
2. Support the special tool with a cord, etc. to prevent it from coming off.

INSTALLATION SERVICE POINT

▶◀ TIE ROD ASSEMBLY INSTALLATION

Tighten the tie rod assembly to the specified torque.

INSPECTION

37100310019

Check the rubber parts for cracks and break.


DUST COVER CHECK

If there are any cracks in or damage to the dust cover, replace the tie rod end assembly or idler arm. If the dust cover is damaged accidentally during service work, replace the dust cover only. (Refer to P. 37A-52.)

DISASSEMBLY AND REASSEMBLY



Idler Arm

<2WD>



<4WD>

Tie rod assembly



Sealant:
3M ATD Part No.8661 or equivalent

00004899


Idler arm disassembly steps

1. Self-locking nut
2. Washer
3. Idler arm assembly
4. Bushing
5. Oil seal
6. Idler arm
7. Idler arm support



Tie rod disassembly steps

8. Tie rod end assembly
9. Pipe





REASSEMBLY SERVICE POINTS

▶A◀ TIE-ROD END INSTALLATION

1. Apply multipurpose grease to the threaded section of the tie-rod end.
2. Screw in the right and left tie-rod ends to the pipe by the same amount, and then and provisionally tighten the tie-rod end fixing nut.

▶B◀ OIL SEAL INSTALLATION





►C◄ BUSHING INSTALLATION

1. Apply a neutral detergent to the inside of the idler arm and to the outside of the bushings.
2. Insert the bushings as far as the stepped section. If they won't go in easily, use a vice to push them in.


Caution

Wipe off the detergent after the bushings are inserted.

3. Apply multipurpose grease to the inside of the bushings and in between the bushings.

Caution

Do not apply grease to the outside of the bushings.




INSPECTION

37100350011

IDLER ARM SLIDING RESISTANCE

Standard value:

- <2WD> 8.8 – 30 N [1.0 – 3.4 Nm]
<4WD> 2.4 – 16 N [0.3 – 2.0 Nm]



DUST COVER REPLACEMENT

Only when the dust cover is damaged accidentally during service work, replace the dust cover only as follows:

1. Fill inside the dust cover with multipurpose grease.
2. Apply the specified sealant to the dust cover lip.

Specified sealant: 3M ATD Part No.8661 or equivalent

3. Using the special tool, install the dust cover to the tie rod end ball joint.



SERVICE BULLETIN

QUALITY INFORMATION ANALYSIS
OVERSEAS SERVICE DEPT. MITSUBISHI MOTORS CORPORATION

SERVICE BULLETIN		No.: MSB-98E37-002	
		Date: 1999-08-15	<Model> <M/Y>
Subject:	NEW SERVICE PROCEDURE FOR POWER STEERING GEARBOX	(EC,EXP) L200 (K00)	97-10
Group:	STEERING	Draft No.: 98SY100912	(EC,EXP) PAJERO (V10,V20,V30,V40) 95-10
INFORMATION	OVERSEAS SERVICE DEPT	 T.NITTA - VICE GENERAL MANAGER QUALITY INFORMATION ANALYSIS	

1. Description:

The mainshaft valve assembly in the power steering gearbox is now available only as an assembly (supply of individual components and parts discontinued). Accordingly, the service procedure for the power steering gearbox is also changed as shown in the attached sheets.

2. Applicable Manuals:

Manual	Pub. No.	Language	Page(s)
'97 L200 Workshop Manual CHASSIS	PWTE96E1	(English)	37A-3~6, 28-34
	PWTS96E1	(Spanish)	
	PWTF96E1	(French)	
	PWTG96E1	(German)	
'95 PAJERO Workshop Manual CHASSIS	PWJE9086-F	(English)	37-3, 4, 6, 25-32
	PWJF9088-F	(French)	
	PWJG9089-F	(German)	
	PWJD9090-F	(Dutch)	
	PWJW9091-F	(Swedish)	
'95 MONTERO Workshop Manual CHASSIS	PWJS9087-F	(Spanish)	

3. Interchangeability:

Not interchangeable

4. Effective Date:

From when the part stock has been exhausted

SERIVICE SPECIFICATIONS

37100030021

Items		Standard value	Limit
Steering Wheel free play mm	With engine running	-	50
	With engine stopped	10 or less	-
Steering angle	2WD	Inner wheel	33°55'-36°55'
		Outer wheel	30°57'
	4WD	Inner wheel	29°40'-32°40'
		Outer wheel	29°30'
Steering gear backlash mm		-	0.5
Variation of tie rod end ball joint shaft direction mm		-	1.5
Tie rod end ball joint starting torque Nm		3.0	-
Steering gear oil level mm		22	-
Engine idle speed r/min	4G6	750 ± 100	-
	4D56	750 ± 100	-
Stationary steering effort N		39.2 or less	-
Oil pump pressure MPa	Oil pump relief pressure	8.3 - 9.0	-
	Pressure under no-load conditions	0.8 - 1.0	-
	Steering gear retention hydraulic pressure	8.3 - 9.0	-
Oil pressure switch operating pressure Mpa	OFF → ON	1.5 – 2.0	-
	ON → OFF	0.7 – 1.2	-
Mainshaft starting torque Nm		0.49 – 0.78	-
Cross-shaft axial play mm		0.05 or less	-
Mainshaft total starting torque Nm	<2WD>	0.98 – 1.47	-
	<4WD>	0.69 – 1.28	-
Pitman arm ball joint starting torque Nm		0.5 – 1.5	-
Mainshaft axial play mm		0.03 or less	-
Backlash between ball groove of rack piston and balls mm		-	0.05
Idler arm sliding resistance N	2WD	8.8 – 30	-
	4WD	2.4 – 16	-

<Deleted>

LUBRICANTS

37100040017

Items	Specified lubricants	Quantity I
Manual steering gear oil	Hypoid gear oil API GL-4 higher SAE80	0.21
Power steering fluid	Automatic transmission fluid DEXRON or DEXRON II	0.8
Seal ring, rack piston, mainshaft, bearing, O-ring, oil seal, vane	Automatic transmission fluid DEXRON or DEXRON II	As required

SEALANTS





<Deleted>

37100050010

Items	Specified sealants	Remarks
Cover assembly installation hole Adjusting bolt, seal bolt, packing, adjusting shim, dust cover lip for ball joint	3M ATD Part No. 8663 or equivalent	Semi-drying sealant

SPECIAL TOOLS







37100060013

Tools	Number	Name	Use
 B990948	MB990948	Linkage joint gauge	Ball joint variation check for shaft direction
 00003982	MB991113 or MB990635	Steering linkage puller	Disconnection of ball joint
	MB990685 MB991151	Torque wrench	<ul style="list-style-type: none"> • Measurement of the ball joint starting torque • Measurement of the shaft preload • Measurement of the mainshaft starting torque
	MB990326	Preload socket	Measurement of the ball joint starting torque
 B990993	MB990993 or MB991217	Power steering oil pressure gauge adapter (pump side)	Measurement of oil pressure


Tools	Number	Name	Use
B990994	MB990994	Power steering oil pressure gauge adapter (hose side)	Measurement of oil pressure
B990662	MB990662	Oil pressure gauge assembly	
B990803	MB990803	Steering wheel puller	Disconnection of the steering wheel
B991006	MB991006 or MB990228	Preload socket	Measurement of the mainshaft total starting torque
B990776	MB990776	Front axle base	Installation of dust cover for tie rod end ball joint
MB990628	MB990628	Snap ring pliers	To remove and install the snap ring of the pulley assembly
B990925	MB990925	Bearing and oil seal installer set	Installation of the oil seal and bearing (Refer to GROUP 26 – Special tools)
B990915	MB990915	Pitman arm puller	Removal of the pitman arm
B991367	MB991367	Special spanner	Removal and installation of the lock nut

↑ <Deleted>

<Deleted>

Tools	Number	Name	Use
 <p>B991394</p>	MB991394	Pin set	Removal and installation of the lock nut
 <p>B991203</p>	MB991203	Oil seal & bearing installer	To press in the valve housing oil seal and bearing
 <p>B990956</p>	MB990956	Needle bearing installer	To press in the drive shaft assembly
	MB991172	Adapter	
	MB990767	End yolk holder	Securing the drive pulley
	MB998719 or MD998754	Crankshaft pulley holder pin	

DISASSEMBLY



Disassembly steps


- ◀A▶ 1. Jam nut
- 2. Pitman arm
- 3. Bolts
- 4. Adjusting bolt locking nut
- ◀B▶ 5. Side cover
- 6. O-ring
- 7. Y-packing
- 8. Adjusting bolt
- 9. Adjusting plate
- ◀C▶ 10. Cross-shaft
- 11. Mainshaft and valve assembly
- ◀D▶ ~~12. Rack piston~~
- ~~13. Spacer~~
- ◀E▶ ~~14. Seal ring~~
- ◀F▶ ~~15. Circulator helder~~
- ◀G▶ ~~16. Circulator~~

- ◀E▶ ~~17. Ball~~
- ◀F▶ ~~18. Lock nut~~
- ◀F▶ ~~19. Mainshaft~~
- ◀F▶ ~~20. Bearing race~~
- ~~21. Cage~~
- ~~22. Ball~~
- ~~23. Seal ring~~
- ~~24. Bearing race~~
- ~~25. O-ring~~
- ◀G▶ ~~26. Bearing~~
- ◀G▶ ~~27. Oil seal~~
- ~~28. Valve housing~~
- 29. Oil seal
- 30. Y-packing
- 31. Gear box housing

<Added>
14-1. O-ring


<Deleted>

<Deleted>




DISASSEMBLY SERVICE POINTS

◀A▶PITMAN ARM REMOVAL



◀B▶SIDE COVER REMOVAL


1. Loosen the lock nut and then turn the adjusting bolt anti-clockwise slightly.
2. Screw in the adjusting bolt without turning the side cover, and then remove the side cover.



◀C▶CROSS-SHAFT REMOVAL

With the mainshaft and cross-shaft placed in the straight ahead position, tap the bottom of the cross-shaft with a plastic hammer to take out the cross-shaft together with the side cover.

<Deleted>




◀D▶RACK PISTON REMOVAL


Remove the rack piston from the mainshaft by turning it counterclockwise.

Caution


Be careful not to lose the 26 balls inside the rack piston.



◀E▶LOCK NUT REMOVAL

**◀F▶ MAINSHAFT, BEARING RACE AND BALL REMOVAL**










Remove the mainshaft while pressing the bearing race so that the balls do not come out.

**◀G▶ BEARING AND OIL SEAL REMOVAL**


using a socket, remove the oil seal and bearing from the valve housing simultaneously.

<Deleted>

LUBRICATION AND SEALING POINTS



00004894




REASSEMBLY SERVICE POINTS

◀▶ OIL SEAL INSTALLATION

Apply a coating of the specified fluid to the outside of the oil seal. Using the special tools, press the oil seal into the valve housing.

Specified fluid:

Automatic transmission fluid DEXRON or DEXRON II




►B◄ OIL SEAL INSTALLATION

Apply a coating of the specified fluid to the outside of the bearing. Using the special tools, press the oil seal into the valve housing.

Specified fluid:

**Automatic transmission fluid
DEXRON or DEXRON II**




►C◄ BEARING INSTALLATION

Apply a coating of the specified fluid to the outside of the bearing. Using the special tools, press the bearing into the valve housing.


Specified fluid:

**Automatic transmission fluid
DEXRON or DEXRON II**



►D◄ SEAL RING INSTALLATION

Press the seal ring firmly into the valve groove.



►E◄ CAGE, BALLS, BEARING RACE AND MAINSHAFT INSTALLATION

1. Apply specified fluid to the mainshaft.

Specified fluid:

**Automatic transmission fluid
DEXRON or DEXRON II**

2. Wrap vinyl tape around the serrated part so that the oil seal won't be damaged when the mainshaft is installed to the valve housing.


3. Mount the mainshaft to the valve housing.

4. Align the cage's hole and the channel in the mainshaft and insert two or three balls.

5. Insert the remainder of the balls into the cage's hole while pressing the ball with the bearing race.


6. When installing the mainshaft, connect it to the valve housing while pressing the bearing race so that the balls do not come out.

<Deleted>



▶◀ LOCK NUT INSTALLATION


Using special tools, tighten carefully until the lock nut contacts the bearing race.




▶◀ MAINSHAFT AXIAL PLAY ADJUSTMENT

1. Adjust the play by tightening the lock nut gradually so that the mainshaft axial play will meet the range of the standard value.

Standard value: 0.03 mm or less



2. Use a punch to crimp the circumference of the lock nut so as to secure the lock nut.
3. Check to be sure that the mainshaft rotates smoothly.



▶◀ RACK PISTON AND BALLS INSTALLATION

1. Install the rack piston until it comes in contact with the edge of the mainshaft.
2. Rotate the mainshaft to align the ball race way with the 19-ball insertion hole.

NOTE

The balls must be inserted so that there is no clearance between the balls.

3. Set the remaining seven balls in the circulator, and install the circulator to the rack piston.
4. Apply the specified fluid to the seal ring of the rack piston.

Specified fluid:

**Automatic transmission fluid
DEXRON or DEXRON II**

<Deleted>

Items	Specifications
Pressure switch activation oil pressure	Mpa (kg/cm ² , psi)
OFF → ON	1.5 – 2.0 (15 – 20, 21-284)
ON → OFF	0.7 – 1.2 (7.2 – 12, 100-171)
Mainshaft starting torque (Manual steering)	Nm (kgcm, in.lbs.)
<Deleted>	0.35 – 0.55 (3.5 – 5.5, 3 – 5)
Mainshaft axial play (Power steering)	mm (in.) 0.03 – (0.0012) or less
Cross-shaft axial play	mm (in.)
Manual steering	0.05 (0.0020)
Power steering	0.05 (0.0020)
Mainshaft total starting torque	Nm (kgcm, in.lbs.)
Manual steering	0.65 – 0.85 (6.5 – 8.5, 5.7 – 7.3)
Power steering	0.45 – 1.25 (4.5 – 12, 5, 4 – 11)
Ball joint starting torque	Nm (kgcm, in.lbs.)
Tie rod end	1 – 3 (10 – 30, 8.9 – 26)
Idler arm	0.5 – 2.0 (5 – 520, 4 – 17)
Idler arm turning torque	Nm (kgcm, in.lbs.)
Spring balance reading	N (kg,lbs)
Limit	2.3 – 15.4 (0.23 – 1.54, 0.5 – 33.9)
Steering wheel free play	mm (in.)
Manual steering	50 (1.97)
Power steering	50 (1.97)
Steering gear backlash	mm (in.) 0.5 (0.020)
Ball joint axia play	mm (in.) 1.5 (0.059)
Backlash between ball groove of rack piston	mm (in.)
And balls	0.05 (0.0020)
Gap between vane and rotor groove	mm (in.) 0.06 (0.0024)
Clearance between oil pump drive shaft	mm (in.)
And pump body	0.1 (0.004)

LUBRICANTS





E37CD--


Items	Specified lubricant	Quantity
Manual steering gear oil	Hypoid gear oil API GL-4 or higher SAE 80	210 cm ³ (12.81 cu.in.)
Power steering fluid L.H. drive vehicles <2800D> <Except 2800D> R.H. drive vehicles <2800D> <Except 2800D>	Automatic transmission fluid DEXRON or DEXRON II	11.1 dm ³ (1.17 U.S.qts., 0.98 Imp.qts.) 1.06 dm ³ (1.12 U.S.qts., 0.93 Imp.qts.) 1.02 dm ³ (1.08 U.S.qts., 0.90 Imp.qts.) 0.97 dm ³ (1.02 U.S. qts., 0.85 Imp.qts.)
Power steering gear box Bearing, O-ring and oil seal Bearing <Deleted>	Automatic transmission fluid DEXRON or DEXRON II	As required
Oil pump Flow control valve and O-ring Friction surface of rotor, vane, cam ring and pump cover	Automatic transmission fluid DEXRON or DEXRON II	As required

SEALANTS AND ADHESIVES

E37CE--

Items	Specified sealant and adhesive	Remarks
Steering column cover assembly installation hole Dash panel cover installed surface Manual steering gear box top cover packing Manual steering gear box cross-shaft adjusting and lock nut Manual steering gear box top cover bolt Manual steering gear box adjusting shim Tie-rod end dust cover installed surface	3M ATD Part No. 861 or equivalent	Semi-drying sealant
Inside of steering column lower pipe bearing Connection of steering column upper and steering column lower (Nut side)	3M Stud Locking Part No. 4170 or equivalent	Semi-drying sealant
Steering column upper bearing	3M ATD Part No. 8001 or equivalent	Semi-drying sealant

Tool	Number	Name	Use
	MB990925	Bearing and oil seal installer set	Installation of the oil seal and the ball bearing (Refer to GROUP 26.) MB990938, MB99028, MB990926, MB991203 ← <Deleted>
	MB991151 MB990685	Torque wrench	Measurement of the mainshaft starting torque
	MB991006 or MB990228	Preload socket	Measurement of the mainshaft total starting torque <Deleted>
	MB991367	Special spanner	Removal and installation of the lock nut
	MB991394	Pin set	
	MB990326	Preload socket	Measurement of the ball joint starting torque
	MB990778	Ball joint remover	Disconnection of idler arm from relay rod



SERVICE ADJUSTMENT PROCEDURES

STEERING WHEEL FREE PLAY CHECK

E37FAAF


MANUAL STEERING

Standard value: 26.6 mm (1.05 in.) or less

Limit: 50 mm (1.97 in.)

If the measured value exceeds the repair limit, check the steering gear backlash and ball joint axial play.

DISASSEMBLY



13W703

Disassembly steps

- ↔ 1. Jam nut
- ↔ 2. Pitman arm
- ↔ 3. Dust cover
- ↔ 4. Side cover and cross-shaft assembly
- 5. Adjusting bolt lock nut
- 6. Cross-shaft
- 7. Adjusting bolt
- 8. Adjusting plate
- 9. O-ring
- ↔ 10. Y-packing
- 11. Side cover
- ↔ 12. Main shaft and valve assembly

~~↔ 13. Rack piston~~

~~14. Seal ring~~

~~15. O-ring~~

~~16. Circulation holder~~

<Deleted>

- | | |
|--------------|-------------------|
| ↔ | 17. Circulator |
| ↔ | 18. Ball |
| ↔ | 19. Lock nut |
| ↔ | 20. Main shaft |
| ↔ | 21. Bearing race |
| ↔ | 22. Cage |
| ↔ | 23. Ball |
| ↔ | 24. Seal ring |
| ↔ | 25. Bearing race |
| ↔ | 26. O-ring |
| ↔ | 27. Bearing |
| ↔ | 28. Oil seal |
| ↔ | 29. Valve housing |

<Deleted>


30. Oil seal

31. Y-packing

32. Gear box housing


SERVICE POINTS OF DISASSEMBLY

2. REMOVAL OF PITMAN ARM



4. REMOVAL OF SIDE COVER AND CROSS-SHAFT ASSEMBLY

With the mainshaft and cross-shaft placed in the straight ahead position, tap the bottom of the cross-shaft with a plastic hammer to take out the cross-shaft together with the side cover.



10. REMOVAL OF Y-PACKING


Do not remove the Y-packing at the rear of the needle bearing unless there is fluid leakage from the threads of the adjusting bolt. If there is leakage, replace the Y-packing with a new one.

<Deleted>


13. REMOVAL OF RACK PISTON

Remove the rack piston from the mainshaft by turning it counterclockwise.

Caution
Be careful not to lose the 26 balls inside the rack piston.




19. REMOVAL OF LOCK NUT




20. REMOVAL OF MAIN SHAFT/21. BEARING RACE/22. CAGE/23. BALL

When removing the main shaft, remove it while pressing the bearing race so that the balls do not come out.




<Deleted>



27. REMOVAL OF BEARING/28. OIL SEAL

Using a socket, remove the oil seal and the bearing from the valve housing simultaneously.

E37NHAD




INSPECTION

BACKLASH BETWEEN BALL GROOVE OF RACK PISTON AND BALLS

Set the rack piston to the position shown in the figure, and then measure the backlash by using a dial gauge.


Limit: 0.05 mm (0.0020 in.)



PITMAN ARM BALL JOINT STARTING TORQUE

Standard value: 1-3 Nm (10-30 kgcm, 9-26 in.lbs.)

REASSEMBLY



Reassembly steps

- 1. Gear box housing
- ↔ 2. Y-packing
- ↔ 3. Oil seal
- ↔ 4. Oil seal
- ↔ 5. Bearing
- ↔ 6. Bearing case
- ↔ 7. O-ring
- ↔ 8. Seal ring
- ↔ 9. Cage
- ↔ 10. Ball
- ↔ 11. Bearing race
- ↔ 12. Mainshaft
- ↔ 13. Lock nut
- Adjustment of main shaft axial play
- ↔ 14. O-ring
- ↔ 15. Seal ring
- ↔ 16. Rack piston
- ↔ 17. Ball



<Deleted>

- ↔ ~~18. Circulator~~
- ↔ ~~19. Circulator holder~~
- ↔ ~~20. Valve housing~~
- 21. Mainshaft and valve assembly
- 22. Y-packing
- 23. O-ring
- ↔ 24. Adjusting plate
- ↔ 25. Adjusting bolt
- ↔ 26. Cross-shaft
- ↔ 27. Adjusting bolt lock nut
- 28. Side cover
- ↔ 29. Side cover and cross-shaft assembly
- Adjustment of main shaft total starting torque
- ↔ 30. Dust cover
- ↔ 31. Pitman arm
- 32. Jam nut

A13V0108

<Deleted>

LUBRICATION AND SEALING POINTS




SERVICE POINTS OF REASSEMBLY

E37NJAE

2. INSTALLATION OF Y-PACKING/3. OIL SEAL

- (1) Install the Y-packing facing the direction shown in the illustration.
- (2) Use the special tool to press-fit the oil seal to the gearbox housing so that it faces in the direction shown in the illustration.

<Deleted>




4. INSTALLATION OF OIL SEAL

Apply a coating of the specified fluid to the outside of the oil seal. Using the special tools, press the oil seal into the valve housing.

Specified fluid: Automatic transmission fluid DEXRON or DEXRON II


<Deleted>



5. INSTALLATION OF BEARING


Apply a coating of the specified fluid to the outside of the bearing. Using the special tools, press the oil seal into the valve housing.

Specified fluid: Automatic transmission fluid DEXRON or DEXRON II



8. INSTALLATION OF SEAL RING

When installing seal ring, press firmly into valve groove.



9. INSTALLATION OF CAGE/10. BALL/11. BEARING RACE/12. MAIN SHAFT

(1) Apply specified fluid to valve body.


Specified fluid: Automatic transmission fluid DEXRON or DEXRON II

(2) Wrap vinyl tape around the serrated part so that the oil seal won't be damaged when the valve body is installed to the valve housing.


(3) Mount the valve body to the valve housing

(4) Align the cage's hole and the channel in the main shaft, and insert two or three balls.


(5) Insert the remainder of the balls into the cage's hole while pressing the ball with the bearing race.



(6) When installing the main shaft, connect it to the valve housing while pressing the bearing race so that the balls do not come out.




<Deleted>



13. INSTALLATION OF LOCK NUT


Using the special tool, tighten carefully until the lock nut contacts the bearing race.




• **ADJUSTMENT OF MAIN SHAFT AXIAL PLAY**

(1) Adjust the play by tightening the lock nut gradually so that the mainshaft axial play will meet the range of standard value.

Standard value: 0.03 mm (0.0012 in.) or less



- (2) Use a punch to crimp the circumference of the lock nut so as to secure the lock nut.
- (3) Check to be sure that the mainshaft rotates smoothly.




16. INSTALLATION OF RACK PISTON

- (1) Install the rack piston until it comes in contact with the edge of the main shaft.
- (2) Rotate the main shaft to align the ball raceway with the 19-ball insertion hole.

NOTE


The balls must be inserted so that there is no clearance between the balls.

- (3) Set the remaining seven balls in the circulator, and install the circulator to the rack piston.



<Deleted>

20. INSTALLATION OF VALVE HOUSING
 (1) Apply specified automatic transmission fluid to the seal ring of the rack piston.
Specified fluid: Automatic transmission fluid DEXRON or DEXRON II
 (2) Insert the valve housing.
 (3) Rotate the main shaft until the rack piston moves to the neutral position (center).




24. INSTALLATION OF ADJUSTING PLATE/25. ADJUSTING BOLT

- (1) Install the adjusting plate so that the beveled part is facing downward.
- (2) Using a thickness gauge, measure the clearance between the adjusting bolt and cross-shaft.
Standard value: 0 - 0.05 mm (0 – 0.002 in.)
- (3) If the clearance is exceeded the standard value, replace with a suitable adjusting plate.

26. INSTALLATION OF CROSS-SHAFT/27. ADJUSTING BOLT LOCK NUT

Install the cross-shaft to the side cover, and then temporarily tighten the adjusting bolt lock nut.



29. INSTALLATION OF SIDE COVER AND CROSS-SHAFT ASSEMBLY

Install the side cover assembly (with the corss-shaft) to the gear box.

NOTE
 Apply specified automatic transmission fluid to the teeth and shaft areas of the rack piston, and apply multipurpose grease to the oil seal lip.

Specified fluid: Automatic transmission fluid DEXRON or DEXRON II

Caution
 Do not rotate the side cover during installation. Take care not to damage the cross-shaft oil seal.



SERVICE BULLETIN

QUALITY INFORMATION ANALYSIS
OVERSEAS SERVICE DEPT. MITSUBISHI MOTORS CORPORATION

SERVICE BULLETIN		No.: MSB-00E37-501	
		Date: 2000-12-30	<Model> <M/Y>
Subject: ADDITION OF STEERING ANGLE ADJUSTMENT PROCEDURE		(EC)PAJERO/ MONTERO (V10, 20, 30, 40)	00-10
Group: STEERING	Draft No.: 00SY040517		(EC)PAJERO SPORT/MONTERO SPORT (K80W, K90W) (EC)L200(K60, K70) 99-10
INFORMATION/ CORRECTION	INTERNATIONAL CAR ADMINISTRATION OFFICE	<i>Tamaki Nitta</i> T.NITTA - PROJECT LEADER AFTER SALES SERVICE & CS PROMOTION	

1. Description:


This Service Bulletin informs you that a cautionary description has been added on Steering Angle Check.

2. Applicable Manuals:

Manual	Pub. No.	Language	Page(s)
PAJERO Workshop Manual Chassis	PWJE9086	(English)	37-8
MONTERO Workshop Manual Chassis	PWJS9087	(Spanish)	
PAJERO Workshop Manual Chassis	PWJF9088	(French)	
	PWJG9089	(German)	
	PWJD9090	(Dutch)	
	PWJW9091	(Swedish)	
'99 PAJERO SPORT Workshop Manual Chassis	PWJE9812	(English)	37A-7
'99 MONTERO SPORT Workshop Manual Chassis	PWJS9813	(Spanish)	
'99 PAJERO SPORT Workshop Manual Chassis	PWJF9814	(French)	
	PWJG9815	(German)	
'97 L200 Workshop Manual Chassis	PWTE96E1	(English)	37A-7
	PWTS96E1	(Spanish)	
	PWTF96E1	(French)	
	PWTG96E1	(German)	
'93 L200 Workshop Manual Chassis'97	PWTE9319	(English)	37-14

3. Details:


Pajero Workshop Manual (PWJE 9086)	(Page 2)
'99 PAJERO SPORT Workshop Manual Chassis	(Page 3)
'93 L200 Workshop Manual Chassis	(Page 4 to 5)
'97 L200 Workshop Manual Chassis	(Page 6 to 7)

**STEERING ANGLE CHECK**


E37FDAH

1. Place the front wheel on a turning radius gauge and measure the steering angle

Standard value:
Inner wheel 32° 40'⁰/₃
Outer wheel 29° 45'




2. If the steering angle is outside the standard value, after checking the toe-in, (Refer to GROUP 33-Service Adjustment Procedures), adjust the steering angle with the stopper bolt.

**STEERING GEAR OIL LEVEL CHECK (MANUAL STEERING)**

E37FEAAa

Remove the breather plug and check the oil level in the steering gear box by using a special gauge or a thin screwdriver.


Standard value: 25 mm (0.98 in.)

**STATIONARY STEERING EFFORT CHECK (POWER STEERING)**


E37FFAG

1. Place the vehicle on a level surface and place the steering wheel in the straight-ahead position.
2. Set the engine speed to 1,000 r/min.
Caution
After checking the engine r/min., there must be a return to the standard idling r/min.
3. Measure the tangential force with a spring balance by turning the steering wheel clockwise and counter clock wise one and a half turns.
Standard value: 37N (3.7kg, 8.21 lbs) or less
4. If the stationary steering effort exceeds the standard value, check for belt slackness, damage, insufficient oil, air mixed into oil, collapsed or twisted hoses, etc., and repair if found.

<Added>

**Caution**

When the steering wheel is turned to lock, check that the clearance between the knuckle and the stopper is 1 mm or more.



ON-VEHICLE SERVICE


37100090043

STEERING WHEEL FREE PLAY CHECK

1. With engine running (hydraulic operation), set front wheels straight ahead.
 2. Measure the play on steering wheel circumference before wheels start to move when slightly moving steering wheel in both directions.
- Limit: 50 mm**
3. When play exceeds the limit, check for play on steering shaft connection and steering linkage. Correct or replace.
 4. If the free play still exceeds the limit value, set steering wheel straight ahead with engine stopped. Load 5 N towards steering wheel circumference and check play.

Standard value (steering wheel play with engine stopped): 10 mm or less

If the play exceeds the standard value, check the steering gear backlash and ball joint axial play.




STEERING ANGLE CHECK

37100100029

1. Place the front wheel on a turning radius gauge and measure the steering angle.


Standard value:

Items	Specifications
Inside wheel	29°40' - 32°40'
Outside wheel	29°30'




2. If the steering angle is outside the standard value after checking the toe-in (refer to GROUP 33A – On-Vehicle Service), adjust the steering angle with the stopper bolt.

<Added>



Caution

When the steering wheel is turned to lock, check that the clearance between the knuckle and the stopper is 1 mm or more.




5. 4WD VEHICLES

If the measured value exceeds the limit, screw in the steering gear box adjusting bolt until steering wheel free play is within the range of standard value.

Caution

1. Be sure to make the adjustment with the steering wheel in the straight-ahead position.
2. If the adjusting bolt is overtightened, more steering effort will be required, and return of the wheel will be adversely affected.




MEASURING BALL JOINT AXIAL PLAY

E37FCAA

1. Hold the ball joint by using the special tool.
2. Set the scale of special tool to the upper limit (A), compress the ball stud, and measure the axial play. The measured displacement should be between the upper limit (A) and the centre graduation (B).

Limit: 1.5 mm (0.06 in.)

3. If the measured displacement exceeds the centre graduation (B), replace the ball joint.



CHECKING STEERING ANGLE

E37FDAA

1. Place the front wheel on a turning radius gauge and measure the steering angle.

Standard value	2WD vehicles	4WD vehicles
Inner wheel	37° 0° -3°	30°
Outer wheel	30° 20'	27° 0° -3°

2. Adjust the steering angle of each wheel by turning the stop bolt of the knuckle arm.


NOTE

On 4WD vehicles, after adjusting the steering angle, mount the cap onto the jam bolt so that the edge of the slit side of the cap and the head of the stop volt are flush and face in the same direction, and then pack the head of the stop volt with the specified grease.

Specified grease: Multipurpose grease SAE J310, NLGI No. 2

Caution

Be sure that the toe-in is properly adjusted before adjusting the steering angle.




CHECKING STEERING GEAR OIL LEVEL (MANUAL STEERING)

E37FEAA

Remove the breather plug and check the oil level in the steering gear box by using a special gauge or a thin screwdriver.

Standard value:


2WD vehicles	35 mm (1.4 in.)
4WD vehicles	30 mm (1.2 in.)



PWTE8614-B

REVISED


Followed by next page



<2WD>

Caution


After adjusting toe-in and wheel steering angle, if stop bolt does not touch the lower arm when turning steering wheel fully, decrease wheel steering angle to touch on stop bolt in advance.



<4WD>

Caution

When the steering wheel is turned to lock, check that the clearance between the knuckle and the stopper is 1 mm or more.



ON-VEHICLE SERVICE

37100090036

STEERING WHEEL FREE PLAY CHECK

<Manual steering>

1. Set the front wheels straight ahead.
2. Measure the play on the steering wheel circumference before wheels move when slightly moving the steering wheel in both directions.

Limit: 50 mm

3. When the play exceeds the limit, check the play in the steering shaft connection and steering linkage. Correct or replace.
4. When (3) check provides good results, check the following to adjust:
 - Remove the steering gear box, check and adjust the mainshaft total starting torque.

<Power steering>


1. With engine running (Hydraulic operation), set front wheels straight ahead.
2. Measure the play on steering wheel circumference before wheels start to move when slightly moving steering wheel in both directions.

Limit: 50 mm

3. When play exceeds the limit, check for play on steering shaft connection and steering linkage. Correct or replace.
4. If the free play still exceeds the limit value, set steering wheel straight ahead with engine stopped. Load 5 N towards steering wheel circumference and check play.

Standard value (steering wheel play with engine stopped): 10 mm or less

If the play exceeds the standard value, check the steering gear backlash and ball joint axial play.



STEERING ANGLE CHECK

37100100012


1. Place the front wheel on a turning radius gauge and measure the steering angle.

Standard value:

Items	2WD	4WD
Inside wheel	33°55' - 36°55'	29°40' - 32°40'
Outside wheel	30°57'	29°30'

<Added>


Followed by next page



<2WD>

Caution

After adjusting toe-in and wheel steering angle, if stop bolt does not touch the lower arm when turning steering wheel fully, decrease wheel steering angle to touch on stop bolt in advance.



<4WD>

Caution

When the steering wheel is turned to lock, check that the clearance between the knuckle and the stopper is 1 mm or more.