
MULTIPOINT FUEL INJECTION (MPI) <4G9>

MULTIPOINT FUEL INJECTION (MPI) <4G9>

CONTENTS

| | | | |
|--|-----------|---|------------|
| GENERAL | 2 | Fuel Pump Operation Check | 100 |
| Outline of Changes | 2 | Component Location | 101 |
| GENERAL INFORMATION | 2 | Control Relay and Fuel Pump Relay Continuity Check | 102 |
| SERVICE SPECIFICATIONS | 5 | Intake Air Temperature Sensor Check | 102 |
| SEALANT | 5 | Engine Coolant Temperature Sensor Check | 102 |
| SPECIAL TOOLS | 6 | Throttle Position Sensor Check | 103 |
| TROUBLESHOOTING | 8 | Oxygen Sensor Check | 103 |
| ON-VEHICLE SERVICE | 96 | Injector Check | 106 |
| Throttle Body (Throttle Valve Area) Cleaning | 96 | Idle Speed Control (ISC) Servo (Stepper Motor) Check | 107 |
| Throttle Position Sensor Adjustment | 96 | Purge Control Solenoid Valve Check | 108 |
| Basic Idle Speed Adjustment | 97 | EGR Control Solenoid Valve Check | 108 |
| Fuel Pressure Test | 98 | INJECTOR | 109 |
| Fuel Pump Connector Disconnection (How to Reduce the Fuel Pressure) | 100 | THROTTLE BODY | 111 |

GENERAL

OUTLINE OF CHANGES

The following contents have been established to correspond to the addition of vehicles with 4G9-MPI engine.

GENERAL INFORMATION

The Multipoint Fuel Injection System consists of sensors which detect the engine conditions, the engine-ECU which controls the system based on signals from these sensors, and actuators which operate under the control of the engine-ECU. The engine-ECU carries out

activities such as fuel injection control, idle speed control and ignition timing control. In addition, the engine-ECU is equipped with several diagnosis modes which simplify troubleshooting when a problem develops.

FUEL INJECTION CONTROL

The injector drive times and injector timing are controlled so that the optimum air/fuel mixture is supplied to the engine to correspond to the continually-changing engine operation conditions.

A single injector is mounted at the intake port of each cylinder. Fuel is sent under pressure from the fuel tank by the fuel pump, with the pressure being regulated by the fuel pressure regulator. The fuel thus regulated is distributed to each of the injectors.

Fuel injection is normally carried out once for each cylinder for every two rotations of the

crankshaft. The firing order is 1-3-4-2. This is called sequential fuel injection. The engine-ECU provides a richer air/fuel mixture by carrying out “open-loop” control when the engine is cold or operating under high load conditions in order to maintain engine performance. In addition, when the engine is warm or operating under normal conditions, the engine-ECU controls the air/fuel mixture by using the oxygen sensor signal to carry out “closed-loop” control in order to obtain the theoretical air/fuel mixture ratio that provides the maximum cleaning performance from the three way catalyst.

IDLE AIR CONTROL

The idle speed is kept at the optimum speed by controlling the amount of air that bypasses the throttle valve in accordance with changes in idling conditions and engine load during idling. The engine-ECU drives the idle speed control (ISC) motor to keep the engine running at the pre-set idle target speed in accordance with

the engine coolant temperature and air conditioner load. In addition, when the air conditioner switch is turned off and on while the engine is idling, the ISC motor operates to adjust the throttle valve bypass air amount in accordance with the engine load conditions in order to avoid fluctuations in the engine speed.

IGNITION TIMING CONTROL

The power transistor located in the ignition primary circuit turns ON and OFF to control the primary current flow to the ignition coil. This controls the ignition timing in order to provide the optimum ignition timing with respect to the

engine operating conditions. The ignition timing is determined by the engine-ECU from the engine speed, intake air volume, engine coolant temperature and atmospheric pressure.

SELF-DIAGNOSIS FUNCTION

- When an abnormality is detected in one of the sensors or actuators related to emission control, the engine warning lamp (check engine lamp) illuminates as a warning to the driver.
- When an abnormality is detected in one of the sensors or actuators, a diagnosis code corresponding to the abnormality is output.
- The RAM data inside the engine-ECU that is related to the sensors and actuators can be read by means of the MUT-II. In addition, the actuators can be force-driven under certain circumstances.



OTHER CONTROL FUNCTIONS

1. Fuel Pump Control
Turns the fuel pump relay ON so that current is supplied to the fuel pump while the engine is cranking or running.
2. A/C Relay Control
Turns the compressor clutch of the A/C ON and OFF.
3. Fan Motor Control
The revolutions of the radiator fan and condenser fan are controlled in response to the engine coolant temperature and vehicle speed.
4. Purge Control Solenoid Valve Control
Refer to GROUP 17.
5. EGR Control Solenoid Valve Control
Refer to GROUP 17.

GENERAL SPECIFICATIONS

| Items | | Specifications |
|-------------------------|--------------------------------------|---|
| Throttle body | Throttle bore mm | 50 |
| | Throttle position sensor | Variable resistor type |
| | Idle speed control servo | Stepper motor type (Stepper motor type by-pass air control system) |
| Engine-ECU | Identification model No. | E2T74481 |
| Sensors | Air flow sensor | Karman vortex type |
| | Barometric pressure sensor | Semiconductor type |
| | Intake air temperature sensor | Thermistor type |
| | Engine coolant temperature sensor | Thermistor type |
| | Oxygen sensor | Zirconia type |
| | Vehicle speed sensor | Magnetic resistive element type |
| | Inhibitor switch | Contact switch type |
| | Camshaft position sensor | Magnetic resistive element type |
| | Crank angle sensor | Hall element type |
| | Detonation sensor | Piezoelectric type |
| | Power steering fluid pressure switch | Contact switch type |
| Actuators | Control relay type | Contact switch type |
| | Fuel pump relay | Contact switch type |
| | Injector type and number | Electromagnetic type, 4 |
| | Injector identification mark | CDH 210 |
| | EGR control solenoid valve | Duty cycle type solenoid valve |
| | Purge control solenoid valve | Duty cycle type solenoid valve |
| Fuel pressure regulator | Regulator pressure kPa | 329 |

CONTROL SYSTEM DIAGRAM












SERVICE SPECIFICATIONS








| Items | | Specifications |
|---|---------------------------|--------------------------|
| Basic idle speed r/min | | 700 ± 50 |
| Throttle position sensor adjusting voltage mV | | 535 – 735 |
| Throttle position sensor resistance kΩ | | 3.5 – 6.5 |
| Idle speed control servo coil resistance Ω | | 27 – 33 (at 20°C) |
| Intake air temperature sensor resistance kΩ | –20°C | 13 – 17 |
| | 0°C | 5.3 – 6.7 |
| | 20°C | 2.3 – 3.0 |
| | 40°C | 1.0 – 1.5 |
| | 60°C | 0.56 – 0.76 |
| | 80°C | 0.30 – 0.42 |
| Engine coolant temperature sensor resistance kΩ | –20°C | 14 – 17 |
| | 0°C | 5.1 – 6.5 |
| | 20°C | 2.1 – 2.7 |
| | 40°C | 0.9 – 1.3 |
| | 60°C | 0.48 – 0.68 |
| | 80°C | 0.26 – 0.36 |
| Oxygen sensor output voltage (at racing) V | | 0.6 – 1.0 |
| Fuel pressure kPa | Vacuum hose disconnection | 324 – 343 at curb idle |
| | Vacuum hose connection | Approx. 265 at curb idle |
| Injector coil resistance Ω | | 13 – 16 (at 20°C) |


SEALANT

| Item | Specified sealant | Remark |
|--|--|----------------|
| Engine coolant temperature sensor threaded portion | 3M Nut Locking Part No. 4171 or equivalent | Drying sealant |

SPECIAL TOOLS

| Tool | Number | Name | Use |
|--|---|---|---|
| <p>A</p>  <p>B</p>  <p>C</p>  <p>D</p>  <p>C991223</p> | <p>MB991223 A: MB991219 B: MB991220 C: MB991221 D: MB991222</p> | <p>Harness set A: Test harness B: LED harness C: LED harness adapter D: Probe</p> | <ul style="list-style-type: none"> ● Check at the ECU terminals A: Connector pin contact pressure inspection B: Power circuit inspection C: Power circuit inspection D: Commercial tester connection |
|  <p>B991502</p> | <p>MB991502</p> | <p>MUT-II sub assembly</p> | <ul style="list-style-type: none"> ● Reading diagnosis code ● MPI system inspection |
|  | <p>MB991348</p> | <p>Test harness set</p> | <ul style="list-style-type: none"> ● Measurement of voltage during troubleshooting ● Inspection using an analyzer |
|  <p>MB991709</p> | <p>MB991709</p> | <p>Test harness</p> | <ul style="list-style-type: none"> ● Measurement of voltage during troubleshooting ● Inspection using an analyzer ● Adjustment of throttle position sensor |
|  | <p>MB991519</p> | <p>Alternator harness connector</p> | <p>Measurement of voltage during troubleshooting</p> |
|  | <p>MD998478</p> | <p>Test harness (3-pin, triangle)</p> | <ul style="list-style-type: none"> ● Measurement of voltage during troubleshooting ● Inspection using an analyzer |

| Tool | Number | Name | Use |
|---|----------|-------------------------|---|
|  | MD998709 | Adaptor hose | Measurement of fuel pressure |
|  | MD998742 | Hose adaptor | |
|  <p data-bbox="367 726 428 743">B991637</p> | MB991637 | Fuel pressure gauge set | |
|  | MD998706 | Injector test set | Checking the spray condition of injectors |
|  <p data-bbox="318 1104 440 1121">MB991607</p> | MB991607 | Injector test harness | |
|  <p data-bbox="318 1304 386 1320">MD998741</p> | MD998741 | Injector test adaptor | |
|  | MB991608 | Clip | |



TROUBLESHOOTING

DIAGNOSIS TROUBLESHOOTING FLOW

Refer to GROUP 00 – How to Use Troubleshooting/Inspection Service Point.

NOTE

If the engine-ECU for vehicles for GCC is replaced, the immobilizer-ECU and ignition key should be replaced together with it.

DIAGNOSIS FUNCTION

ENGINE WARNING LAMP (CHECK ENGINE LAMP)

If an abnormality occurs in any of the following items related to the MPI system, the engine warning lamp will illuminate or flash. If the lamp remains illuminated or if the lamp illuminates while the engine is running, check the diagnosis code output. However, the warning lamp will illuminate as bulb check for five seconds whenever the ignition switch is turned to the ON position.

Engine warning lamp inspection items

| Code No. | Diagnosis item |
|----------|--|
| – | Engine-ECU |
| P0100 | Air flow sensor system |
| P0105 | Barometric pressure sensor system |
| P0110 | Intake air temperature sensor system |
| P0115 | Engine coolant temperature sensor system |
| P0120 | Throttle position sensor system |
| P0125 | Feedback system |
| P0130 | Oxygen sensor (front) system <sensor 1> |
| P0135 | Oxygen sensor heater (front) system <sensor 1> |
| P0136 | Oxygen sensor (rear) system <sensor 2> |
| P0141 | Oxygen sensor heater (rear) system <sensor 2> |
| P0170 | Abnormal fuel system |
| P0201 | No. 1 injector system |
| P0202 | No. 2 injector system |
| P0203 | No. 3 injector system |
| P0204 | No. 4 injector system |
| P0300★ | Ignition coil (power transistor) system |
| P0301 | No. 1 cylinder misfire detected |
| P0302 | No. 2 cylinder misfire detected |
| P0303 | No. 3 cylinder misfire detected |
| P0304 | No. 4 cylinder misfire detected |
| P0325 | Detonation sensor system |

| Code No. | Diagnosis item |
|----------|---|
| P0335 | Crank angle sensor system |
| P0340 | Camshaft position sensor system |
| P0403 | EGR valve system |
| P0420 | Catalyst malfunction |
| P0443 | Purge control solenoid valve system |
| P0500 | Vehicle speed sensor system |
| P0505 | Idle speed control system |
| P0551 | Power steering fluid pressure switch system |
| P1603 | Battery backup line system |

NOTE

1. If the engine warning lamp illuminates because of a malfunction of the engine-ECU, communication between MUT-II and the engine-ECU is impossible. In this case, the diagnosis code cannot be read.
2. After the engine-ECU has detected a malfunction, the engine warning lamp illuminates when the engine is next turned on and the same malfunction is re-detected. However, for items marked with a “★” in the diagnosis code number column, the engine warning lamp illuminates only on the first detection of the malfunction.
3. After the engine warning lamp illuminates, it will be switched off under the following conditions.
 - (1) When the engine-ECU monitored the power train malfunction three times* and met set condition requirements, it detected no malfunction.
*: In this case, “one time” indicates from engine start to stop.
 - (2) For misfiring malfunction, when driving conditions (engine speed, engine coolant temperature, etc.) are similar to those when the malfunction was first recorded.
4. Sensor 1 indicates the sensor mounted at a position closest to the engine, and sensor 2 indicates the sensor mounted at the position second closest to the engine.

METHOD OF READING AND ERASING DIAGNOSIS CODES

Refer to GROUP 00 – How to Use Troubleshooting/Inspection Service Points.

INSPECTION USING MUT-II DATA LIST AND ACTUATOR TESTING

1. Carry out inspection by means of the data list and the actuator test function. If there is an abnormality, check and repair the chassis harnesses and components.
2. After repairing, re-check using the MUT-II and check that the abnormal input and output have returned to normal as a result of the repairs.
3. Erase the diagnosis code memory.
4. Remove the MUT-II, and then start the engine again and carry out a road test to confirm that the problem has disappeared.

FAIL-SAFE FUNCTION REFERENCE TABLE

When the main sensor malfunctions are detected by the diagnosis function, the vehicle is controlled by means of the pre-set control logic to maintain safe conditions for driving.

| Malfunctioning item | Control contents during malfunction |
|-----------------------------------|--|
| Air flow sensor | <ol style="list-style-type: none"> 1. Uses the throttle position sensor signal and engine speed signal (crank angle sensor signal) to take reading of the basic injector drive time and basic ignition timing from the pre-set mapping. 2. Fixes the ISC servo in the appointed position so idle control is not performed. |
| Intake air temperature sensor | Controls as if the intake air temperature is 25°C. |
| Throttle position sensor (TPS) | No increase in fuel injection amount during acceleration due to the throttle position sensor signal. |
| Engine coolant temperature sensor | Controls as if the engine coolant temperature is 80°C. |
| Camshaft position sensor | Injects fuel to all cylinders simultaneously. (However, after the ignition switch is turned to ON, the No.1 cylinder top dead centre is not detected at all.) |
| Barometric pressure sensor | Controls as if the barometric pressure is 101 kPa. |
| Detonation sensor | Switches the ignition timing from ignition timing for super petrol to ignition timing for standard petrol. |
| Ignition coil, power transistor | Cuts off the fuel supply to cylinders with an abnormal ignition. |
| Oxygen sensor (front) | Air/fuel ratio feedback control (closed loop control) is not performed. |
| Oxygen sensor (rear) | Performs the feedback control (closed loop control) of the air/fuel ratio by using only the signal of the oxygen sensor (front) installed on the front of the catalytic converter. |
| Alternator FR terminal | Does not control the output of the alternator according to an electrical load. (works as a normal alternator) |
| Misfiring | If the detected misfiring causes damage to the catalyst, the misfiring cylinder will be shut down. |

INSPECTION CHART FOR DIAGNOSIS CODES


| Code No. | Diagnosis item | Reference page |
|----------|---|----------------|
| P0100 | Air flow sensor system | 13C-14 |
| P0105 | Barometric pressure sensor system | 13C-16 |
| P0110 | Intake air temperature sensor system | 13C-18 |
| P0115 | Engine coolant temperature sensor system | 13C-20 |
| P0120 | Throttle position sensor 1 system | 13C-22 |
| P0125 | Feedback system | 13C-24 |
| P0130 | Oxygen sensor (front) system | 13C-25 |
| P0135 | Oxygen sensor heater (front) system | 13C-26 |
| P0136 | Oxygen sensor (rear) system | 13C-27 |
| P0141 | Oxygen sensor heater (rear) system | 13C-28 |
| P0170 | Abnormal fuel system | 13C-29 |
| P0201 | No. 1 injector system | 13C-30 |
| P0202 | No. 2 injector system | 13C-30 |
| P0203 | No. 3 injector system | 13C-30 |
| P0204 | No. 4 injector system | 13C-30 |
| P0300★ | Ignition coil (power transistor) system | 13C-31 |
| P0301 | No. 1 cylinder misfire detected | 13C-32 |
| P0302 | No. 2 cylinder misfire detected | 13C-32 |
| P0303 | No. 3 cylinder misfire detected | 13C-32 |
| P0304 | No. 4 cylinder misfire detected | 13C-32 |
| P0325 | Detonation sensor system | 13C-33 |
| P0335 | Crank angle sensor system | 13C-33 |
| P0340 | Camshaft position sensor system | 13C-35 |
| P0403 | EGR valve system | 13C-36 |
| P0420 | Catalyst malfunction | 13C-37 |
| P0443 | Purge control solenoid valve system | 13C-38 |
| P0500 | Vehicle speed sensor system | 13C-39 |
| P0505 | Idle speed control system | 13C-40 |
| P0551 | Power steering fluid pressure switch system | 13C-43 |
| P1603 | Battery backup circuit malfunction | 13C-44 |
| P1610 | Immobilizer system | 13C-45 |


NOTE

1. Do not replace the engine-ECU until a through terminal check reveals there are no short/open circuit.
2. Check that the engine-ECU earth circuit is normal before checking for the cause of the problem.
3. After the engine-ECU has detected a malfunction, a diagnosis code is recorded the next time the engine is started and the same malfunction is re-detected. However, for items marked with a “★”, the diagnosis code is recorded on the first detection of the malfunction.
4. Sensor 1 indicates the sensor mounted at a position closest to the engine, and sensor 2 indicates the sensor mounted at the position second closest to the engine.


INSPECTION PROCEDURE CLASSIFIED BY DIAGNOSIS CODE


| Code No. P0100 Air flow sensor system | Probable cause |
|---|--|
| Range of Check ● Engine speed: 500 r/min or more Set Conditions ● The sensor output frequency is 3.3 Hz or less for 4 seconds. | ● Malfunction of air flow sensor ● Open or short circuit in air flow sensor circuit or loose connector contact ● Malfunction of engine-ECU |







| Code No. P0105 Barometric pressure sensor system | Probable cause |
|--|--|
| <p>Range of Check</p> <ul style="list-style-type: none"> Two seconds have passed since the ignition switch is turned ON or the engine starting process is completed. Battery voltage: 8 V or more <p>Set Conditions</p> <ul style="list-style-type: none"> The sensor output voltage is 4.5 V or more for 4 seconds (equivalent to 114 kPa of barometric pressure) <p>or</p> <ul style="list-style-type: none"> The sensor output voltage is 0.2 V or less (equivalent to 53 kPa of barometric pressure) | <ul style="list-style-type: none"> Malfunction of barometric pressure sensor Open or short circuit in barometric pressure sensor circuit or loose connector contact Malfunction of engine-ECU |







| Code No. P0110 Intake air temperature sensor system | Probable cause |
|---|--|
| <p>Range of Check</p> <ul style="list-style-type: none"> 2 seconds have passed since the ignition switch is turned ON or the engine starting process is completed. <p>Set Conditions</p> <ul style="list-style-type: none"> The sensor output voltage is 4.6 V or more for four seconds (equivalent to -45°C of intake air temperature) <p>or</p> <ul style="list-style-type: none"> The sensor output voltage is 0.2 V or more for four seconds (equivalent to 125°C of intake air temperature) | <ul style="list-style-type: none"> Malfunction of intake air temperature sensor Open or short circuit in intake air temperature sensor or loose connector contact Malfunction of engine-ECU |







| Code No. P0115 Engine coolant temperature sensor system | Probable cause |
|---|--|
| Range of Check <ul style="list-style-type: none"> ● Engine: Two seconds after the engine has been started Set Conditions <ul style="list-style-type: none"> ● The sensor output voltage is 4.6 V or more for four seconds (equivalent to -45°C or lower of engine coolant temperature) or <ul style="list-style-type: none"> ● The sensor output voltage is 0.1 V or less for four seconds (equivalent to 140°C or higher of engine coolant temperature) | <ul style="list-style-type: none"> ● Malfunction of engine coolant temperature sensor ● Open or short circuit in the engine coolant temperature sensor circuit or loose connector contact ● Malfunction of engine-ECU |
| Range of Check <ul style="list-style-type: none"> ● Engine: After starting Set Conditions <ul style="list-style-type: none"> ● The engine coolant temperature has reduced from over 40°C to less than 40°C, and that condition has lasted for five minutes or more. | |






| Code No. 0120 Throttle position sensor system | Probable cause |
|--|--|
| <p>Range of Check</p> <ul style="list-style-type: none"> Excluding 2 seconds after the ignition switch is turned ON or immediately after the engine start. <p>Set Conditions</p> <ul style="list-style-type: none"> The sensor output voltage is 0.2 V or less for four seconds. <p>or</p> <ul style="list-style-type: none"> Volume efficiency is 60 percent or lower. Engine speed is lower than 1000 r/min. The sensor output voltage is 2.0 V or more. AFS: Normal | <ul style="list-style-type: none"> Malfunction of throttle position sensor Open or short circuit in the throttle position sensor circuit or loose connector contact Malfunction of the engine-ECU |







| Code No. P0125 Feedback system | Probable cause |
|--|--|
| <p>Range of Check</p> <ul style="list-style-type: none"> • The engine coolant temperature is approx. 80°C or more. • During stoichiometric feedback control • The vehicle is not being decelerated. <p>Set Conditions</p> <ul style="list-style-type: none"> • Oxygen sensor (front) output voltage has been higher or lower than 0.5 V for at least thirty seconds. | <ul style="list-style-type: none"> • Malfunction of oxygen sensor (front) • Open or short circuit in the oxygen sensor (front) circuit or loose connector contact • Malfunction of engine-ECU |




| Code No. P0130 Oxygen sensor (front) system <sensor 1> | Probable cause |
|--|--|
| <p>Range of Check</p> <ul style="list-style-type: none"> • Three minutes have been passed since the engine has been started. • The engine coolant temperature is approx. 80°C or more. • Engine speed is 1,200 r/min or more • Driving on a level surface at constant speed. <p>Set Conditions</p> <ul style="list-style-type: none"> • The oxygen sensor (front) output voltage is 4.5 V or more when the sensor output voltage is 0.2 V or less and a voltage of 5 V is applied to the oxygen sensor (front) inside the engine-ECU. | <ul style="list-style-type: none"> • Malfunction of oxygen sensor (front) • Open or short circuit in the oxygen sensor (front) circuit or loose connector contact • Malfunction of engine-ECU |
| <p>Range of Check</p> <ul style="list-style-type: none"> • Engine speed is 3,000 r/min or less • During driving • During air/fuel ratio feedback control <p>Set Conditions</p> <ul style="list-style-type: none"> • The oxygen sensor (front) output frequency is five or less per 12 seconds on average. | |




| Code No. P0135 Oxygen sensor heater (front) system <sensor 1> | Probable cause |
|---|--|
| <p>Range of Check</p> <ul style="list-style-type: none"> • The engine coolant temperature is approx. 20°C or more. • The oxygen sensor heater (front) remains on. • The engine speed is 50 r/min or more. • Battery voltage is 11 – 16 V. <p>Set Conditions</p> <ul style="list-style-type: none"> • The current, which flows through the oxygen sensor heater (front), is 0.2 A or less or 3.5 A or more for six seconds. | <ul style="list-style-type: none"> • Malfunction of oxygen sensor heater (front) • Open or short circuit in the oxygen sensor heater (front) circuit or loose connector contact • Malfunction of engine-ECU |




| Code No. P0136 Oxygen sensor (rear) system <sensor 2> | Probable cause |
|---|--|
| <p>Range of Check</p> <ul style="list-style-type: none"> • Three minutes have been passed since the engine has been started. • The engine coolant temperature is approx. 80°C or more. • Intake air temperature is 20 – 50°C • Engine speed is 1,200 r/min or more • Driving on a level surface at constant speed. <p>Set Conditions</p> <ul style="list-style-type: none"> • The oxygen sensor (rear) output voltage is 4.5 V or more when the sensor output voltage is 0.2 V or less and a voltage of 5 V is applied to the oxygen sensor (rear) inside the engine-ECU. | <ul style="list-style-type: none"> • Malfunction of oxygen sensor (rear) • Open or short circuit in the oxygen sensor (rear) circuit or loose connector contact • Malfunction of engine-ECU |
| <p>Range of Check</p> <ul style="list-style-type: none"> • Two seconds have passed after the engine-ECU detected an open circuit. • When the oxygen sensor (front) is in good condition. <p>Set Conditions</p> <ul style="list-style-type: none"> • When the air/fuel ratio is rich, the oxygen sensor (front) output voltage is 0.5 V or more, the oxygen sensor (rear) output voltage is less than 0.1 V, and the oxygen sensor (rear) output voltage fluctuates within 0.078 V. | |




| Code No. P0141 Oxygen sensor heater (rear) system <sensor 2> | Probable cause |
|---|--|
| <p>Range of Check</p> <ul style="list-style-type: none"> • The engine coolant temperature is approx. 20°C or more. • The oxygen sensor heater (rear) remains on. • The engine speed is 50 r/min or more. • Battery voltage is 11 – 16 V. <p>Set Conditions</p> <ul style="list-style-type: none"> • The current, which flows through the oxygen sensor heater (rear), is 0.2 A or less or 3.5 A or more for six seconds. | <ul style="list-style-type: none"> • Malfunction of oxygen sensor heater (rear) • Open or short circuit in the oxygen sensor heater (rear) circuit or loose connector contact • Malfunction of engine-ECU |



| Code No. P0170 Abnormal fuel system | Probable cause |
|--|--|
| <p>Range of Check</p> <ul style="list-style-type: none"> Engine: Being learning the air-fuel ratio <p>Set Conditions</p> <ul style="list-style-type: none"> Ten seconds or more have been passed while the fuel injection amount compensation value is too low. <p>or</p> <ul style="list-style-type: none"> Ten seconds or more have been passed while the fuel injection amount compensation value is too high. | <ul style="list-style-type: none"> Incorrect fuel pressure Malfuction of fuel supply system Malfuction of oxygen sensor (front) Malfuction of intake air temperature sensor Malfuction of barometric pressure sensor Malfuction of air flow sensor Malfuction of engine-ECU |




| Code No. P0201 No. 1 injector system Code No. P0202 No. 2 injector system Code No. P0203 No. 3 injector system Code No. P0204 No. 4 injector system | Probable cause |
|---|--|
| Range of Check <ul style="list-style-type: none"> • Engine speed is approx. 50 – 1,000 r/min • The throttle position sensor output voltage is 1.15 V or less. • Actuator test by MUT-II is not carried out. Set Conditions <ul style="list-style-type: none"> • Surge voltage of injector coil is not detected for 4 seconds. | <ul style="list-style-type: none"> • Malfunction of the injector • Improper connector contact, open circuit or short-circuited harness wire of the injector circuit • Malfunction of engine-ECU |




| Code No. P0300 Ignition coil (power transistor) system | Probable cause |
|--|--|
| Range of Check ● Engine speed is approx. 50 – 4,000 r/min. ● Engine is not cranking. Set Conditions ● The ignition failure sensor does not send a signal about a certain cylinder for 4 seconds. | ● Malfunction of the ignition coil ● Malfunction of the ignition failure sensor ● Malfunction of spark plug ● Open or short circuit in the primary ignition circuit or loose connector contact ● Malfunction of engine-ECU |


MUT-II Actuator Test
 01 No. 1 injector
 02 No. 2 injector
 03 No. 3 injector
 04 No. 4 injector
OK: The idling condition should change.
 Reference
 When the cylinder (defective cylinder) where idling condition does not change is detected after suspending the injector, go to (1) and inspect the spark plug, the ignition coil, the connector, and the harness of the defective cylinder. (When more than one cylinder are detected, inspect all of them.)
 When all the cylinders are OK, go to (2).




(2)
 Use an analyzer to measure the signal waveform at the ignition failure sensor connector A-90.
 ● Use test harness (MB991536) to connect the connector, and measure at the pick-up harness.
 ● Engine: Idling
 ● The voltage between terminal 2 and earth
OK: A normal waveform should be displayed as described on P.13C-87 (INSPECTION PROCEDURE USING AN ANALYZER).
 Reference
 When a normal waveform is displayed, compare it with that of the ignition coil primary signal at the engine-ECU terminal to determine the cylinder (defective cylinder) with an abnormal waveform.
 →When one or more cylinders are abnormal, go to (1)
 →When all of the cylinders are abnormal, go to (3)
 →When a normal waveform is displayed, go to (4).




| Code No. P0301 No. 1 cylinder misfire detected Code No. P0302 No. 2 cylinder misfire detected Code No. P0303 No. 3 cylinder misfire detected Code No. P0304 No. 4 cylinder misfire detected | Probable cause |
|---|--|
| Range of Check <ul style="list-style-type: none"> • The engine speed is 500 – 4,500 r/min. • While the engine is running except deceleration and sudden acceleration. Set Conditions <ul style="list-style-type: none"> • The number of misfires exceeds a predetermined number per 200 engine revolutions (Misfire has occurred in only one cylinder). or <ul style="list-style-type: none"> • The number of misfires exceeds a predetermined number per 100 engine revolutions (Misfire has occurred in only one cylinder). | <ul style="list-style-type: none"> • Malfunction of the ignition system • Abnormal compression • Malfunction of injector • Malfunction of engine-ECU |




| Code No. P0325 Detonation sensor system | Probable cause |
|--|--|
| Range of Check ● Engine: Two seconds after the engine has been started Set Conditions ● Changes in sensor output voltage (detonation sensor peak voltage per 1/2 crankshaft rotation) in 200 consecutive cycles are 0.06 V or less. | ● Malfunction of the detonation sensor ● Open or short circuit in the detonation sensor circuit or loose connector contact ● Malfunction of engine-ECU |




| Code No. P0335 Crank angle sensor system | Probable cause |
|--|--|
| Range of Check ● Engine is cranking Set Conditions ● Sensor output voltage does not change for 4 seconds (no pulse signal input). | ● Malfunction of the crank angle sensor. ● Open or short circuit in the crank angle sensor circuit or loose connector contact. ● Malfunction of engine-ECU |







| Code No. P0340 Camshaft position sensor system | Probable cause |
|--|---|
| Range of Check ● After the engine was started Set Conditions ● The sensor output voltage does not change for 4 seconds (no pulse signal input). | ● Malfunction of the camshaft position sensor ● Open or short circuit in the camshaft position sensor circuit or loose connector contact. ● Malfunction of engine-ECU |




| Code No. P0403 EGR control solenoid valve system | Probable cause |
|---|--|
| <p>Range of Check</p> <ul style="list-style-type: none"> • Ignition switch: ON • Battery voltage is 10 V or more. <p>Set Conditions</p> <ul style="list-style-type: none"> • The solenoid coil surge voltage (battery voltage + 2 V) is not detected when the purge control solenoid valve is turned from on to off. | <ul style="list-style-type: none"> • Malfunction of the EGR control solenoid valve • Open or short circuit in the EGR control solenoid valve circuit or loose connector contact • Malfunction of engine-ECU |




| Code No. P0420 Catalyst malfunction | Probable cause |
|---|---|
| <p>Range of Check</p> <ul style="list-style-type: none"> • The engine speed is 3,000 r/min or less. • During driving • During air/fuel ratio feedback control <p>Set Conditions</p> <ul style="list-style-type: none"> • The ratio between the oxygen sensor (rear) and the oxygen sensor (front) output frequencies reaches 0.8 per 12 seconds on average. | <ul style="list-style-type: none"> • Malfunction of catalyst • Malfunction of the oxygen sensor (front) • Malfunction of the oxygen sensor (rear) • Malfunction of engine-ECU |



| Code No. P0443 Purge control solenoid valve system | Probable cause |
|---|--|
| <p>Range of Check</p> <ul style="list-style-type: none"> Ignition switch: ON Battery voltage is 10 V or more. <p>Set Conditions</p> <ul style="list-style-type: none"> The solenoid coil surge voltage (battery voltage + 2 V) is not detected when the purge control solenoid valve is turned from on to off. | <ul style="list-style-type: none"> Malfunction of the purge control solenoid valve Open or short circuit in the purge control solenoid valve circuit or loose connector contact Malfunction of engine-ECU |





| Code No. P0500 Vehicle speed sensor system | Probable cause |
|---|--|
| <p>Range of Check</p> <ul style="list-style-type: none"> ● Engine: Two seconds after the engine was started ● Idle switch: OFF ● Engine speed: 2,500 r/min or more ● During high engine load <p>Set Conditions</p> <ul style="list-style-type: none"> ● The sensor output voltage does not change for 4 seconds (no pulse signal input). | <ul style="list-style-type: none"> ● Malfunction of the vehicle speed sensor ● Open or short circuit in the vehicle speed sensor circuit or loose connector contact ● Malfunction of engine-ECU |




13C-40

| Code No. P0505 Idle speed control (ISC) system | Probable cause |
|---|--|
| <p>Check Area</p> <ul style="list-style-type: none">● Vehicle speed has reached 1.5 km/h at least once.● Under the closed loop idle speed control. <p>Judgment Criteria</p> <ul style="list-style-type: none">● Actual idle speed has continued to be higher than the target idle speed by 300 r/min or more for 10 sec. <p>Check Area</p> <ul style="list-style-type: none">● Vehicle speed has reached 1.5 km/h at least once.● During idle speed closed loop control.● The highest temperature at the last drive is 45°C or less.● Engine coolant temperature is approx. 80°C or more.● Battery voltage is 10 V or more.● Intake air temperature is -10°C or more. <p>Judgment Criteria</p> <ul style="list-style-type: none">● Actual idle speed has been minimum 200 r/min higher than the target idle speed for 10 seconds. <p>Check Area</p> <ul style="list-style-type: none">● During idle speed closed loop control.● Engine coolant temperature is about 80°C or higher.● Battery voltage is 10 V or higher.● Power steering switch is off.● Intake air temperature is -10°C or more.● Volume efficiency is 40 percent or lower.● Barometric pressure is 76 kPa or higher. <p>Judgment Criteria</p> <ul style="list-style-type: none">● Actual idle speed has been minimum 100 r/min higher than the target idle speed for 10 seconds. | <ul style="list-style-type: none">● Malfunction of idle speed control (ISC) servo● Improper connector contact, open circuit or short-circuit harness wire● Malfunction of engine-ECU |






| Code No. P0551 Power Steering fluid Pressure Switch System | Probable cause |
|---|--|
| <p>Check Area</p> <ul style="list-style-type: none"> ● Intake air temperature is -10°C or higher. ● Barometric pressure is 76 kPa or higher. ● Engine coolant temperature is 30°C or more. ● Repeat *1 drive and *2 stop ten times or more. <p>*1: Engine speed is 2,500 r/min or higher, volumetric efficiency is 55 % or higher and vehicle speed is 5 km/h or higher for 4 seconds or more.</p> <p>*2: Vehicle speed is 1.5 km/h or lower.</p> <p>Judgment Criteria</p> <ul style="list-style-type: none"> ● Power steering pressure switch remains on. | <ul style="list-style-type: none"> ● Power steering fluid pressure switch failed. ● Open or shorted power steering fluid pressure switch circuit or loose connector ● Malfunction of engine-ECU |




| Code No. P1603 Battery backup line system | Probable cause |
|---|---|
| Range of Check ● Ignition switch: ON Set Conditions ● Backup RAM data which was set when the ignition switch was turned off the previous time has not been retained. | <ul style="list-style-type: none"> ● Open circuit or short-circuit in the battery backup line, or loose connector contact ● Malfunction of the engine-ECU |



| Code No. P1610 Immobilizer system | Probable cause |
|--|--|
| Range of Check ● Ignition switch: ON Set Conditions ● Improper communication between the engine-ECU and the immobilizer-ECU | <ul style="list-style-type: none"> ● Open or short circuit, or loose connector contact ● Malfunction of the immobilizer-ECU ● Malfunction of the engine-ECU |

NOTE

- (1) If the registered ignition keys are close each other when starting the engine, radio interference may cause this code to be displayed.
- (2) This code may be displayed when registering the key ID code.




INSPECTION CHART FOR TROUBLE SYMPTOMS

| Trouble symptom | | Inspection procedure No. | Reference page |
|--|---|--------------------------|----------------|
| Communication with MUT-II is impossible. | Communication with all systems is not possible. | 1 | 13C-47 |
| | Communication with engine-ECU only is not possible. | 2 | 13C-47 |
| Engine warning lamp and related parts | The engine warning lamp does not illuminate right after the ignition switch is turned to the ON position. | 3 | 13C-48 |
| | The engine warning lamp remains illuminating and never goes out. | 4 | 13C-48 |
| Starting | No initial combustion (starting impossible) | 5 | 13C-49 |
| | Initial combustion but no complete combustion (starting impossible) | 6 | 13C-50 |
| | Long time to start (improper starting) | 7 | 13C-51 |
| Idling stability (Improper idling) | Unstable idling (Rough idling, hunting) | 8 | 13C-52 |
| | Idling speed is high. (Improper idling speed) | 9 | 13C-54 |
| | Idling speed is low. (Improper idling speed) | 10 | 13C-54 |
| Idling stability (Engine stalls) | When the engine is cold, it stalls at idling. (Die out) | 11 | 13C-55 |
| | When the engine becomes hot, it stalls at idling. (Die out) | 12 | 13C-56 |
| | The engine stalls when starting the car. (Pass out) | 13 | 13C-58 |
| | The engine stalls when decelerating. | 14 | 13C-58 |
| Driving | Hesitation, sag or stumble | 15 | 13C-59 |
| | The feeling of impact or vibration when accelerating | 16 | 13C-60 |
| | The feeling of impact or vibration when decelerating | 17 | 13C-60 |
| | Poor acceleration | 18 | 13C-61 |
| | Surge | 19 | 13C-63 |
| | Knocking | 20 | 13C-64 |
| Dieseling | | 21 | 13C-64 |
| Too high CO and HC concentration when idling | | 22 | 13C-65 |
| Idling speed is improper when A/C is operating | | 23 | 13C-66 |
| Fans (radiator fan, A/C condenser fan) are inoperative | | 24 | 13C-67 |

INSPECTION PROCEDURE FOR TROUBLE SYMPTOMS


INSPECTION PROCEDURE 1

| Communication with MUT-II is not possible. (Communication with all systems is not possible.) | Probable cause |
|---|---|
| The cause is probably a defect in the power supply system (including earth) for the diagnosis line. | <ul style="list-style-type: none"> ● Malfunction of the connector ● Malfunction of the harness wire |




INSPECTION PROCEDURE 2

| MUT-II communication with engine-ECU is impossible. | Probable cause |
|--|--|
| One of the following causes may be suspected. <ul style="list-style-type: none"> ● No power supply to engine-ECU. ● Defective earth circuit of engine-ECU. ● Defective engine-ECU. ● Improper communication line between engine-ECU and MUT-II | <ul style="list-style-type: none"> ● Malfunction of engine-ECU power supply circuit ● Malfunction of engine-ECU ● Open circuit between the engine-ECU and diagnosis connector |




INSPECTION PROCEDURE 3

| | |
|--|---|
| <p>The engine warning lamp does not illuminate right after the ignition switch is turned to the ON position.</p> | <p>Probable cause</p> |
| <p>Because there is a burnt-out bulb, the engine-ECU causes the engine warning lamp to illuminate for five seconds immediately after the ignition switch is turned to ON. If the engine warning lamp does not illuminate immediately after the ignition switch is turned to ON, one of the malfunctions listed at right has probably occurred.</p> | <ul style="list-style-type: none"> ● Burnt-out bulb ● Defective warning lamp circuit ● Malfunction of the engine-ECU |




INSPECTION PROCEDURE 4

| | |
|--|---|
| <p>The engine warning lamp remains illuminating and never goes out.</p> | <p>Probable cause</p> |
| <p>In cases such as the above, the cause is probably that the engine-ECU is detecting a problem in a sensor or actuator, or that one of the malfunctions listed at right has occurred.</p> | <ul style="list-style-type: none"> ● Short-circuit between the engine warning lamp and engine-ECU ● Malfunction of the engine-ECU |




INSPECTION PROCEDURE 5

| No initial combustion (starting impossible) | Probable cause |
|--|--|
| In cases such as the above, the cause is probably that a spark plug is defective, or that the supply of fuel to the combustion chamber is defective. In addition, foreign materials (water, kerosene, etc.) may be mixed with the fuel. | <ul style="list-style-type: none"> ● Malfunction of the ignition system ● Malfunction of the fuel pump system ● Malfunction of the injectors ● Malfunction of the engine-ECU ● Malfunction of the immobilizer system ● Foreign materials in fuel |




INSPECTION PROCEDURE 6

| Initial combustion but no complete combustion (starting impossible) | Probable cause |
|---|--|
| In such cases as the above, the cause is probably that the spark plugs are generating sparks but the sparks are weak, or the initial mixture for starting is not appropriate. | <ul style="list-style-type: none"> ● Malfunction of the ignition system ● Malfunction of the injector system ● Foreign materials in fuel ● Poor compression ● Malfunction of the engine-ECU |




INSPECTION PROCEDURE 7


| It takes too long time to start. (Incorrect starting) | Probable cause |
|--|--|
| In cases such as the above, the cause is probably that the spark is weak and ignition is difficult, the initial mixture for starting is not appropriate, or sufficient compression pressure is not being obtained. | <ul style="list-style-type: none"> ● Malfunction of the ignition system ● Malfunction of the injector system ● Inappropriate gasoline use ● Poor compression |



INSPECTION PROCEDURE 8


| Unstable idling (Rough idling, hunting) | Probable cause |
|--|--|
| <p>In cases as the above, the cause is probably that the ignition system, air/fuel mixture, idle speed control (ISC) or compression pressure is defective. Because the range of possible causes is broad, inspection is narrowed down to simple items.</p> | <ul style="list-style-type: none"> ● Malfunction of the ignition system ● Malfunction of air-fuel ratio control system ● Malfunction of the ISC system ● Malfunction of the purge control solenoid valve system ● Malfunction of the EGR solenoid valve system ● Poor compression ● Drawing air into exhaust system |






INSPECTION PROCEDURE 9

| Idling speed is high. (Improper idling speed) | Probable cause |
|--|---|
| In such cases as the above, the cause is probably that the intake air volume during idling is too great. | <ul style="list-style-type: none"> ● Malfunction of the ISC servo system ● Malfunction of the throttle body |




INSPECTION PROCEDURE 10

| Idling speed is low. (Improper idling speed) | Probable cause |
|--|---|
| In cases such as the above, the cause is probably that the intake air volume during idling is too small. | <ul style="list-style-type: none"> ● Malfunction of the ISC servo system ● Malfunction of the throttle body |




INSPECTION PROCEDURE 11


| When the engine is cold, it stalls at idling. (Die out) | Probable cause |
|--|---|
| In such cases as the above, the cause is probably that the air/fuel mixture is inappropriate when the engine is cold, or that the intake air volume is insufficient. | <ul style="list-style-type: none"> ● Malfunction of the ISC servo system ● Malfunction of the throttle body ● Malfunction of the injector system ● Malfunction of the ignition system |



INSPECTION PROCEDURE 12


| When the engine is hot, it stalls at idling. (Die out) | Probable cause |
|--|---|
| In such cases as the above, the cause is probably that ignition system, air/fuel mixture, idle speed control (ISC) or compression pressure is defective. In addition, if the engine suddenly stalls, the cause may also be a defective connector contact. | <ul style="list-style-type: none"> ● Malfunction of the ignition system ● Malfunction of air-fuel ratio control system ● Malfunction of the ISC system ● Drawing air into intake system ● Improper connector contact |






INSPECTION PROCEDURE 13

| The engine stalls when starting the car. (Pass out) | Probable cause |
|--|--|
| In cases such as the above, the cause is probably misfiring due to a weak spark, or an inappropriate air/fuel mixture when the accelerator pedal is depressed. | <ul style="list-style-type: none"> • Drawing air into intake system • Malfunction of the ignition system |




INSPECTION PROCEDURE 14


| The engine stalls when decelerating. | Probable cause |
|--|---|
| In cases such as the above, the cause is probably that the intake air volume is insufficient due to a defective idle speed control (ISC) servo system. | <ul style="list-style-type: none"> • Malfunction of the ISC system |



INSPECTION PROCEDURE 15


| Hesitation, sag or stumble | Probable cause |
|--|---|
| In cases such as the above, the cause is probably that ignition system, air/fuel mixture or compression pressure is defective. | <ul style="list-style-type: none"> ● Malfunction of the ignition system ● Malfunction of air-fuel ratio control system ● Malfunction of the fuel supply system ● Malfunction of the EGR control solenoid valve system ● Poor compression |






INSPECTION PROCEDURE 16

| The feeling of impact or vibration when accelerating | Probable cause |
|--|--|
| In cases such as the above, the cause is probably that there is an ignition leak accompanying the increase in the spark plug demand voltage during acceleration. | <ul style="list-style-type: none"> Malfunction of the ignition system |




INSPECTION PROCEDURE 17


| The feeling of impact or vibration when decelerating. | Probable cause |
|---|---|
| Malfunction of the ISC system is suspected. | <ul style="list-style-type: none"> Malfunction of the ISC system |



INSPECTION PROCEDURE 18


| Poor acceleration | Probable cause |
|--|--|
| Defective ignition system, abnormal air-fuel ratio, poor compression pressure, etc. are suspected. | <ul style="list-style-type: none"> ● Malfunction of the ignition system ● Malfunction of air-fuel ratio control system ● Malfunction of the fuel supply system ● Poor compression pressure ● Clogged exhaust system |






INSPECTION PROCEDURE 19

| Surge | Probable cause |
|---|--|
| Defective ignition system, abnormal air-fuel ratio, etc. are suspected. | <ul style="list-style-type: none"> ● Malfunction of the ignition system ● Malfunction of air-fuel ratio control system ● Malfunction of the EGR control solenoid valve system |



INSPECTION PROCEDURE 20

| Knocking | Probable cause |
|---|---|
| In cases as the above, the cause is probably that the detonation control is defective or the heat value of the spark plug is inappropriate. | <ul style="list-style-type: none"> ● Defective detonation sensor ● Inappropriate heat value of the spark plug |




INSPECTION PROCEDURE 21

| Dieseling | Probable cause |
|---|---|
| Fuel leakage from injectors is suspected. | <ul style="list-style-type: none"> ● Fuel leakage from injectors |

Check the injectors for fuel leakage.


INSPECTION PROCEDURE 22

| Too high CO and HC concentration when idling | Probable cause |
|--|---|
| Abnormal air-fuel ratio is suspected. | <ul style="list-style-type: none"> ● Malfunction of the air-fuel ratio control system ● Deteriorated catalyst |




INSPECTION PROCEDURE 23

| Idling speed is improper when A/C is operating | Probable cause |
|--|--|
| <p>If the engine-ECU detects that the air conditioner is on, it activates the idle speed control (ISC) servo to control idle-up operation. The A/C-ECU judges if the load caused by air conditioner operation is high or low, and converts it to voltage signal (high or low voltage) and inputs the signal to the engine-ECU. Based on this voltage signal, the engine-ECU controls the idle-up speed (for high or low load).</p> | <ul style="list-style-type: none"> ● Malfunction of the A/C control system ● Improper connector contact, open circuit or short-circuited harness wire ● Malfunction of the engine-ECU |




INSPECTION PROCEDURE 24

| Fans (radiator fan, A/C condenser fan) are inoperative | Probable cause |
|--|--|
| <p>The engine-ECU outputs a duty signal to the fan controller depending on the engine coolant temperature, vehicle speed, and air conditioner switch condition. Based on this signal, the fan controller controls the radiator fan and condenser fan speeds. (The more the average voltage at the terminal approaches 5 V, the higher the fan speed become.)</p> | <ul style="list-style-type: none"> ● Malfunction of the fan motor relay ● Malfunction of the fan motor ● Malfunction of the fan controller ● Improper connector contact, open circuit or short-circuited harness wire ● Malfunction of the engine-ECU |




INSPECTION PROCEDURE 25

| Engine-ECU power supply and earth circuit system | Probable cause |
|--|---|
| The engine-ECU may be defective, or that one of the malfunctions listed at right has occurred. | <ul style="list-style-type: none"> Improper connector contact, open circuit or short-circuited harness wire in the engine-ECU power supply circuit. Open circuit or short-circuited harness wire in the engine-ECU earth circuit Malfunction of the engine-ECU |




INSPECTION PROCEDURE 26


| Power supply system and ignition switch-IG system | Probable cause |
|---|---|
| When an ignition switch ON signal is input to the engine-ECU, the engine-ECU turns the control relay ON. This causes battery voltage to be supplied to the engine-ECU, injectors and air flow sensor. | <ul style="list-style-type: none"> ● Malfunction of the ignition switch ● Malfunction of the control relay ● Improper connector contact, open circuit or short-circuited harness wire ● Disconnected engine-ECU earth wire ● Malfunction of the engine-ECU |



INSPECTION PROCEDURE 27

| Fuel pump system | Probable cause |
|---|---|
| The engine-ECU turns the control relay ON when the engine is cranking or running, and this supplies power to drive the fuel pump. | <ul style="list-style-type: none"> ● Malfunction of the fuel pump relay ● Malfunction of the fuel pump ● Improper connector contact, open circuit or short-circuited harness wire ● Malfunction of the engine-ECU |







INSPECTION PROCEDURE 28

| Ignition switch-ST system | Probable cause |
|--|---|
| The ignition switch-ST outputs a HIGH signal to the engine-ECU while the engine is cranking. The engine-ECU uses this signal to carry out functions such as fuel injection control during starting. | <ul style="list-style-type: none"> ● Malfunction of the ignition switch ● Malfunction of the inhibitor switch <A/T> ● Open circuit or short-circuited harness wire of the ignition switch circuit ● Malfunction of the engine-ECU |

<M/T>




<A/T>




INSPECTION PROCEDURE 29


| A/C switch and A/C relay system | Probable cause |
|---|---|
| When an A/C ON signal is input to the engine-ECU, the engine-ECU carries out control of the idle speed control (ISC) servo, and also operates the A/C compressor magnetic clutch. | <ul style="list-style-type: none"> ● Malfunction of A/C control system ● Malfunction of A/C switch ● Improper connector contact, open circuit or short-circuited harness wire ● Malfunction of the engine-ECU |



INSPECTION PROCEDURE 30

| Ignition circuit system | Probable cause |
|---|---|
| The engine-ECU interrupts the ignition coil primary current by turning the power transistor inside the engine-ECU ON and OFF. | <ul style="list-style-type: none"> ● Malfunction of ignition coil. ● Malfunction of ignition failure sensor. ● Improper connector contact, open circuit or short-circuited harness wire ● Malfunction of the engine-ECU |





DATA LIST REFERENCE TABLE

Caution

When shifting the select lever to D range, the brakes should be applied so that the vehicle does not move forward.

NOTE

- *1. In a new vehicle [driven approximately 500 km or less], the air flow sensor output frequency is sometimes 10 % higher than the standard frequency.
- *2. The injector drive time represents the time when the cranking speed is at 250 r/min or below when the power supply voltage is 11 V.
- *3. In a new vehicle [driven approximately 500 km or less], the injector drive time is sometimes 10 % longer than the standard time.
- *4. In a new vehicle [driven approximately 500 km or less], the step of the stepper motor is sometimes 30 steps greater than the standard value.
- ★ It will not be displayed when service data of the check mode is selected.

| Item No. | Inspection item | Inspection contents | | Normal condition | Inspection procedure No. | Reference page |
|----------|-------------------------------|---|---|--|--------------------------|----------------|
| 11 | Oxygen sensor (front) | Engine: After having warmed up Air/fuel mixture is made leaner when decelerating, and is made richer when racing. | When at 4,000 r/min, engine is suddenly decelerated | 200 mV or less | Code No. P0130 | 13C-25 |
| | | | When engine is suddenly raced | 600 – 1,000 mV | | |
| | | Engine: After having warmed up The oxygen sensor signal is used to check the air/fuel mixture ratio, and control condition is also checked by the ECU. | Engine is idling | 400 mV or less (Changes) 600 – 1,000 mV | | |
| | | | 2,500 r/min | | | |
| 12 | Air flow sensor*1 | <ul style="list-style-type: none"> ● Engine coolant temperature: 80 – 95°C ● Lamps, electric cooling fan and all accessories: OFF ● Transmission: Neutral (A/T: P range) | Engine is idling | 12 – 38 Hz | – | – |
| | | | 2,500 r/min | 58 – 98 Hz | | |
| | | | Engine is raced | Frequency increases in response to racing | | |
| 13 | Intake air temperature sensor | Ignition switch: ON or with engine running | When intake air temperature is –20°C | –20°C | Code No. P0110 | 13C-18 |
| | | | When intake air temperature is 0°C | 0°C | | |
| | | | When intake air temperature is 20°C | 20°C | | |
| | | | When intake air temperature is 40°C | 40°C | | |
| | | | When intake air temperature is 80°C | 80°C | | |

| Item No. | Inspection item | Inspection contents | | Normal condition | Inspection procedure No. | Reference page |
|----------|--------------------------------------|---|--|---|--------------------------|----------------|
| 14 | Throttle position sensor | Ignition switch: ON | Set to idle position | 535 – 735 mV | Code No. P0120 | 13C-22 |
| | | | Gradually open | Increases in proportion to throttle opening angle | | |
| | | | Open fully | 4,750 mV or more | | |
| 16 | Power supply voltage | Ignition switch: ON | | System voltage | Procedure No. 25 | 13C-68 |
| 18 | Cranking signal (ignition switch-ST) | Ignition switch: ON | Engine: Stopped | OFF | Procedure No. 28 | 13C-71 |
| | | | Engine: Cranking | ON | | |
| 21 | Engine coolant temperature sensor | Ignition switch: ON or with engine running | When engine coolant temperature is –20°C | –20°C | Code No. P0115 | 13C-20 |
| | | | When engine coolant temperature is 0°C | 0°C | | |
| | | | When engine coolant temperature is 20°C | 20°C | | |
| | | | When engine coolant temperature is 40°C | 40°C | | |
| | | | When engine coolant temperature is 80°C | 80°C | | |
| 22 | Crank angle sensor | <ul style="list-style-type: none"> ● Engine: Cranking ● Tachometer: Connected | Compare the engine speed readings on the tachometer and the MUT-II. | Accord | Code No. P0335 | 13C-33 |
| | | | <ul style="list-style-type: none"> ● Engine: Idling ● Idle position switch: ON | When engine coolant temperature is –20°C | | |
| | | When engine coolant temperature is 0°C | | 1,320 – 1,520 r/min | | |
| | | When engine coolant temperature is 20°C | | 1,200 – 1,400 r/min | | |
| | | When engine coolant temperature is 40°C | | 1,100 – 1,300 r/min | | |
| | | When engine coolant temperature is 80°C | 600 – 800 r/min | | | |


| Item No. | Inspection item | Inspection contents | Normal condition | Inspection procedure No. | Reference page | | |
|----------|--------------------------------------|---|--|---------------------------------|------------------|--------|-----|
| 24 | Vehicle speed sensor | Drive at 40 km/h | Approximately 40 km/h | Code No. P0500 | 13C-39 | | |
| 25 | Barometric pressure sensor | Ignition switch: ON | At altitude of 0 m | 101 kPa | Code No. P0105 | 13C-16 | |
| | | | At altitude of 600 m | 95 kPa | | | |
| | | | At altitude of 1,200 m | 88 kPa | | | |
| | | | At altitude of 1,800 m | 81 kPa | | | |
| 27 | Power steering fluid pressure switch | Engine: Idling | Steering wheel stationary | OFF | Code No. P0551 | 13C-43 | |
| | | | Steering wheel turning | ON | | | |
| 28 | A/C switch | Engine: Idling | A/C switch: OFF | OFF | Procedure No. 29 | 13C-72 | |
| | | | A/C switch: ON | A/C compressor does not operate | | | OFF |
| | | | | A/C compressor operates | | | ON |
| 29 | Inhibitor switch <A/T> | Ignition switch: ON | P or N | P or N | Procedure No. 28 | 13C-71 | |
| | | | D, 2, L or R | D, 2, L or R | | | |
| 41 | Injectors* ² | Engine: Cranking | When engine coolant temperature is 0°C (injection is carried out for all cylinders simultaneously) | 14 – 21 ms | – | – | |
| | | | When engine coolant temperature is 20°C | 30 – 45 ms | | | |
| | | | When engine coolant temperature is 80°C | 6.9 – 10.4 ms | | | |
| | Injectors* ³ | <ul style="list-style-type: none"> ● Engine coolant temperature: 80 – 95°C ● Lamps, electric cooling fan and all accessories: OFF ● Transmission: Neutral (A/T: P range) | Engine is idling | 1.6 – 2.8 ms | | | |
| | | | 2,500 r/min | 1.4 – 2.6 ms | | | |
| | | | When engine is suddenly raced | Increases | | | |

| Item No. | Inspection item | Inspection contents | Normal condition | Inspection procedure No. | Reference page | | |
|----------|--------------------------------------|--|--|------------------------------|------------------|--------|-----|
| 44 | Ignition coils and power transistors | <ul style="list-style-type: none"> Engine: After having warmed up Timing lamp is set. (The timing lamp is set in order to check actual ignition timing.) | Engine is idling | 2 – 18° BTDC | Code No. P0300 | – | |
| | | | 2,500 r/min | 23 – 43° BTDC | | | |
| 45 | ISC (step-per) motor position*4 | <ul style="list-style-type: none"> Engine coolant temperature: 80 – 95°C Lamps, electric cooling fan and all accessories: OFF Transmission: Neutral (A/T: P range) Idle position switch: ON Engine: Idling When A/C switch is ON, A/C compressor should be operating | A/C switch: OFF | 2 – 25 STEP | – | – | |
| | | | A/C switch: OFF → ON | Increases by 10 – 70 steps | | | |
| | | | <ul style="list-style-type: none"> A/C switch: OFF Select lever: N range → D range | Increases by 5 – 50 steps | | | |
| 49 | A/C relay | Engine: After having warmed up/Engine is idling | A/C switch: OFF | OFF | Procedure No. 29 | 13C-72 | |
| | | | A/C switch: ON | A/C compressor is not driven | | | OFF |
| | | | | A/C compressor is driven | | | ON |
| 59 | Oxygen sensor (rear) | <ul style="list-style-type: none"> Transmission: 2nd gear <M/T>, L range <A/T> Drive with throttle widely open | 3,500 r/min | 600 – 1,000 mV | Code No. P0316 | 13C-27 | |
| 24★ | Vehicle speed sensor | Drive at 40 km/h | | Approximately 40 km/h | Code No. P0500 | 13C-39 | |
| 81★ | Long-term fuel compensation | Engine: Warm, 2,500 r/min without any load (during closed loop) | | –12.5 – 12.5 % | Code No. P0170 | 13C-29 | |
| 82★ | Short-term fuel compensation | Engine: Warm, 2,500 r/min without any load (during closed loop) | | –25 – 25 % | Code No. P0170 | 13C-29 | |
| 87★ | Calculation load value | Engine: Warm | Engine: Idling | 10 – 30 % | – | – | |
| | | | 2,500 r/min | 17 – 37 % | | | |
| 88★ | Fuel control condition | Engine: Warm | 2,500 r/min | Closed loop | Code No. P0125 | 13C-24 | |
| | | | When engine is suddenly raced | Open loop – drive condition | | | |

| Item No. | Inspection item | Inspection contents | Normal condition | Inspection procedure No. | Reference page | |
|----------|---|--|---|--|----------------|--------|
| A1 ★ | Oxygen sensor (sensor 1) | Engine: After warm-up | Idling | 0.2 V or less | Code No. P0130 | 13C-25 |
| | | | Sudden racing | 0.6 – 1.0 V | | |
| | | | 2,500 r/min | 0.4 V or less and 0.6 – 1.0 V alternates | | |
| A2 ★ | Oxygen sensor (sensor 2) | <ul style="list-style-type: none"> Transmission: 2nd gear <M/T>, L range <A/T> Drive with throttle widely open | 3,500 r/min | 0.6 – 1.0 V | Code No. P0136 | 13C-27 |
| 8A ★ | Throttle position sensor (Throttle valve opening angle) | <ul style="list-style-type: none"> Engine coolant temperature: 80 – 95°C Ignition switch: ON (Engine: Stopped) | Release the accelerator pedal. | 6 – 20 % | Code No. P0120 | 13C-22 |
| | | | Depress the accelerator pedal gradually | Increase in response to pedal depression stroke. | | |
| | | | Depress the accelerator pedal fully. | 80 – 100 % | | |

ACTUATOR TEST REFERENCE TABLE

| Item No. | Inspection item | Drive contents | Inspection contents | Normal condition | Inspection procedure No. | Reference page | |
|----------|------------------------------|--|---|---|--------------------------|------------------|--------|
| 01 | Injectors | Cut fuel to No. 1 injector | Engine: After having warmed up/Engine is idling (Cut the fuel supply to each injector in turn and check cylinders which don't affect idling.) | Idling condition becomes different (becomes unstable). | Code No. P0201 | 13C-30 | |
| 02 | | Cut fuel to No. 2 injector | | | Code No. P0202 | 13C-30 | |
| 03 | | Cut fuel to No. 3 injector | | | Code No. P0203 | 13C-30 | |
| 04 | | Cut fuel to No. 4 injector | | | Code No. P0204 | 13C-30 | |
| 07 | Fuel pump | Fuel pump operates and fuel is recirculated. | <ul style="list-style-type: none"> Engine: Cranking Fuel pump: Forced driving Inspect according to both the above conditions. | Pinch the return hose with fingers to feel the pulse of the fuel being recirculated. Listen near the fuel tank for the sound of fuel pump operation. | Pulse is felt. | Procedure No. 27 | 13C-69 |
| 08 | Purge control solenoid valve | Solenoid valve turns from OFF to ON. | Ignition switch: ON | Sound of operation can be heard when solenoid valve is driven. | Code No. P0443 | 13C-38 | |
| 10 | EGR control solenoid valve | Solenoid valve turns from OFF to ON. | Ignition switch: ON | Sound of operation can be heard when solenoid valve is driven. | Code No. P0403 | 13C-36 | |
| 17 | Basic ignition timing | Set to ignition timing adjustment mode | Engine: Idling Timing light is set | 5° BTDC | – | – | |
| 21 | Fan relay | Drive the fan motor | Ignition switch: ON | Radiator fan and condenser fan operate at high speed | Procedure No. 24 | 13C-67 | |



CHECK AT THE ENGINE-ECU TERMINALS

TERMINAL VOLTAGE CHECK CHART

1. Connect a needle-nosed wire probe (test harness: MB991223 or paper clip) to a voltmeter probe.
2. Insert the needle-nosed wire probe into each of the engine-ECU connector terminals from the wire side, and measure the voltage while referring to the check chart.

NOTE


- (1) Make the voltage measurement with the engine-ECU connectors connected.
- (2) You may find it convenient to pull out the engine-ECU to make it easier to reach the connector terminals.
- (3) The checks can be carried out off the order given in the chart.

Caution

Short-circuiting the positive (+) probe between a connector terminal and earth could damage the vehicle wiring, the sensor, engine-ECU or all of them. Be careful to prevent this!

3. If voltmeter shows any deviation from standard value, check the corresponding sensor, actuator and related electrical wiring, then repair or replace.
4. After repair or replacement, recheck with the voltmeter to confirm that the repair has corrected the problem.

Engine-ECU Connector Terminal Arrangement



9FU0393

| Terminal No. | Check item | Check condition (Engine condition) | Normal condition |
|--------------|---|--|---|
| 1 | No. 1 injector | While engine is idling after having warmed up, suddenly depress the accelerator pedal. | From 11 – 14 V, momentarily drops slightly |
| 14 | No. 2 injector | | |
| 2 | No. 3 injector | | |
| 15 | No. 4 injector | | |
| 4 | Stepper motor coil <A> | Engine: Soon after the warmed up engine is started | System voltage ↔ 0 V (Changes repeatedly) |
| 17 | Stepper motor coil | | |
| 5 | Stepper motor coil <C> | | |
| 18 | Stepper motor coil <D> | | |
| 6 | EGR control solenoid valve | Ignition switch: ON | System Voltage |
| | | While engine is idling, suddenly depress the accelerator pedal. | From system voltage, momentarily drops |
| 8 | A/C relay | <ul style="list-style-type: none"> Engine: Idle speed A/C switch: OFF → ON (A/C compressor is operating) | System voltage or momentarily 6 V or more → 0 – 3 V |
| 9 | Purge control solenoid valve | Ignition switch: ON | System voltage |
| | | Running at 3,000 r/min while engine is warming up after having been started. | 0 – 3 V |
| 10 | Ignition coil – No. 1, No. 4 (power transistor) | Engine r/min: 3,000 r/min | 0.3 – 3.0 V |
| 23 | Ignition coil – No. 2, No. 3 (power transistor) | | |
| 12 | Power supply | Ignition switch: ON | System voltage |
| 25 | | | |
| 19 | Air flow sensor reset signal | Engine: Idle speed | 0 – 1 V |
| | | Engine r/min: 3,000 r/min | 6 – 9 V |
| 20 | Condenser motor relay (HI) | Radiator fan is not operating (Engine coolant temperature is 90°C or less) | System voltage |
| | | Radiator fan is not operating (Engine coolant temperature is 105°C or less) | 0 – 3 V |

| Terminal No. | Check item | Check condition (Engine condition) | Normal condition |
|--------------|--------------------------------------|--|--|
| 21 | Radiator motor relay (LO) | Radiator fan and condenser fan are not operating (Engine coolant temperature is 90°C or less) | System voltage |
| | | Radiator fan and condenser fan are not operating (Engine coolant temperature is 90 – 105°C or less) | 0 – 3 V |
| 22 | Fuel pump relay | Ignition switch: ON | System voltage |
| | | Engine: Idle speed | 0 – 3 V |
| 33 | Alternator G terminal | <ul style="list-style-type: none"> ● Engine: Warm, idle (radiator fan: OFF) ● Headlamp: OFF to ON ● Rear defogger switch: OFF to ON ● Brake lamp: ON | Voltage rises by 0.2 – 3.5 V. |
| 41 | Alternator FR terminal | <ul style="list-style-type: none"> ● Engine: Warm, idle (radiator fan: OFF) ● Headlamp: OFF to ON ● Rear defogger switch: OFF to ON ● Brake lamp: ON | Voltage drops by 0.2 – 3.5 V. |
| 36 | Engine warning lamp | Ignition switch: "LOCK" (OFF) position → ON | 0 – 3 V → 9 – 13 V (After several seconds have elapsed) |
| 37 | Power steering fluid pressure switch | Engine: Idling after warming up | When steering wheel is stationary System voltage |
| | | | When steering wheel is turned 0 – 3 V |
| 38 | Control relay (Power supply) | Ignition switch: "LOCK" (OFF) position | System voltage |
| | | Ignition switch: ON | 0 – 3 V |
| 45 | A/C switch 1 | Engine: Idle speed | Turn the A/C switch OFF 0 – 3 V |
| | | | Turn the A/C switch ON (A/C compressor is operating) System voltage |
| 58 | Tachometer signal | Engine r/min: 3,000 r/min | 0.3 – 3.0 V |
| 60 | Oxygen sensor (front) heater | Engine: Idling after warming up | 0 – 3 V |
| | | Engine r/min: 5,000 r/min | System voltage |
| 54 | Oxygen sensor (rear) heater | Engine: Idling after warming-up | 0 – 3 V |
| | | Engine r/min: 5,000 r/min | System voltage |
| 71 | Ignition switch – ST | Engine: Cranking | 8 V or more |

| Terminal No. | Check item | Check condition (Engine condition) | Normal condition | |
|--------------|-----------------------------------|---|---|-------------|
| 72 | Intake air temperature sensor | Ignition switch: ON | When intake air temperature is 0°C | 3.2 – 3.8 V |
| | | | When intake air temperature is 20°C | 2.3 – 2.9 V |
| | | | When intake air temperature is 40°C | 1.5 – 2.1 V |
| | | | When intake air temperature is 80°C | 0.4 – 1.0 V |
| 75 | Oxygen sensor (rear) | <ul style="list-style-type: none"> • Transmission: 2nd gear <M/T>, L range <A/T> • Engine r/min: 3,500 r/min or more • Driving with the throttle valve widely open | 0.6 – 1.0 V | |
| 76 | Oxygen sensor (front) | Engine: Running at 2,500 r/min after warmed up (Check using a digital type voltmeter) | 0 ↔ 0.8 V (Changes repeatedly) | |
| 77 | A/C thermo sensor | <ul style="list-style-type: none"> • Ignition switch: ON • Temperature at sensor: 25°C (1.5 kΩ) | 2.2 V | |
| 80 | Backup power supply | Ignition switch: "LOCK" (OFF) position | System voltage | |
| 81 | Sensor impressed voltage | Ignition switch: ON | 4.5 – 5.5 V | |
| 82 | Ignition switch – IG | Ignition switch: ON | System voltage | |
| 83 | Engine coolant temperature sensor | Ignition switch: ON | When engine coolant temperature is 0°C | 3.2 – 3.8 V |
| | | | When engine coolant temperature is 20°C | 2.3 – 2.9 V |
| | | | When engine coolant temperature is 40°C | 1.3 – 1.9 V |
| | | | When engine coolant temperature is 80°C | 0.3 – 0.9 V |
| 84 | Throttle position sensor | Ignition switch: ON | Set throttle valve to idle position | 0.3 – 1.0 V |
| | | | Fully open throttle valve | 4.5 – 5.5 V |

| Terminal No. | Check item | Check condition (Engine condition) | Normal condition | |
|--------------|----------------------------|--|---------------------------------|-------------|
| 85 | Barometric pressure sensor | Ignition switch: ON | When altitude is 0 m | 3.7 – 4.3 V |
| | | | When altitude is 1,200 m | 3.2 – 3.8 V |
| 86 | Vehicle speed sensor | <ul style="list-style-type: none"> ● Ignition switch: ON ● Move the vehicle slowly forward | 0 ↔ 5 V (Changes repeatedly) | |
| 88 | Camshaft position sensor | Engine: Cranking | 0.4 – 3.0 V | |
| | | Engine: Idle speed | 0.5 – 2.0 V | |
| 89 | Crank angle sensor | Engine: Cranking | 0.4 – 4.0 V | |
| | | Engine: Idle speed | 1.5 – 2.5 V | |
| 90 | Air flow sensor | Engine: Idle speed | 2.2 – 3.2 V | |
| | | Engine r/min: 2,500 r/min | | |

CHECK CHART FOR RESISTANCE AND CONTINUITY BETWEEN TERMINALS

1. Turn the ignition switch to “LOCK” (OFF) position.
2. Disconnect the engine-ECU connector.
3. Measure the resistance and check for continuity between the terminals of the engine-ECU harness-side connector while referring to the check chart.

NOTE

- (1) When measuring resistance and checking continuity, a harness for checking contact pin pressure should be used instead of inserting a test probe.
- (2) Checking need not be carried out in the order given in the chart.


Caution

If the terminals that should be checked are mistaken, or if connector terminals are not correctly shorted to earth, damage may be caused to the vehicle wiring, sensors, engine-ECU and/or ohmmeter.

Be careful to prevent this!

4. If the ohmmeter shows any deviation from the standard value, check the corresponding sensor, actuator and related electrical wiring, and then repair or replace.
5. After repair or replacement, recheck with the ohmmeter to confirm that the repair or replacement has corrected the problem.


Engine-ECU Harness Side Connector Terminal Arrangement



9FU0392

| Terminal No. | Inspection item | Normal condition (Check condition) |
|-----------------|------------------------------|------------------------------------|
| 1 – 12 | No. 1 injector | 13 – 16 Ω (At 20°C) |
| 14 – 12 | No. 2 injector | |
| 2 – 12 | No. 3 injector | |
| 15 – 12 | No. 4 injector | |
| 4 – 12 | Stepper motor coil (A) | 28 – 33 Ω (At 20°C) |
| 17 – 12 | Stepper motor coil (B) | |
| 5 – 12 | Stepper motor coil (C) | |
| 18 – 12 | Stepper motor coil (D) | |
| 6 – 12 | EGR control solenoid valve | 29 – 35 Ω (At 20°C) |
| 9 – 12 | Purge control solenoid valve | 29 – 35 Ω (At 20°C) |
| 13 – Body earth | Engine-ECU earth | Continuity (0 Ω) |
| 26 – Body earth | Engine-ECU earth | |
| 60 – 12 | Oxygen sensor (front) heater | 4.5 – 8.0 Ω (At 20°C) |
| 54 – 12 | Oxygen sensor (rear) heater | 11 – 18 Ω (At 20°C) |

| Terminal No. | Inspection item | Normal condition (Check condition) |
|--------------|-----------------------------------|--|
| 72 – 92 | Intake air temperature sensor | 5.3 – 6.7 k Ω (When intake air temperature is 0°C) |
| | | 2.3 – 3.0 k Ω (When intake air temperature is 20°C) |
| | | 1.0 – 1.5 k Ω (When intake air temperature is 40°C) |
| | | 0.30 – 0.42 k Ω (When intake air temperature is 80°C) |
| 83 – 92 | Engine coolant temperature sensor | 5.1 – 6.5 k Ω (When coolant temperature is 0°C) |
| | | 2.1 – 2.7 k Ω (When coolant temperature is 20°C) |
| | | 0.9 – 1.3 k Ω (When coolant temperature is 40°C) |
| | | 0.26 – 0.36 k Ω (When coolant temperature is 80°C) |



INSPECTION PROCEDURE USING AN ANALYZER

AIR FLOW SENSOR (AFS)

Measurement Method

1. Disconnect the air flow sensor connector, and connect the special tool (test harness: MB991709) in between. (All terminals should be connected.)
2. Connect the analyzer special patterns pickup to air flow sensor connector terminal 3.

Alternate Method (Test harness not available)


1. Connect the analyzer special patterns pickup to engine-ECU terminal 90.

Standard Wave Pattern


Observation conditions

| Function | Special patterns |
|------------------|------------------|
| Pattern height | Low |
| Pattern selector | Display |
| Engine r/min | Idle speed |

Standard wave pattern




Observation conditions (from conditions above engine speed is increased by racing.)



Wave Pattern Observation Points

Check that cycle time T becomes shorter and the frequency increases when the engine speed is increased.



Examples of Abnormal Wave Patterns

- Example 1

Cause of problem

Sensor interface malfunction

Wave pattern characteristics

Rectangular wave pattern is output even when the engine is not started.


- Example 2

Cause of problem

Damaged rectifier or vortex generation column

Wave pattern characteristics

Unstable wave pattern with non-uniform frequency. However, when an ignition leak occurs during acceleration, the wave pattern will be distorted temporarily, even if the air flow sensor is normal.



CAMSHAFT POSITION SENSOR AND CRANK ANGLE SENSOR

Measurement Method

1. Disconnect the camshaft position sensor connector and connect the special tool (test harness: MB991659) and jumper wire in between. (All terminals should be connected.)
2. Connect the analyzer special patterns pickup to camshaft position sensor terminal 2.
3. Disconnect the crank angle sensor connector and connect the special tool (test harness: MB991658) in between.
4. Connect the analyzer special patterns pickup to crank angle sensor terminal 3.

Alternate Method (Test harness not available)


1. Connect the analyzer special patterns pickup to engine-ECU terminal 88. (When checking the camshaft position sensor signal wave pattern.)
2. Connect the analyzer special patterns pickup to engine-ECU terminal 89. (When checking the crank angle sensor signal wave pattern.)

Standard Wave Pattern

Observation conditions


| | |
|------------------|------------------|
| Function | Special patterns |
| Pattern height | Low |
| Pattern selector | Display |
| Engine r/min | Idle speed |

Standard wave pattern



Wave Pattern Observation Points

Check that cycle time T becomes shorter when the engine speed increases.



Examples of Abnormal Wave Patterns


- Example 1

Cause of problem

Sensor interface malfunction

Wave pattern characteristics

Rectangular wave pattern is output even when the engine is not started.




- Example 2

Cause of problem

Loose timing belt
Abnormality in sensor disk

Wave pattern characteristics

Wave pattern is displaced to the left or right.



Examples of Abnormal Wave Patterns


- Example 1

Cause of problem

Sensor interface malfunction

Wave pattern characteristics

Rectangular wave pattern is output even when the engine is not started.



- Example 2


Cause of problem

Loose timing belt

Abnormality in sensor disk

Wave pattern characteristics

Wave pattern is displaced to the left or right.



INJECTOR

Measurement Method

1. Disconnect the injector connector, and then connect the special tool (test harness: MB991348) in between. (Both the power supply side and engine-ECU side should be connected.)
2. Connect the analyzer special patterns pickup to terminal 2 of the injector connector.

Alternate Method (Test harness not available)


1. Connect the analyzer special patterns pickup to engine-ECU terminal 1. (When checking the No. 1 cylinder.)
2. Connect the analyzer special patterns pickup to engine-ECU terminal 14. (When checking the No. 2 cylinder.)
3. Connect the analyzer special patterns pickup to engine-ECU terminal 2. (When checking the No. 3 cylinder.)
4. Connect the analyzer special patterns pickup to engine-ECU terminal 15. (When checking the No. 4 cylinder.)

Standard Wave Pattern

Observation conditions

| | |
|------------------|---------------------------------------|
| Function | Special patterns |
| Pattern height | Variable |
| Variable knob | Adjust while viewing the wave pattern |
| Pattern selector | Display |
| Engine r/min | Idle speed |

Standard wave pattern




Wave Pattern Observation Points


Point A: Height of solenoid back electromotive force

| | |
|---|--------------------------------|
| Contrast with standard wave pattern | Probable cause |
| Solenoid coil back electromotive force is low or doesn't appear at all. | Short in the injector solenoid |

Point B: Injector drive time



- The injector drive time will be synchronized with the MUT-II tester display.
- When the engine is suddenly raced, the drive time will be greatly extended at first, but the drive time will soon match the engine speed.



IDLE SPEED CONTROL (ISC) SERVO (STEPPER MOTOR)

Measurement Method

1. Disconnect the ISC servo connector, and connect the special tool (test harness: MB991709) in between.
2. Connect the analyzer special patterns pickup to the ISC servo-side connector terminal 1, terminal 3, terminal 4 and terminal 6 respectively.

Alternate Method (Test harness not available)


1. Connect the analyzer special patterns pickup to engine-ECU terminal 4, connection terminal 5, connection terminal 17, and connection terminal 18 respectively.

Standard Wave Pattern

Observation conditions

| Function | Special patterns |
|------------------|--|
| Pattern height | High |
| Pattern selector | Display |
| Engine condition | When the engine coolant temperature is 20°C or below, turn the ignition switch from LOCK (OFF) position to ON (without starting the engine). |
| | While the engine is idling, turn the A/C switch to ON. |
| | Immediately after starting the warm engine |

Standard wave pattern



Wave Pattern Observation Points


Check that the standard wave pattern appears when the stepper motor is operating.

Point A: Presence or absence of induced electromotive force from the motor turning. (Refer to the abnormal wave pattern.)

| | |
|--|-------------------------|
| Contrast with standard wave pattern | Probable cause |
| Induced electromotive force does not appear or is extremely small. | Motor is malfunctioning |

Point B: Height of coil reverse electromotive force

| | |
|---|-------------------|
| Contrast with standard wave pattern | Probable cause |
| Coil reverse electromotive force does not appear or is extremely small. | Short in the coil |



Examples of Abnormal Wave Pattern

- Example 1

Cause of problem

Motor is malfunctioning. (Motor is not operating.)

Wave pattern characteristics

Induced electromotive force from the motor turning does not appear.


- Example 2


Cause of problem

Open circuit in the line between the stepper motor and the engine-ECU.

Wave pattern characteristics

Current is not supplied to the motor coil on the open circuit side. (Voltage does not drop to 0 V.) Furthermore, the induced electromotive force waveform at the normal side is slightly different from the normal waveform.





IGNITION COIL AND POWER TRANSISTOR

- Ignition coil primary signal
Refer to GROUP 16 – Ignition system.
- Power transistor control signal

Measurement Method

1. Disconnect the ignition coil connector, and connect the special tool (test harness: MB991348) in between. (All terminals should be connected.)
2. Connect the analyzer special patterns pickup to terminal 3 of each ignition coil connector in turn.

Alternate Method (Test harness not available)


1. Connect the analyzer special patterns pickup to engine-ECU terminal 10 (No. 1 – No. 4), terminal 23 (No. 2 – No. 3) respectively.

Standard Wave Pattern

Observation condition

| | |
|------------------|---------------------|
| Function | Special patterns |
| Pattern height | Low |
| Pattern selector | Display |
| Engine r/min | Approx. 1,200 r/min |


Standard wave pattern



Wave Pattern Observation Points

Point: Condition of wave pattern build-up section and maximum voltage (Refer to abnormal wave pattern examples 1 and 2.)

| Condition of wave pattern build-up section and maximum voltage | Probable cause |
|--|--|
| Rises from approx. 2 V to approx. 4.5 V at the top-right | Normal |
| 2 V rectangular wave | Open-circuit in ignition primary circuit |
| Rectangular wave at power voltage | Power transistor malfunction |



Examples of Abnormal Wave Patterns

- Example 1


Wave pattern during engine cranking

Cause of problem

Open-circuit in ignition primary circuit

Wave pattern characteristics

Top-right part of the build-up section cannot be seen, and voltage value is approximately 2 V too low.



- Example 2


Wave pattern during engine cranking

Cause of problem

Malfunction in power transistor

Wave pattern characteristics

Power voltage results when the power transistor is ON.




ON-VEHICLE SERVICE

THROTTLE BODY (THROTTLE VALVE AREA) CLEANING

1. Disconnect the air intake hose from the throttle body.
2. Apply some detergent to a clean cloth.
3. Use the clean cloth with detergent to wipe the area around the throttle valve until it is clean.


Caution

- (1) Do not let any of the detergent get directly onto the throttle valve.
 - (2) Take care not to let any detergent get into the motor through the bypass passage. Furthermore, do not let it get to the sensor through the shaft.
 - (3) Do not wipe the molybdenum coating which is located around the throttle valve shaft.
4. Connect the air intake hose.
 5. Adjust the standard idle speed.



THROTTLE POSITION SENSOR ADJUSTMENT


1. Turn the ignition switch to LOCK (OFF) position.
2. Connect the MUT-II to the diagnosis connector.
When not using the MUT-II, proceed as follows:



- (1) Disconnect the throttle position sensor connector, and connect the special tool (throttle position sensor test harness: MB991536) between the disconnected connector taking care not to confuse the terminal to be connected.
- (2) Connect digital voltmeter between the terminal No.2 (sensor output: blue clip of special tool) and the terminal No.4 (sensor earth: black clip of special tool) of the throttle position sensor connector.

3. Turn the ignition switch to ON (but do not start the engine).
4. Check the output voltage of the throttle position sensor.

Standard value: 535 – 735 mV



5. If not within the standard value, loosen the throttle position sensor mounting bolts. Then rotate the sensor body to adjust.
6. Turn the ignition switch to LOCK (OFF) position.
7. Remove the MUT-II. If the MUT-II is not used, remove the special tool, and then connect the throttle position sensor connector.
8. If a diagnosis code is displayed, erase the diagnosis code by using the MUT-II or disconnect the negative battery cable from the battery terminal and then leave it for at least ten seconds. After that, reconnect the battery cable, and then let the engine run at idle for approx. ten minutes.

BASIC IDLE SPEED ADJUSTMENT

NOTE

- (1) The standard idling speed has been adjusted by the speed adjusting screw (SAS) by the manufacturer, and there should usually be no need for readjustment.
 - (2) If the adjustment has been changed by mistake, the idle speed may become too high or the idle speed may drop too low when loads from components such as the A/C are placed on the engine. If this occurs, adjust by the following procedure.
 - (3) The adjustment, if made, should be made after first confirming that the spark plugs, the injectors, the idle speed control servo, the compression pressure, etc., are all normal.
1. Before inspection and adjustment, set the vehicle to the pre-inspection condition.
 2. Turn the ignition switch to LOCK (OFF) position.
 3. Connect the MUT-II to the diagnosis connector (16-pin).

NOTE

When the MUT-II is connected, the diagnosis control terminal should be earthed.

4. Start the engine and run at idle.
5. Select the item No.30 of the MUT-II Actuator test.

NOTE


This holds the ISC servo at the basic step to adjust the basic idle speed.

6. Check the idle speed.

Standard value: 700 ± 50 r/min

NOTE

- (1) The engine speed may be 20 to 100 r/min lower than indicated above for a new vehicle [driven approximately 500 km or less], but no adjustment is necessary.
- (2) If the engine stalls or the engine speed is low even though the vehicle has been driven approximately 500 km or more, it is probable that deposits are adhered to the throttle valve, so clean it. (Refer to P.13C-96.)




7. If not within the standard value range, turn the speed adjusting screw (SAS) to make the necessary adjustment.
8. Press the MUT-II clear key, and release the ISC servo from the Actuator test mode.

NOTE

Unless the ISC servo is released, the Actuator test mode will continue 27 minutes.


9. Turn the ignition switch to LOCK (OFF) position.
10. Disconnect the MUT-II.
11. Start the engine again and let it run at idle speed for about 10 minutes; check that the idling condition is normal.

**FUEL PRESSURE TEST**

1. Release residual pressure from the fuel pipe line to prevent fuel gush out. (Refer to P.13C-70.)
2. Disconnect the high-pressure fuel hose at the delivery pipe side.

Caution


Cover the hose connection with rags to prevent splash of fuel that could be caused by some residual pressure in the fuel pipe line.



3. Remove the union joint and bolt from the special tool (adapter hose) and instead attach the special tool (hose adapter) to the adapter hose.
4. Install the special tool (for measuring the fuel pressure) that was set up in step 3.

<When using the fuel pressure gauge set (special tool)>


 - (1) Install the special tool (for measuring the fuel pressure) between the high-pressure fuel hose and the delivery pipe.
 - (2) Install the fuel pressure gauge set (special tool) on the special tool (for measuring the fuel pressure) putting the gasket between them.
 - (3) Connect the lead wire of the fuel pressure gauge set (special tool) to the power supply (cigarette lighter socket) and to the MUT-II.



<When using the fuel pressure gauge>

- (1) Install the fuel pressure gauge on the special tool (for measuring the fuel pressure) putting a suitable O-ring or gasket between them.
- (2) Install the special tool which was set up in step (1) between the high-pressure fuel hose and the delivery pipe.
5. Connect the MUT-II to the diagnosis connector.
6. Turn the ignition switch to ON. (But do not start the engine.)
7. Select "Item No.07" from the MUT-II Actuator test to drive the fuel pump. Check that there are no fuel leaks from any parts.
8. Finish the actuator test or turn the ignition switch to LOCK (OFF) position.
9. Start the engine and run at idle.
10. Measure fuel pressure while the engine is running at idle.

Standard value: Approx. 265 kPa



11. Disconnect the vacuum hose from the fuel pressure regulator and measure fuel pressure with the hose end closed by a finger.

Standard value: 324–349 kPa

12. Check to see that fuel pressure at idle does not drop even after the engine has been raced several times.
13. Racing the engine repeatedly, hold the fuel return hose lightly with fingers to feel that fuel pressure is present in the return hose.

NOTE

If the fuel flow rate is low, there will be no fuel pressure in the return hose.

14. If any of fuel pressure measured in steps 10 to 13 is out of specification, troubleshoot and repair according to the table below.

| Symptom | Probable cause | Remedy |
|---|--|-------------------------------------|
| <ul style="list-style-type: none"> ● Fuel pressure too low ● Fuel pressure drops after racing ● No fuel pressure in fuel return hose | Clogged fuel filter | Replace fuel filter |
| | Fuel leaking to return side due to poor fuel regulator valve seating or settled spring | Replace fuel pressure regulator |
| | Low fuel pump delivery pressure | Replace fuel pump |
| Fuel pressure too high | Binding valve in fuel pressure regulator | Replace fuel pressure regulator |
| | Clogged fuel return hose or pipe | Clean or replace hose or pipe |
| Same fuel pressure when vacuum hose is connected and when disconnected | Damaged vacuum hose or clogged nipple | Replace vacuum hose or clean nipple |

15. Stop the engine and check change of fuel pressure gauge reading. Normal if the reading does not drop within 2 minutes. If it does, observe the rate of drop and troubleshoot and repair according to the table below.

| Symptom | Probable cause | Remedy |
|---|---------------------------------------|---------------------------------|
| Fuel pressure drops gradually after engine is stopped | Leaky injector | Replace injector |
| | Leaky fuel regulator valve seat | Replace fuel pressure regulator |
| Fuel pressure drops sharply immediately after engine is stopped | Check valve in fuel pump is held open | Replace fuel pump |

16. Release residual pressure from the fuel pipe line.
(Refer to P.13C-70.)
17. Remove the fuel pressure gauge and special tool from the delivery pipe.


Caution

Cover the hose connection with rags to prevent splash of fuel that could be caused by some residual pressure in the fuel pipe line.

18. Replace the O-ring at the end of the fuel high pressure hose with a new one. Furthermore, apply engine oil to the new O-ring before replacement.
19. Fit the fuel high pressure hose over the delivery pipe and tighten the bolt to specified torque.

Tightening torque: 9.0 ± 2.0 Nm

20. Check for any fuel leaks by following the procedure in step 7.
21. Disconnect the MUT-II.



**FUEL PUMP CONNECTOR DISCONNECTION
(HOW TO REDUCE THE FUEL PRESSURE)**

When removing the fuel pipe, hose, etc., since fuel pressure in the fuel pipe line is high, do the following operation so as to release the fuel pressure in the line and prevent fuel from running out.


1. Remove the fuel pump relay.
2. After starting the engine and letting it run until it stops naturally, turn the ignition switch to LOCK (OFF) position.
3. Install the fuel pump relay.


FUEL PUMP OPERATION CHECK

Refer to GROUP 13A – On-vehicle Service.

COMPONENT LOCATION


| Name | Symbol | Name | Symbol |
|---|--------|---|--------|
| A/C relay | A | Engine warning lamp (check engine lamp) | O |
| A/C switch | Q | Idle speed control servo | B |
| Air flow sensor (With intake air temperature sensor and barometric pressure sensor) | J | Ignition coil | N |
| | | Ignition failure sensor | E |
| Camshaft position sensor | F | Inhibitor switch <A/T> | G |
| Control relay and fuel pump relay | A | Injectors | D |
| Crank angle sensor | L | Oxygen sensor (front) | I |
| Detonation sensor | K | Oxygen sensor (rear) | S |
| Diagnosis connector | P | Power steering fluid pressure switch | M |
| EGR control solenoid valve | C | Purge control solenoid valve | C |
| Engine coolant temperature sensor | H | Throttle position sensor | B |
| Engine-ECU | R | Vehicle speed sensor | T |





CONTROL RELAY AND FUEL PUMP RELAY CONTINUITY CHECK

| Battery voltage | Terminal No. | | | |
|-----------------|--------------|---|---|---|
| | 1 | 2 | 3 | 4 |
| Not supplied | | ○ | | ○ |
| Supplied | ○ | ⊖ | ○ | ⊕ |




INTAKE AIR TEMPERATURE SENSOR CHECK

1. Disconnect the air flow sensor connector.
2. Measure resistance between terminals 5 and 6.

Standard value:

- 13 – 17 kΩ (at -20°C)
- 5.7 – 6.7 kΩ (at 0°C)
- 2.3 – 3.0 kΩ (at 20°C)
- 1.0 – 1.5 kΩ (at 40°C)
- 0.56 – 0.76 kΩ (at 60°C)
- 0.30 – 0.42 kΩ (at 80°C)




3. Measure resistance while heating the sensor using a hair drier.

Normal condition:

| Temperature (°C) | Resistance (kΩ) |
|------------------|-----------------|
| Higher | Smaller |

4. If the value deviates from the standard value or the resistance remains unchanged, replace the air flow sensor assembly.




ENGINE COOLANT TEMPERATURE SENSOR CHECK

Caution

Be careful not to touch the connector (resin section) with the tool when removing and installing.

1. Remove the engine coolant temperature sensor.




2. With temperature sensing portion of engine coolant temperature sensor immersed in hot water, check resistance.

Standard value:

- 14 – 17 k Ω (at -20°C)
- 5.1 – 6.5 k Ω (at 0°C)
- 2.1 – 2.7 k Ω (at 20°C)
- 0.9 – 1.3 k Ω (at 40°C)
- 0.48 – 0.68 k Ω (at 60°C)
- 0.26 – 0.36 k Ω (at 80°C)

3. If the resistance deviates from the standard value greatly, replace the sensor.




4. Apply sealant to threaded portion.

Specified sealant:

3M Nut Locking Part No.4171 or equivalent

5. Install the engine coolant temperature sensor and tighten it to the specified torque.

Tightening torque: 29 ± 9 N·m

**THROTTLE POSITION SENSOR CHECK**

1. Disconnect the throttle position sensor connector.
2. Measure the resistance between the throttle position sensor side connector terminal 1 and terminal 4.

Standard value: 3.5 – 6.5 k Ω

3. Measure the resistance between the throttle position sensor side connector terminal 2 and terminal 4.


Normal condition:

| | |
|--|---|
| Throttle valve slowly open until fully open from the idle position | Changes smoothly in proportion to the opening angle of the throttle valve |
|--|---|



4. If the resistance is outside the standard value, or if it doesn't change smoothly, replace the throttle position sensor.

NOTE

For the throttle position sensor adjustment procedure, refer to P.13C-96.

**OXYGEN SENSOR CHECK**
<Oxygen sensor (front)>

1. Disconnect the oxygen sensor connector and connect the special tool (test harness) to the connector on the oxygen sensor side.
2. Make sure that there is continuity (4.8 – 8.0 Ω at 20°C) between terminal 1 (red clip of special tool) and terminal 3 (blue clip of special tool) on the oxygen sensor connector.



3. If there is no continuity, replace the oxygen sensor.
4. Warm up the engine until engine coolant is 80°C or higher.

5. Use the jumper wire to connect terminal 1 (red clip) of the oxygen sensor connector to the battery (+) terminal and terminal 3 (blue clip) to the battery (-) terminal.

Caution

Be very careful when connecting the jumper wire; incorrect connection can damage the oxygen sensor.

6. Connect a digital voltage meter between terminal 2 (black clip) and terminal 4 (white clip).
7. While repeatedly racing the engine, measure the oxygen sensor output voltage.


Standard value:

| Engine | Oxygen sensor output voltage | Remarks |
|------------------------|------------------------------|---|
| When racing the engine | 0.6 – 1.0 V | If you make the air/fuel ratio rich by racing the engine repeatedly, a normal oxygen sensor will output a voltage of 0.6 – 1.0 V. |

8. If the sensor is defective, replace the oxygen sensor.


NOTE

For removal and installation of the oxygen sensor, refer to GROUP 15 – Exhaust Pipe and Main Muffler.




<Oxygen sensor (rear)>

1. Disconnect the oxygen sensor connector and connect the special tool (test harness) to the connector on the oxygen sensor side.
2. Make sure that there is continuity (11 – 18 Ω at 20°C) between terminal 1 (red clip of special tool) and terminal 3 (blue clip of special tool) on the oxygen sensor connector.



3. If there is no continuity, replace the oxygen sensor.
4. Warm up the engine until engine coolant is 80°C or higher.



5. Use the jumper wire to connect terminal 1 (red clip) of the oxygen sensor connector to the battery (+) terminal and terminal 3 (blue clip) to the battery (-) terminal.

Caution

Be very careful when connecting the jumper wire; incorrect connection can damage the oxygen sensor.

6. Connect a digital voltage meter between terminal 2 (black clip) and terminal 4 (white clip).
7. While repeatedly racing the engine, measure the oxygen sensor output voltage.


Standard value:

| Engine | Oxygen sensor output voltage | Remarks |
|------------------------|------------------------------|---|
| When racing the engine | 0.6 – 1.0 V | If you make the air/fuel ratio rich by racing the engine repeatedly, a normal oxygen sensor will output a voltage of 0.6 – 1.0 V. |

8. If the sensor is defective, replace the oxygen sensor.

NOTE

For removal and installation of the oxygen sensor, refer to GROUP 15 – Exhaust Pipe and Main Muffler.



INJECTOR CHECK

Measurement of Resistance between Terminals


1. Remove the injector connector.
2. Measure the resistance between terminals.

Standard value: 13 – 16 Ω (at 20°C)


3. Install the injector connector.

Checking the Injection Condition


1. Following the steps below, bleed out the residual pressure within the fuel pipe line to prevent flow of the fuel. (Refer to P.13C-100.)
2. Remove the injector.
3. Arrange the special tool (injector test set), adaptor, fuel pressure regulator and clips as shown in the illustration below.



4. Connect the MUT-II to the diagnosis connector.
5. Turn the ignition switch to ON. (But do not start the engine.)
6. Select "Item No.7" from the MUT-II Actuator test to drive the fuel pump.




7. Activate the injector and check the atomized spray condition of the fuel. The condition can be considered satisfactory unless it is extremely poor.



- Stop the actuation of the injector, and check for leakage from the injector's nozzle.

Standard value: 1 drop or less per minute

- Activate the injector without activating the fuel pump; then, when the spray emission of fuel from the injector stops, disconnect the special tool and restore it to its original condition.
- Disconnect the MUT-II.



IDLE SPEED CONTROL (ISC) SERVO (STEPPER MOTOR) CHECK


Checking the Operation Sound

- Check that the engine coolant temperature is 20°C or below.

NOTE

Disconnecting the engine coolant temperature sensor connector and connecting the harness-side of the connector to another engine coolant temperature sensor that is at 20°C or below is also okay.

- Check that the operation sound of the stepper motor can be heard after the ignition is switched ON. (But do not start the engine.)
- If the operation sound cannot be heard, check the stepper motor's activation circuit.
If the circuit is normal, it is probable that there is a malfunction of the stepper motor or of the engine control unit.




Checking the Coil Resistance

- Disconnect the idle speed control servo connector.
- Measure the resistance between terminal 2 and either terminal 1 or terminal 3 of the connector at the idle speed control servo side.

Standard value: 27 – 33 Ω (at 20°C)

- Measure the resistance between terminal 5 and either terminal 6 or terminal 4 of the connector at the idle speed control servo side.

Standard value: 27 – 33 Ω (at 20°C)

**Operation Check**

1. Remove the throttle body.
2. Remove the stepper motor.
3. Connect the special tool (test harness: MB991709) to the idle speed control servo connector.
4. Connect the positive (+) terminal of a power supply (approx. 6 V) to the terminals 2 and 5.
5. With the idle speed control servo as shown in the illustration, connect the negative (–) terminal of the power supply to each clip as described in the following steps, and check whether or not a vibrating feeling (a feeling of very slight vibration of the stepper motor) is generated as a result of the activation of the stepper motor.
 - (1) Connect the negative (–) terminal of the power supply to the red and black clip.
 - (2) Connect the negative (–) terminal of the power supply to the blue and black clip.
 - (3) Connect the negative (–) terminal of the power supply to the blue and yellow clip.
 - (4) Connect the negative (–) terminal of the power supply to the red and yellow clip.
 - (5) Connect the negative (–) terminal of the power supply to the red and black clip.
 - (6) Repeat the tests in sequence from (5) to (1).
6. If, as a result of these tests, vibration is detected, the stepper motor can be considered to be normal.

**PURGE CONTROL SOLENOID VALVE CHECK
<Vehicles with catalytic converter>**

Refer to GROUP 17 – Emission Control System.

EGR CONTROL SOLENOID VALVE CHECK

Refer to GROUP 17 – Emission Control System.

INJECTOR



REMOVAL AND INSTALLATION

Pre-removal Operation

- Fuel Discharge Prevention (Refer to P.13C-100)
- Air Cleaner and Air Intake Pipe Removal (Refer to GROUP 15.)

Post-installation Operation

- Air Cleaner and Air Intake Pipe Installation (Refer to GROUP 15.)
- Accelerator Cable Adjustment (Refer to GROUP 17 – On-vehicle Service.)



Removal steps

- | | |
|---|----------------------|
| 1. Accelerator cable connection | 9. Fuel hose |
| 2. PCV hose | 10. Fuel return pipe |
| 3. Injector connector | 11. Delivery pipe |
| 4. Injector harness clamp | 12. Insulator |
| ▶A◀ 5. High-pressure fuel hose connection | 13. Insulator |
| 6. Fuel return hose connection | ◀A▶ ▶A▶ 14. Injector |
| 7. Vacuum hose connection | 15. Grommet |
| ▶A◀ 8. Fuel pressure regulator | |

AX0027AL

REMOVAL SERVICE POINT**◀A▶ DELIVERY PIPE/INJECTOR REMOVAL**

Remove the delivery pipe (with the injectors attached to it).

Caution

Care must be taken, when removing the delivery pipe, not to drop the injector.

INSTALLATION SERVICE POINT**▶A◀ INJECTOR/FUEL PRESSURE REGULATOR/
HIGH-PRESSURE FUEL HOSE INSTALLATION**

1. Apply a drop of new engine oil to the O-ring.

Caution

Be sure not to let engine oil in the delivery pipe.

2. While turning the injector, high-pressure fuel hose and fuel pressure regulator to the right and left, install the delivery pipe, while being careful not to damage the O-ring. After installing, check that the hose turns smoothly.
3. If it does not turn smoothly, the O-ring may be trapped, remove the injector, high-pressure fuel hose or fuel pressure regulator and then re-insert it into the delivery pipe and check once again.
4. Tighten the high-pressure fuel hose and fuel pressure regulator to the specified torque.

Tightening torque:

9.0 ± 2.0 N·m (Fuel pressure regulator)
5.0 ± 1.0 N·m (High-pressure fuel hose)

THROTTLE BODY


REMOVAL AND INSTALLATION

Pre-removal Operation

- Engine Coolant Draining
(Refer to GROUP 14 – On-vehicle Service.)
- Air Cleaner and Air Intake Pipe Removal
(Refer to GROUP 15.)

Post-installation Operation

- Air Cleaner and Air Intake Pipe Installation
(Refer to GROUP 15.)
- Engine Coolant Supplying
(Refer to GROUP 14 – On-vehicle Service.)
- Accelerator Cable Adjustment
(Refer to GROUP 17 – On-vehicle Service.)




A10014AL

Removal steps

1. Accelerator cable connection
2. Throttle position sensor connector
3. Idle speed control servo connector
4. Vacuum hose connection
5. Water hose connection
6. Stay
7. Throttle cable bracket
8. Harness Clamp
9. Throttle body
10. Throttle body gasket

DISASSEMBLY AND REASSEMBLY



9EN0994

Disassembly steps


- ▶A◀
1. Throttle position sensor
 2. Idle speed control body assembly
 3. O-ring
 4. Throttle body
 5. Speed adjusting screw
 6. O-ring

NOTE


1. The speed adjusting screw is correctly adjusted at the factory and should not be removed.
2. If the speed adjusting screw has been removed, carry out fixed SAS adjustment.
3. If the speed adjusting screw should happen to have been removed, carry out speed adjusting screw adjustment.

CLEANING THROTTLE BODY PARTS

1. Clean all throttle body parts.
Do not use solvent to clean the following parts:
 - Throttle position sensor
 - Accelerator pedal position sensor
 - Idle speed control body assembly
 If these parts are immersed in solvent, their insulation will deteriorate.
Wipe them with cloth only.
2. Check if the vacuum port or passage is clogged. Use compressed air to clean the vacuum passage.

**REASSEMBLY SERVICE POINT****▶A◀ THROTTLE POSITION SENSOR (TPS) INSTALLATION**

1. Install the TPS to the throttle body as shown by (1) in the illustration.
2. Turn the TPS so that it is at the position shown by (2) in the illustration, and then tighten the screw.
3. Connect a multimeter between terminal (4) (TPS power supply) and terminal (3) (TPS output) of the TPS connector, and check that the resistance increases gradually as the throttle valve is opened slowly to the fully-open position.
4. If there is an abnormality, replace the TPS.



NOTES