
BASIC BRAKE SYSTEM

BASIC BRAKE SYSTEM

CONTENTS


GENERAL INFORMATION	3	Brake Fluid Level Sensor Check	10
SERVICE SPECIFICATIONS	4	Disc Brake Pad Check and Replacement	11
LUBRICANTS	5	Disc Brake Rotor Check	12
SEALANT	5	Brake Disc Thickness Check	12
SPECIAL TOOLS	5	Brake Disc Run-out Check and Correction	13
ON-VEHICLE SERVICE	6	BRAKE PEDAL	14
Brake Pedal Check and Adjustment	6	MASTER CYLINDER AND BRAKE BOOSTER	15
Brake Booster Operating Test	7	Master Cylinder	19
Check Valve Operation Check	8	FRONT DISC BRAKE	20
Load Sensing Spring Length Check and Adjustment	8	REAR DISC BRAKE	25
Load Sensing Proportioning Valve Function Test	9	LOAD SENSING PROPORTIONING VALVE	31
Bleeding	10		

GENERAL INFORMATION

The brake system offers high dependability and durability along with improved braking performance and brake sensitivity.

Items		Specifications
Master cylinder	Type	Tandem type
	I.D. mm	22.2
Brake booster	Type	Vacuum type, single
	Effective dia. of power cylinder mm	230
	Boosting ratio	4.5
Load sensing proportioning valve	Type	Dual type
	Decompression ratio	0.25
Front disc brakes	Type	Floating caliper, 1-piston, ventilated disc
	Disc effective dia. × thickness mm	236 × 22
	Wheel cylinder I.D. mm	57.2
	Pad thickness mm	10.0
	Clearance adjustment	Automatic
Rear disc brakes	Type	Floating caliper, 1-piston, solid disc
	Disc effective dia. × thickness	222 × 9.4
	Wheel cylinder I.D. mm	34.93
	Pad thickness mm	10.0
	Clearance adjustment	Automatic
Brake fluid		DOT3 or DOT4

CONSTRUCTION DIAGRAM



AX0071AL

SERVICE SPECIFICATIONS

Items		Standard value	Limit
Brake pedal height mm	L.H. drive vehicles	201 – 204	–
	R.H. drive vehicles	201.7 – 204.7	–
Brake pedal play mm		3 – 8	–
Brake pedal to floorboard clearance when the brake pedal is depressed mm		105 or more	–
Brake booster push rod protrusion amount mm	L.H. drive vehicles with ABS	22.7 – 22.9	–
	L.H. drive vehicles without ABS and R.H. drive vehicles	23.93 – 24.18	–
Load sensing proportioning valve output fluid pressure (Input fluid pressure) MPa	When load sensing spring length is 199 mm (when unladen)	4.2 – 6.0 (9.8)	–
	When load sensing spring length is 217 mm (when laden)	9.7 – 10.5 (9.8)	–
		14.5 – 16.3 (16.7)	–
Output fluid pressure difference between left and right MPa		–	0.39
Load sensing spring length <Distance between spring ends> mm		194 – 198	–
Front disc brake	Pad thickness mm	10.0	2.0
	Disc thickness mm	22.0	20.4
	Disc runout mm	–	0.06
	Drag force N	69	–
Rear disc brake	Pad thickness mm	10.0	2.0
	Disc thickness mm	9.4	7.8
	Disc runout mm	–	0.08
	Drag force N	34	–
Front hub end play mm		–	0.2
Rear hub end play mm		–	0.025




LUBRICANTS


Items	Specified Lubricant	Quantity
Brake fluid	DOT3 or DOT4	As required
Vacuum sensor grommet	Silicone grease	
Brake booster seal		
Piston boot, piston seal	Repair kit grease	
Guide pin, lock pin		
Piston, wheel cylinder body	DOT3 or DOT4	

SEALANT

Items	Specified sealant	Remarks
Fitting	3M ATD Part No. 8661 or equivalent	Semi-drying sealant

SPECIAL TOOLS

Tool	Number	Name	Use
	MB990964 A: MB990520	Brake tool set	Pushing-in of the disc brake piston
	A: MB990998 B: MB991000	A: Front hub re- mover and installer B: Spacer	When bearing provisional holding MB991000, which belongs to MB990998, should be used as a spacer.
	MB991568	Push rod adjusting socket	Adjustment of the brake booster push rod protrusion amount



ON-VEHICLE SERVICE

BRAKE PEDAL CHECK AND ADJUSTMENT

BRAKE PEDAL HEIGHT

1. Turn up the carpet, etc. under the brake pedal.
2. Measure the brake pedal height as illustrated.

Standard value (A):


<L.H. drive vehicles> 201 – 204 mm

<R.H. drive vehicles> 201.7 – 204.7 mm

3. If the brake pedal height is not within the standard value, follow the procedure below.
 - (1) Disconnect the stop lamp switch connector.
 - (2) Loosen the stop lamp switch by turning it approx. 1/4 turns anticlockwise.
 - (3) Remove the pin, and then adjust so that the brake pedal height meets the standard value by turning the clevis.

NOTE

When the clevis is turned 180°, the pedal height is changed approximately 2.3 mm.




- (4) Screw in the stop lamp switch until it touches the stopper. At this time, support the brake pedal to the highest position by hand.
- (5) Lock the stop lamp switch by turning it approx. 1/4 turns clockwise, and confirm that the clearance between the switch plunger and the stopper is as shown.
- (6) Connect the connector at the stop lamp switch.

Caution

Check that the stop lamp does not illuminate when the brake pedal is not depressed.

4. For A/T, check the key interlock and shift lock mechanisms. (Refer to GROUP 23 – On-vehicle Service.)
5. Return the carpet, etc.




BRAKE PEDAL FREE PLAY

1. With the engine stopped, depress the brake pedal two or three times. After eliminating the vacuum in the power brake booster, press the pedal down by hand, and confirm that the amount of movement before resistance is met (the free play) is within the standard value range.

Standard value (B): 3 – 8 mm

2. If the brake pedal play is not within the standard value, check the following, and adjust or replace if necessary:
 - Excessive play between the brake pedal and the clevis pin, or between the clevis pin and the brake booster operating rod
 - Brake pedal height
 - Installation position of the stop lamp switch, etc.




CLEARANCE BETWEEN BRAKE PEDAL AND FLOOR BOARD

1. Turn up the carpet etc. under the brake pedal.
2. Start the engine, depress the brake pedal with approximately 490 N of force, and measure the clearance between the brake pedal and the floorboard.

Standard value (C): 105 mm or more


3. If the clearance is outside the standard value, check for air trapped in the brake line, thickness of the disc brake pad or the drum brake lining and dragging in the parking brake.
Adjust and replace defective parts as required.
4. Return the carpet, etc.




BRAKE BOOSTER OPERATING TEST

For simple checking of the brake booster operation, carry out the following tests:

1. Run the engine for one or two minutes, and then stop it.
If the pedal depresses fully the first time but gradually becomes higher when depressed succeeding times, the booster is operating properly. If the pedal height remains unchanged, the booster is defective.



2. With the engine stopped, step on the brake pedal several times.
Then start the engine while the brake pedal is stepped on.
If the pedal moves downward slightly, the booster is in good condition. If there is no change, the booster is defective.



- With the engine running, step on the brake pedal and then stop the engine. Hold the pedal depressed for 30 seconds. If the pedal height does not change, the booster is in good condition. If the pedal rises, the booster is defective.

If the above three tests are okay, the booster performance can be determined as good.

If one of the above three tests is not okay at least, the check valve, vacuum hose, or booster will be defective.

CHECK VALVE OPERATION CHECK

- Remove the vacuum hose. (Refer to P.35A-15, 16.)

Caution


The check valve should not be disassembled from the vacuum hose as they are united as one part.

- Check the operation of the check valve by using a vacuum pump.

Vacuum pump connection	Accept/reject criteria
Connection at the brake booster side (A)	A negative pressure (vacuum) is created and held.
Connection at the intake manifold side (B)	A negative pressure (vacuum) is not created.

Caution

If the check valve is defective, always replace it as an assembly unit together with the vacuum hose.




LOAD SENSING SPRING LENGTH CHECK AND ADJUSTMENT

- Park the vehicle on a level ground. The vehicle should be unloaded and supported only by wheels.

Caution


Never support the vehicle with jacks or other similar means.



- With the lever pressed all the way to the load sensing proportioning valve side, check whether or not the length (shown in the figure) of the spring (the length between its ends) is the standard value.


Standard value (A): 194 – 198 mm

- If the spring length is not within the standard value, loosen the bolt attaching the support and adjust the distance by moving the support.



**LOAD SENSING PROPORTIONING VALVE
FUNCTION TEST**

1. Connect pressure gauges to the input and output ports of the load sensing proportioning valve.
2. Bleed the system. (Refer to P.35A-10.)
3. Disconnect the spring at the support side.



4. Place the spring so that it is in parallel with the load sensing proportioning valve, and then pull in the direction indicated by arrow A so that its length H shown in the figure (the length between its ends) is as noted below.

NOTE

At this time the lever is pressed all the way to the load sensing proportioning valve side.

5. Check at this time whether or not the output fluid's pressure, relative to the load sensing proportioning valve's input fluid pressure, is within the standard value.

Standard value:

Spring length H mm	Input fluid pressure MPa	Output fluid pressure MPa
199*1	9.8	4.2 – 6.0
217*2	9.8	9.7 – 10.5
	16.7	14.5 – 16.3

NOTE

*1 and *2 indicate the applicable lengths for unladen and laden vehicles respectively.

6. Measure each output fluid pressure at both valves, and check that the difference between the two is at the limit value or less.


Limit: 0.39 MPa

7. After making the check, install the spring. Disconnect the pressure gauges from the load sensing proportioning valve and bleed air.

BLEEDING**Caution**


Specified brake fluid: DOT3 or DOT4

Always use the specified brake fluid. Avoid using a mixture of the specified brake fluid and other fluid.


**MASTER CYLINDER BLEEDING**

The master cylinder used has no check valve, so if bleeding is carried out by the following procedure, bleeding of air from the brake pipeline will become easier. (When brake fluid is not contained in the master cylinder.)

1. Fill the reserve tank with brake fluid.
2. Keep the brake pedal depressed.
3. Have another person cover the master cylinder outlet with a finger.
4. With the outlet still closed, release the brake pedal.
5. Repeat steps 2 – 4 three or four times to fill the inside of the master cylinder with brake fluid.

**BRAKE PIPE LINE BLEEDING**

Bleed the air in the sequence shown in the figure.


**BRAKE FLUID LEVEL SENSOR CHECK**

The brake fluid level sensor is in good condition if there is no continuity when the float surface is above "MIN" and if there is continuity when the float surface is below "MIN".

DISC BRAKE PAD CHECK AND REPLACEMENT

NOTE

The brake pads have wear indicators that contact the brake disc when the brake pad thickness reaches approximately 2 mm and emit a squealing sound to warn the driver.




1. Check the brake pad thickness through the caliper body check port.


Standard value: 10.0 mm

Limit: 2.0 mm

2. When the thickness is less than the limit, always replace the pads at an axle set.



3. Remove the guide lock pin bolt. Pivot the caliper assembly and hold it with wires.



4. Remove the following parts from the caliper support.

1. Pad and wear indicator assembly
2. Pad assembly
3. Clip
4. Inner shim
5. Outer shim

5. In order to measure the brake drag force after pad installation, measure the rotary-sliding resistance of the hub with the pads removed. (Refer to P.35A-20, 25.)

6. Install the pads and caliper assembly, and then check the brake drag force. (Refer to P.35A-21, 26.)


DISC BRAKE ROTOR CHECK

Caution

When servicing disc brakes, it is necessary to exercise caution to keep the disc brakes within the allowable service values in order to maintain normal brake operation.

Before re-finishing or re-processing the brake disc surface, the following conditions should be checked.

Inspection items	Remarks
Scratches, rust, saturated lining materials and wear	<ul style="list-style-type: none"> If the vehicle is not driven for a certain period, the sections of the discs that are not in contact with lining will become rusty, causing noise and shuddering. If grooves resulting from excessive disc wear and scratches are not removed prior to installing a new pad assembly, there will momentarily be inappropriate contact between the disc and the lining (pad).
Run-out or drift	Excessive run-out or drift of the discs will increase the pedal depression resistance due to piston knock-back.
Change in thickness (parallelism)	If the thickness of the disc changes, this will cause pedal pulsation, shuddering and surging.
Inset or warping (flatness)	Overheating and improper handling while servicing will cause inset or warping.



BRAKE DISC THICKNESS CHECK

- Using a micrometer, measure disc thickness at eight positions, approximately 45° apart and 10 mm in from the outer edge of the disc.


Brake disc thickness

Item	Standard value	Limit
Front	22.0	20.4
Rear	9.4	7.8

Thickness variation (at least 8 positions)

The difference between any thickness measurements should not be more than 0.015 mm.

- If the disc is beyond the limits for thickness, remove it and install a new one. If thickness variation exceeds the specification, replace the brake disc or grind it with on-the-car type brake lathe ("MAD, DL-8700PF" or equivalent).




BRAKE DISC RUN-OUT CHECK AND CORRECTION

1. Remove the brake assembly, and then hold it with wire.
2. Place a dial gauge approximately 5 mm from the outer circumference of the brake disc, and measure the run-out of the disc.

**Limit: <Front> 0.06 mm or less,
<Rear> 0.08 mm or less**

3. If the brake disc run-out exceeds the limit, correct it as follows:


(1) Chalk phase marks on the wheel stud and the brake disc, which run-out is excessive as shown.



(2) Remove the brake disc. Then place a dial gauge as shown, and measure the end play by pushing and pulling the wheel hub.

Limit: <Front> 0.2 mm, <Rear> 0.025 mm

- (3) If the end play exceeds the limit, disassemble the hub and knuckle assembly to check each part.
- (4) If the end play does not exceed the limit, dephase the brake disc and secure it. Then recheck the brake disc run-out.




4. If the run-out cannot be corrected by changing the phase of the brake disc, replace the brake disc or grind it with the on-the-car type brake lathe ("MAD, DL-8700PF" or equivalent).

BRAKE PEDAL

REMOVAL AND INSTALLATION


Post-installation Operation
 Brake Pedal Adjustment (Refer to P.35A-6.)



AW0151AL

Removal steps

- | | |
|--|--|
| <ol style="list-style-type: none"> 1. Harness connector 2. Stop lamp switch 3. Adjuster 4. Pedal stopper 5. Snap pin 6. Pin assembly | <ol style="list-style-type: none"> 7. Split pin <A/T> 8. Shift lock cable connection <A/T> 9. Pedal pad 10. Brake pedal and pedal support member |
|--|--|



1410005

INSPECTION

STOP LAMP SWITCH CHECK

1. Connect an ohmmeter between the stop lamp switch connector terminals.
2. There should be no continuity between the terminals when the plunger is pushed in as shown. There should be continuity when it is released.

MASTER CYLINDER AND BRAKE BOOSTER




REMOVAL AND INSTALLATION

<L.H. drive vehicles with ABS>

Pre-removal Operation
Brake Fluid Draining


Post-installation Operation

- Brake Fluid Supplying and Air Bleeding (Refer to P.35A-10.)
- Brake Pedal Adjustment (Refer to P.35A-6.)



Specified Sealant: 3M ATD Part No.8661 or equivalent

Grease: Silicone grease






35A-16 BASIC BRAKE SYSTEM – Master Cylinder and Brake Booster


<L.H. drive vehicles without ABS and R.H. drive vehicles>

Pre-removal Operation
Brake Fluid Draining


Post-installation Operation

- Brake Fluid Supplying and Air Bleeding (Refer to P.35A-10.)
- Brake Pedal Adjustment (Refer to P.35A-6.)


 <p>AX0100AL</p>	 <p>A14Z0003</p>	 <p>AW0747AL</p>
<p>Grease: Silicone grease</p>	<p>Specified Sealant: 3M ATD Part No.8661 or equivalent</p>	<p>Grease: Silicone grease</p>



<L.H. drive vehicles>



<R.H. drive vehicles>



Master cylinder removal steps

1. Brake pipe connection
 2. Brake fluid level sensor connector
 3. Bracket <L.H. drive vehicles>
 4. Master cylinder
- ▶C◀ 5. Seal

Brake booster removal steps

1. Brake pipe connection
 2. Brake fluid level sensor connector
 3. Bracket <L.H. drive vehicles>
 4. Master cylinder
 5. Seal
- ▶C◀
▶B◀ ● Push rod protrusion amount check and adjustment

- ▶A◀ 6. Vacuum hose
(With built-in check valve)
7. Snap pin
 8. Pin assembly
 9. Vacuum sensor connector
 10. Vacuum sensor
 11. Grommet
 12. Brake booster
 13. Sealer

Fitting removal

14. Fitting

INSTALLATION SERVICE POINTS

▶A◀ VACUUM HOSE CONNECTION

Insert the vacuum hose to the fitting with its paint mark facing forward <L.H. drive vehicles>/upward <R.H. drive vehicles> until the hose end reaches the edge of the hexagonal part of the fitting, and then secure the hose by using the hose clip.

▶B◀ PUSH ROD PROTRUSION AMOUNT CHECK AND ADJUSTMENT


1. Measure dimension (A).

Standard value (A) :

- <L.H. drive vehicles with ABS> 22.7 – 22.9 mm
- <L.H. drive vehicles without ABS and R.H. drive vehicles> 23.93 – 24.18 mm

NOTE

When a negative pressure of 66.7 kPa is applied to the brake booster, the push rod should protrude 22.2 – 22.4 mm <L.H. drive vehicles with ABS>/23.48 – 23.73 mm <L.H. drive vehicles without ABS and R.H. drive vehicles>.




Measuring distance A


Block gauge

1410088
00008957

35A-18 BASIC BRAKE SYSTEM – Master Cylinder and Brake Booster



2. If the protrusion amount is not within the standard value range, adjust the push rod length by turning the push rod. Use the special tool to turn the push rod while holding the rod spline with angle-nose pliers.



►◀ SEAL INSTALLATION

1. Apply silicone grease to the seal.
2. Install the seal to the master cylinder as shown.

INSPECTION




VACUUM SENSOR CHECK

Refer to GROUP 13A – Troubleshooting.

NOTE

The vacuum sensor is monitored by the engine-ECU. Diagnosis code is output when the vacuum sensor has a malfunction.


**MASTER CYLINDER <L.H. drive vehicles without ABS and R.H. drive vehicles>
DISASSEMBLY AND REASSEMBLY**



Disassembly steps

1. Reservoir cap
2. Pin
3. Reservoir tank
4. Brake fluid level sensor
5. Reservoir seal
6. Stopper ring

7. Piston guide
8. Cylinder cup
9. Plate
10. Primary piston assembly
11. Secondary piston assembly
12. Master cylinder body



DISASSEMBLY SERVICE POINT

◀▶ STOPPER RING REMOVAL


Push the primary piston assembly and remove the stopper ring.

FRONT DISC BRAKE


REMOVAL AND INSTALLATION

Pre-removal Operation
Brake Fluid Draining

Post-installation Operation
Brake Fluid Supplying and Air Bleeding
(Refer to P.35A-10.)

**Removal steps**

- ▶◀
1. Brake hose connection
 2. Gasket
 3. Disc brake assembly
 4. Brake disc

**INSTALLATION SERVICE POINT****▶◀ DISC BRAKE ASSEMBLY INSTALLATION**


1. In order to measure the brake drag force after pad installation, measure the rotary-sliding resistance of the hub by the following procedure with the pads removed.
 - (1) Withdraw the drive shaft. (Refer to GROUP 26 – Front Axle.)
 - (2) Attach the special tool to the front hub assembly as shown in the illustration, and tighten it to the specified torque.


Tightening torque: 196 – 255 Nm

- (3) Use a spring balance to measure the rotary-sliding resistance of the hub in the forward direction.
2. Install the caliper support to the knuckle, and then assemble the pad clip and the pad to the caliper support.


Caution

Do not contaminate the friction surfaces of the pads and brake discs by any oil or grease.





3. Clean the piston and insert it into the cylinder with the special tool.
4. Be careful that the piston boot does not become caught, when lowering the caliper assembly and install the guide pin to the caliper.
5. Start the engine, and then depress the brake pedal two or three times strongly. Then stop the engine.
6. Turn the brake disc forward 10 times.




7. Use a spring balance to measure the rotary-sliding resistance of the hub.
8. Calculate the drag force of the disc brake [difference between the values measured at steps 1 and 7].

Standard value: 69 N

9. If that drag force exceeds the standard value, disassemble the piston assembly. Then check the piston for contamination or rust, and confirm if the piston or the piston seal is deteriorated, and if the lock pin and the guide pin slide smoothly.

DISASSEMBLY AND REASSEMBLY



<p>Brake caliper kit</p>	<p>Pad set</p>	<p>Shim kit</p>	<p>Seal and boot kit</p>

Disassembly steps


1. Guide pin lock bolt
2. Guide pin
3. Boot
4. Bushing
5. Bushing retainer
6. Caliper support (including pad, clip, and shim)
7. Piston boot



8. Piston
9. Piston seal
10. Caliper body
11. Pad and wear indicator assembly
12. Pad assembly
13. Inner shim
14. Outer shim
15. Clip



LUBRICATION POINTS




Piston seal

W0544AL

14X0301



Caution
The piston seal inside the seal and boot kit is coated with special grease, so do not wipe this grease off.

Brake fluid: DOT3 or DOT4




AW0542AL

Grease: Repair kit grease



AW0542AL


Grease: Repair kit grease



W0560AL 00008973

W0543AL

Grease: Repair kit grease




DISASSEMBLY SERVICE POINTS

◀A▶ PISTON BOOT/PISTON REMOVAL

Use a piece of wood to protect the caliper body outer side, and then apply compressed air through the brake hose connection hole to withdraw the piston and piston boot.

Caution

If air is blown into the caliper body suddenly, the piston will pop out, causing damage to the caliper body. Be sure to apply compressed air gradually.



◀B▶ PISTON SEAL REMOVAL

1. Remove the piston seal with finger tip.

Caution


Do not use a flat-tipped screwdriver or other tool to prevent damage to inner cylinder.

2. Clean piston surface and inner bore with trichloroethylene, alcohol or the specified brake fluid.

Specified brake fluid: DOT3 or DOT4

INSPECTION

- Check the cylinder for wear, damage or rust.
- Check the piston surface for wear, damage or rust.
- Check the caliper body or sleeve for wear.
- Check pad for damage or adhesion of grease, check the backing metal for damage.



PAD WEAR CHECK

Measure thickness at the thinnest and worn area of the pad. Replace the pad assembly if the pad thickness is less than the limit value.

Standard value: 10 mm

Limit: 2.0 mm

Caution

1. Always replace the brake pads as an axle set.
2. If an excessive difference is found in the thickness between the right and left brake pads, check moving parts.

REAR DISC BRAKE


REMOVAL AND INSTALLATION

Pre-removal Operation

- Brake Fluid Draining


Post-installation Operation

- Brake Fluid Supplying and Air Bleeding (Refer to P.35A-10.)



Removal steps

- ▶A◀
1. Brake hose connection
 2. Disc brake assembly
 3. Brake disc




INSTALLATION SERVICE POINT

▶A◀ **DISC BRAKE ASSEMBLY INSTALLATION**


1. In order to measure the brake drag force after pad installation, use a spring balance to measure the rotary-sliding resistance of the hub with the pads removed.
2. Install the caliper support to the backing plate, and then assemble the pad clip and the pad to the caliper support.

Caution

Do not contaminate the friction surfaces of the pads and brake discs by any oil or grease.



3. Clean the piston and insert it into the cylinder with the special tool.
4. Be careful that the piston boot does not become caught, when lowering the caliper assembly and install the guide pin to the caliper.
5. Start the engine, and then depress the brake pedal two or three times strongly. Then stop the engine.
6. Turn the brake disc forward 10 times.




7. Use a spring balance to measure the rotary-sliding resistance of the hub.
8. Calculate the drag force of the disc brake [difference between the values measured at steps 1 and 7].

Standard value: 34 N

9. If that drag force exceeds the standard value, disassemble the piston assembly. Then check the piston for contamination or rust, and confirm if the piston or the piston seal is deteriorated, and if the lock pin and the guide pin slide smoothly.

DISASSEMBLY AND REASSEMBLY



<p>B14N0159</p>	<p>AW0133AE</p>	<p>AX0120AL</p>	<p>A14N0161</p>
<p>Brake caliper kit</p>	<p>Pad set</p>	<p>Shim set</p>	<p>Seal and boots kit</p>

Disassembly steps




1. Guide pin
2. Lock pin
3. Bushing
4. Caliper support (pad, clip, shim)
5. Pin boot
6. Boot ring
7. Piston boot
8. Piston




9. Piston seal
10. Caliper body
11. Pad and wear indicator assembly
12. Pad assembly
13. Inner shim
14. Outer shim
15. Clip



LUBRICATION POINTS



Piston seal




14X0302

A14X0301



Caution
The piston seal inside the seal and boot kit is coated with special grease, so do not wipe this grease off.

Brake fluid: DOT3 or DOT4




A14A0541

Grease: Repair kit grease



B14A0541


Grease: Repair kit grease



A14N0159

A14X0303

Grease: Repair kit grease




DISASSEMBLY SERVICE POINTS

◀A▶ PISTON BOOT/PISTON REMOVAL

Use a piece of wood to protect the caliper body outer side, and then apply compressed air through the brake hose connection hole to withdraw the piston and piston boot.

Caution

If air is blown into the caliper body suddenly, the piston will pop out, causing damage to the caliper body. Be sure to apply compressed air gradually.



◀B▶ PISTON SEAL REMOVAL


1. Remove the piston seal with finger tip.

Caution

Do not use a flat-tipped screwdriver or other tool to prevent damage to inner cylinder.

2. Clean piston surface and inner bore with trichloroethylene, alcohol or the specified brake fluid.

Specified brake fluid: DOT3 or DOT4




REASSEMBLY SERVICE POINT

▶A◀ LOCK PIN/GUIDE PIN INSTALLATION

Install the guide pin and lock pin as illustrated that each head mark of the guide pin and the lock pin matches the indication mark ("G" or "L") located on the caliper body.

INSPECTION

- Check the cylinder for wear, damage or rust.
- Check the piston surface for wear, damage or rust.
- Check the caliper body or sleeve for wear.
- Check pad for damage or adhesion of grease, check the backing metal for damage.

**PAD WEAR CHECK**

Measure thickness at the thinnest and worn area of the pad. Replace the pad assembly if the pad thickness is less than the limit value.

Standard value: 10 mm

Limit: 2.0 mm

Caution

1. Always replace the brake pads as an axle set.
2. If an excessive difference is found in the thickness between the right and left brake pads, check moving parts.

LOAD SENSING PROPORTIONING VALVE

REMOVAL AND INSTALLATION


Caution

Do not disassemble the load sensing proportioning valve.


Pre-removal Operation
Brake Fluid Draining

Post-installation Operation

- Brake Fluid Supplying
- Brake Line Bleeding (Refer to P.35A-10.)



BX0071AL




AW1114AL

Removal steps

- ▶A◀
1. Spring support
 2. Load sensing spring
 3. Brake pipe connection

4. Load sensing proportioning valve
5. Bracket



AW1086AL

INSTALLATION SERVICE POINT

▶A◀ SPRING SUPPORT INSTALLATION

1. Install the load sensing spring, and then tighten the spring support to the axle assembly temporarily.
2. Insert the lever of the load sensing proportioning valve fully into the valve side and hold it. Then adjust the spring support so that the spring length (the distance between the two ends of the spring) is at the standard value.


Standard value (A): 194 – 198 mm

NOTES

BASIC BRAKE SYSTEM

CONTENTS

GENERAL	2	ON-VEHICLE SERVICE <1800-MPI>	3
Outline of Change	2	Brake Lining Thickness Check	3
GENERAL INFORMATION	2	Brake Drum Inside Diameter Check	3
SERVICE SPECIFICATIONS	2	Brake Lining and Brake Drum Contact Check ...	3
LUBRICANTS	2	MASTER CYLINDER AND BRAKE	
SPECIAL TOOL	2	BOOSTER <1800-MPI>	4
		REAR DRUM BRAKE	6



GENERAL**OUTLINE OF CHANGE**

The following service procedures have been established due to the adoption of the rear drum brake.
<1800-MPI>

GENERAL INFORMATION

Items		1800-MPI
Rear drum brakes	Type	Leading trailing
	Drum I.D. mm	228
	Wheel cylinder I.D. mm	22.2
	Lining thickness mm	4.9
	Clearance adjustment	Automatic


SERVICE SPECIFICATIONS


Items		Standard value	Limit
Rear drum brake	Lining thickness mm	4.9	1.0
	Drum inside diameter mm	228.6	230.6

LUBRICANTS

Items	Specified Lubricant	Quantity
Backing plate	Brake grease SAE J310, NLGI No.1	As required
Shoe and lining assembly		
Automatic adjuster assembly		

SPECIAL TOOL

Tool	Number	Name	Use
	MB990964 A: MB990520 B: MB990619	Brake tool set	<ul style="list-style-type: none"> Pushing-in of the disc brake piston Installation of drum brake wheel cylinder piston cup



ON-VEHICLE SERVICE <1800-MPI>

BRAKE LINING THICKNESS CHECK

1. Remove the brake drum.
2. Measure the thickness of the brake lining at the place worn the most.


Standard value (A): 4.9 mm

Limit (A): 1.0 mm

3. Replace the shoe and lining assembly as an axle set if brake lining thickness is less than the limit. For information concerning the procedures for installation of the shoe and lining assembly, refer to P.35A-26.

Caution

If there is a significant difference in the thickness of the shoe and lining assemblies on the left and right sides, check the sliding condition of the piston.




BRAKE DRUM INSIDE DIAMETER CHECK

1. Remove the brake drum.
2. Measure the inside diameter of the brake drum at two or more locations.

Standard value (A) : 228.6 mm

Limit (A) : 230.6 mm

3. Replace the brake drum when the inside diameter exceeds the limit value or the brake drum is worn unevenly.



BRAKE LINING AND BRAKE DRUM CONTACT CHECK

1. Remove the shoe and lining assembly. (Refer to P.35A-6.)
2. Chalk inner surface of brake drum and rub with shoe and lining assembly.
3. Replace shoe and lining assembly or brake drums if there are any irregular contact area.
4. Clean off chalk after check.



MASTER CYLINDER AND BRAKE BOOSTER <1800-MPI>



REMOVAL AND INSTALLATION

Pre-removal Operation
Brake Fluid Draining

Post-installation Operation

- Brake Fluid Supplying and Air Bleeding (Refer to P.35A-11.)*
- Brake Pedal Adjustment (Refer to P.35A-7.)*

 <p>11 A14Z0003</p>	 <p>5 9 AWO747AL</p>
<p>Specified Sealant: 3M ATD Part No.8661 or equivalent</p>	<p>Grease: Silicone grease</p>



Master cylinder removal steps

- 1. Brake pipe connection
- 2. Brake fluid level sensor connector
- 3. Bracket <L.H. drive vehicles>
- 4. Master cylinder
- ▶C◀ 5. Seal

Brake booster removal steps

- 1. Brake pipe connection
- 2. Brake fluid level sensor connector
- 3. Bracket <L.H. drive vehicles>
- 4. Master cylinder
- ▶C◀ 5. Seal

- ▶B◀ ● Push rod protrusion amount check and adjustment

- ▶A◀ 6. Vacuum hose (With built-in check valve)
- 7. Snap pin
- 8. Pin assembly
- 9. Brake booster
- 10. Sealer

Fitting removal

- 11. Fitting

NOTE

- (1) *: Refer to PAJERO PININ '00 Workshop Manual (Pub. No. CKRE00E1).
- (2) The installation service points are the same as before.

REAR DRUM BRAKE


REMOVAL AND INSTALLATION

Pre-removal Operation


- Loosening the Parking Brake Cable Adjusting Nut. (Refer to GROUP 36 – On-vehicle Service)
- Brake Fluid Draining

Post-installation Operation

- Parking Brake Lever Stroke Adjustment (Refer to GROUP 36 – On-vehicle Service)
- Brake Fluid Supplying and Air Bleeding (Refer to P.35A-11.)*



14W0094
00008976



Specified grease: Brake grease SAE J310, NLGI No.1

Removal steps

1. Brake drum
2. Shoe-to-shoe spring
3. Adjuster lever
4. Auto-adjuster assembly
5. Retainer spring
6. Shoe hold-down cup
7. Shoe hold-down spring
8. Shoe hold-down cup
9. Shoe-to-shoe spring
10. Shoe and lining assembly
11. Shoe and lever assembly




12. Retainer
13. Wave washer
14. Parking lever
15. Shoe and lining assembly
16. Shoe hold-down pin
17. Backing plate (Refer to GROUP 27 – Rear Axle Shaft.)

Wheel cylinder removal steps

1. Brake drum
18. Brake pipe connection
19. Wheel cylinder assembly

NOTE


*: Refer to PAJERO PININ '00 Workshop Manual (Pub. No. CKRE00E1).



REMOVAL SERVICE POINT

◀A▶ RETAINER REMOVAL


Use a flat-tipped screwdriver or the like to open up the retainer joint, and remove the retainer.



INSTALLATION SERVICE POINTS

▶A◀ WAVE WASHER INSTALLATION

Install the wave washer in the direction shown in the illustration.



▶B◀ RETAINER INSTALLATION

Use pliers or the like to crimp the retainer or the pin positively.

INSPECTION

BRAKE LINING THICKNESS CHECK

Refer to P.35A-3.


BRAKE DRUM INSIDE DIAMETER CHECK

Refer to P.35A-3.


BRAKE LINING AND BRAKE DRUM CONTACT CHECK

Refer to P.35A-3.


**WHEEL CYLINDER
DISASSEMBLY AND REASSEMBLY**




Brake fluid: DOT3 or DOT4



Grease: Repair kit grease




Wheel cylinder repair kit



Disassembly steps

- ▶A◀ 1. Boots
- ▶A◀ 2. Piston assembly
- ▶A◀ 3. Pistons

- ▶A◀ 4. Piston cups
- ▶A◀ 5. Spring
- ▶A◀ 6. Wheel cylinder body



REASSEMBLY SERVICE POINT

▶A◀ **PISTON CUPS/PISTONS REASSEMBLY**

1. Use trichloroethylene, alcohol or the specified brake fluid to clean the piston.
- Specified brake fluid: DOT3 or DOT4**
2. Apply the specified brake fluid to the piston cups and the outer circumference of the special tool.
3. Set the piston cup on the special tool with the lip of the cup facing up, fit the cup onto the special tool.
4. Slide the piston cup down the outside of the tool into the piston groove carefully, making sure that the piston cup is twisted or slanted.


INSPECTION

Check the piston and wheel cylinder walls for rust or damage, and if there is any abnormality, replace the entire wheel cylinder assembly.



SERVICE BULLETIN

PUBLICATION GROUP, AFTER SALES SERVICE DEP.
MITSUBISHI MOTOR SALES EUROPE BV

SERVICE BULLETIN		No.: ESB-01E35-001	
		Date: 2001-07-03	<Model> <M/Y>
Subject:	REPLACEMENT AND CLEANING FOR BRAKE BOOSTER VACUUM NIPPLE ON 4G93 GDI EQUIPPED VEHICLES	(EC)CARISMA (EC)SPACE STAR (EC)PAJERO PININ	98-10
Group:	SERVICE BRAKE	draftno.: 01AL005	
INFORMATION		 O. Kai - E.V.P. & G.M. After Sales Service Dept.	

1. Description:

On 4G93-GDI engine-equipped vehicles for Europe, the vacuum nipple of the brake booster must be replaced and cleaned periodically. This Service Bulletin covers the replacement and cleaning procedures which should be added in On-Vehicle Service as shown below.

2. Applicable Manuals:

Manual	Pub. No.	Language	Page(s)
'98 CARISMA GDI Workshop Manual chassis	PWDE9502-C	(English)	35A-1
	PWDS9503-C	(Spanish)	35A-1
	PWDF9504-C	(French)	35A-1
	PWDG9505-C	(German)	35A-1
	PWDD9505-C	(Dutch)	35A-1
	PWDW9506-C	(Swedish)	35A-1
	PWDI96E1-C	(Italian)	35A-1
'99 SPACE STAR Workshop Manual chassis	CMXE99E1	(English)	35A-14
	CMXS99E1	(Spanish)	35A-14
	CMXF99E1	(French)	35A-14
	CMXG99E1	(German)	35A-14
	CMXD99E1	(Dutch)	35A-14
	CMXW99E1	(Swedish)	35A-14
	CMXI99E1	(Italian)	35A-14
'00 PAJERO PININ Workshop Manual chassis	CKRE00E1	(English)	35A-13
'00 MONTERO io Workshop Manual chassis	CKRS00E1	(Spanish)	35A-13
'00 PAJERO PININ Workshop Manual chassis	CKRF00E1	(French)	35A-13
	CKRG00E1	(German)	35A-13
	CKRD00E1	(Dutch)	35A-13
	CKRW00E1	(Swedish)	35A-13
	CKRI00E1	(Italian)	35A-13


GROUP 35A BASIC BRAKE SYSTEM

GENERAL

OUTLINE OF CHANGES

The following maintenance service points have been established to correspond to the addition of a pressure sensor. Maintenance service procedures not listed below are the same as before.

<Added>



ON-VEHICLE SERVICE

BRAKE BOOSTER VACUUM NIPPLE REPLACEMENT

1. Remove the brake booster hose from the intake manifold.
2. Replace the nipple with a new one, using a sealing agent and tighten to 15 – 18 N.m


Specified sealant:

3M ATD Part No.8661 or equivalent

Caution

Take care when applying the thread sealant as too much could block the nipple.

3. After replacement, re-install the brake booster hose.



BRAKE LINING THICKNESS CHECK

35100300241

1. Remove the brake drum.
2. Measure the wear of the brake lining at the place worn the most.


Standard value: 4.38 mm

Limit: 1.0 mm

Replace the shoe and lining assembly if brake lining thickness is less than the limit if it is not worn evenly. For information concerning the procedures for installation of the shoe and lining assembly, refer to P.35A-22.

Caution

- (1) **Whenever the shoe and lining assembly is replaced, replace both RH and LH assemblies as a set to prevent car from pulling to one side when braking.**
- (2) **If there is a significant difference in the thickness of the shoe and lining assemblies on the left and right sides, check the sliding condition of the piston.**



BRAKE DRUM INSIDE DIAMETER CHECK


35100320049

1. Remove the brake drum.
2. Measure the inside diameter of the brake drum at two or more locations

Standard value: 203 mm

Limit: 205 mm

3. Replace brake drums, shoe and lining assembly when wear exceeds the limit value or is badly imbalanced.



BRAKE LINING AND BRAKE DRUM CONNECTION CHECK


35100310053

1. Remove the brake drum.
2. Remove the shoe and lining assembly. (Refer to P.35A-22.)
3. Chalk inner surface of brake drum and rub with shoe and lining assembly.
4. Replace shoe and lining assembly or brake drums if there are any irregular contact area.

NOTE

Clean off chalk after check.

<Added>



BRAKE BOOSTER VACUUM NIPPLE REPLACEMENT

1. Remove the brake booster hose from the intake manifold.
2. Replace the nipple with a new one, using a sealing agent and tighten to 15 – 18 N.m


Specified sealant:

3M ATD Part No.8661 or equivalent.

Caution

Take care when applying the thread sealant as too much could block the nipple.

3. After replacement, re-install the brake booster hose.



**BRAKE DISC RUN-OUT CHECK AND CORRECTION**

1. Remove the brake assembly, and then hold it with wire.
2. Place a dial gauge approximately 5 mm from the outer circumference of the brake disc, and measure the run-out of the disc.

Limit: <Front> 0.06 mm or less,
<Rear> 0.08 mm or less

3. If the brake disc run-out exceeds the limit, correct it as follows:

(1) Chalk phase marks on the wheel stud and the brake disc, which run-out is excessive as show




(2) Remove the brake disc. Then place a dial gauge as shown, and measure the end play by pushing and pulling the wheel hub.

Limit: <Front> 0.2 mm, <Rear> 0.025 mm

(3) If the end play exceeds the limit, disassemble the hub and knuckle assembly to check each part.

(4) If the end play does not exceed the limit, dephase the brake disc and secure it. Then recheck the brake disc run-out.

4. If the run-out cannot be corrected by changing the phase of the brake disc, replace the brake disc or grind it with the on-the-car type brake lathe ("MAD, DL-8700PF" or equivalent).

<Added>**BRAKE BOOSTER VACUUM NIPPLE REPLACEMENT <SCREW TYPE NIPPLE>**

1. Remove the brake booster hose from the intake manifold.
2. Replace the nipple with a new one, using a sealing agent and tighten to 15 – 18 N.m.


Specified sealant:

3M ATD Part No.8661 or equivalent

Caution

Take care when applying the thread sealant as too much could block the nipple.

3. After replacement, re-install the brake booster hose.

**BRAKE BOOSTER VACUUM NIPPLE CLEANING <PRESS FIT TYPE NIPPLE>**

1. Remove the brake booster hose from the intake manifold.
2. Insert special tool into the nipple and remove the carbon deposit by rotating and reciprocating of the special tool.

Caution

The special tool should be inserted more than 50 mm and confirm that it goes through into the intake manifold.

3. Make sure that no parts of the special tool remain in the manifold.
4. After cleaning, re-install the brake booster hose.