

Technical Bulletin

Division: Automotive
 Category: Technical

Section Title: Driveline/Axle
 TSB No. TS 06 05227

SUBJECT: FRONT DIFFERENTIAL OIL SEAL REPLACEMENT
MODEL(S): VITARA (SQ420 & SQ625L), GRAND VITARA (SQ625W), GRAND VITARA XL-7 2001~2003 ONLY(JA627)

YEAR: 1999-2005

CONDITION: There is now a countermeasure part available to address premature seal failure on the front differential at the right axle.

CAUSE: Axle shaft movement.

CORRECTION: When replacing the right side front differential oil seal be sure to install the new additional support ring behind the oil seal. See below for parts information and instructions.

PART(S) INFORMATION:

Part Numbers	Description	QTY	Notes
27619-65D00	Support, Drive Shaft	1	Right side only. Install with new oil seal.
09283-35008	Seal, Oil	1	Install with Drive Support only on the right side of the Differential.

WARRANTY CLAIM INFORMATION:

Labor Operation	Description	Failed Part Number	Defect Code	Complaint Code	Labor Time
GQ24R0	Diff. Output Seal (One Side)	09283-35008	77	35	0.8hrs.



Technical Service Department
 Dealership Circulation - Initial and file:

Service Manager	Parts Manager	Service Advisor	Technicians			

Suzuki bulletins are intended for use by professional technicians, NOT a "do-it-yourselfer." They are written to inform these technicians of conditions that may occur on some vehicles, or to provide information that could assist in the proper service of a vehicle. Properly trained technicians have the equipment, tools, safety instructions, and know-how to do a job properly and safely. If a condition is described, DO NOT assume that the bulletin applies to your vehicle, or that your vehicle will have that condition. See your authorized Suzuki dealer for information on whether your vehicle may benefit from the information. Suzuki reserves the right to change technical specifications at any time without prior notice.

Drive Shaft Support Installation

1. Completely degrease the inside of the sealing surface.




2. Apply oil resistant RTV sealant to the outer surface of the drive shaft support.



3. Insert the support into the differential with the oil hole at the bottom.



4. There should be a depth of ten millimeters between the support and the edge of the differential.



5. Install the oil seal as described in the service manual.

