

# ADVANCE ADAPTERS INC.

P.O. Box 247, 4320 Aerotech Center Way

Paso Robles, CA 93447

Telephone: (800) 350-2223 Fax: (805) 238-4201

**P/N: 27-0050**

PAGE 1 OF 1

Page Rev. Date: 06-18-01

## TOY. P.U. 4CYL WITH NV4500 TRANS.

### KIT CONSISTS OF:

<u>No.</u>	<u>Qty</u>	<u>Part No.</u>	<u>Description</u>
1.	1 Kit	50-0215	NV4500/TOY. P.U. 21 SPL. T/C
2.	1 Kit	712556	CHEVY NV4500 TO TOYOTA AX5 BHSG.
3.	1 Kit	716050C	NV4500 SHIFT HANDLE ASSY.

### INSTALLATION NOTES:

This kit is designed to fit the 1996-99 GM NV4500 transmission. A new transmission may be ordered from your local GM Dealer under P/N 12572800.

**This kit requires the use of a stock Toyota 4 cylinder bellhousing (tranny codes G52, G54, W56 & G58).**

Remove the stock tailhousing and install the new adapter housing provided in this kit. Refer to the 50-0215 Instruction Sheet.

This is a parts pull sheet. Refer to the instruction sheet on each kit for proper installation.

**SPECIAL NOTE:** The components packaged in this kit have been assembled and machined for specific type of conversions. Modifications to any of the components will void any possible warranty or return privileges. If you do not fully understand modifications or changes that will be required to complete your conversion, we strongly recommend that you contact our sales department for more information. This instruction sheet is only to be used for the assembly of Advance Adapter components. We recommend that a service manual pertaining to your vehicle be obtained for specific torque values, wiring diagrams and other related equipment. These manuals are normally available at automotive dealerships and parts stores.